

1 AIP Batch Splitting

Summary

Some production processes (e.g. goods issue) require a batch (e.g. with large quantities) to be split into several batches (e.g. with smaller quantities) to be able to provide materials in smaller bins/containers at machines/workplaces. With this function the terminal provides an opportunity to separate batches and to print a label for the new batches.

Usage

These split variants are possible:

- "Simple" batches
When splitting "simple" batches, the user separates the required quantities from the original batch and generates new batches for these split quantities.
- Merged batches
When splitting merged batches, the dialog shows the individual sub-batches/serial numbers assigned to the merged batch. The user selects the sub-batches/serial numbers he/she wants to split off to generate a new merged batch.

Prerequisite

The relevant configuration has to be made to be able to use this function.

Terminal functions

The function is triggered manually by using the key of the "split batch" dialog (BATCH_SPLIT).



If the terminal is offline, only a limited number of posting functions is provided based on the available data. If the terminal is offline, errors are not displayed e.g. if posting failed on the server.

Dialog/start

The dialog opens by input of the batch number/merged batch number. The batch information on the batch/merged batch is shown.

Batch information	
Batch	1902FASS09
Material	4711
Designation	22402
Type	MAT
Class	G
Operation	C140000510000006
Machine	4202_00
Material buffer	MELT_OUT
Remaining qty.	10,0 KG
Prod.date	10.12.2013 14:54:26
Status	F
Note	
Merged batch	N

Cancel
 Splitten

Splitting "simple" batches

AIP

Split batch

Batch No. 1001234
Class G
Remaining qty. 61,0 ST

Quantity ST
Reason

☒ Yield
☐ Scrap
☐ Rework
☐ Open quantity

Quantity	Class	Reason
10,000	G	0
10,000	A	1
5,000	H	0
4,000	O	0
10,000	G	0

☐ Repost remaining quantity to new batch
☒ Reduce batch to remaining quantity

Cancel
 Add
 Remove
 Split

CTAIP V2.0.3.4 Server:scg7:4 TNR:131
03.07.14 11:40:58

Description of display fields:

- **Batch number**
Entered number of the batch that is to be split.
- **Class**
Batch class of the batch to be split.
- **Remaining quantity**
Remaining quantity of the batch to be split. At the beginning, it is the original quantity.

- **Quantity**
Quantity to be split off. The user enters this quantity.
- **Class**
Batch class of the quantity to be split off. This can be:
 - Yield
 - Scrap
 - Rework
 - Open quantity
- **Reason**
Reasons for the selected batch class.
- **Repost remaining quantity to new batch**
The remaining quantity of the original batch is reposted to a new batch.
- **Reduce batch to the remaining quantity**
The original batch is reduced to the remaining quantity.
- **Result list**
The result list shows all batches split off including the respective quantity, batch class and reason.

Function keys

- **Function key "add"**
The result list shows the entered quantity as separate entry (later the batch split off).
- **Function key "remove"**
The concerned row of the result list is selected and can be removed. The envisaged quantity is not split off and assigned again to the original batch.
- **Function key "split"**
When using the function key, all entries of the result list are split off including the relevant quantity from the entered batch.
- **Function key "cancel"**
This function key deletes all entries and the dialog is closed.

Procedure:

- The user opens the "split batch" dialog in the basic screen of the terminal
- The user selects the batch he/she wants to split off.
- Batch data of the entered batch is displayed.
- The user enters the split quantity, batch class and the reason, if necessary.
- The "add" function key adds the quantity and/or batch to be split off to the result list and displays it.
- The user may split off additional batch quantities

- The result list shows all quantities/batches to be split off
- The user decides if the remaining quantity of the original batch is to be reposted to a new batch or if it is to remain with the original batch.
- The user closes the dialog by the "split" function key and the split quantities will be posted.

Splitting merged batches

Description of display fields:

- **Batch number**
Entered number of the merged batch that is to be split.
- **Class**
Batch class of the merged batch to be split.
- **Remaining quantity**
Remaining quantity of the merged batch to be split. At the beginning, it is the original quantity.
- **Class**
Batch class of the merged batches to be split off. This can be:
 - Yield
 - Scrap
 - Rework
 - Open quantity
- **Reason**
Reasons for the selected batch class.
- **Display list**
The display list shows all sub-batches/serial numbers including the relevant quantity and article number assigned to the entered merged batch. Individual sub-batches/serial numbers are selected and split off into a new merged batch.

Function keys

- **Function key "reload"**
The display list is updated.
- **Function key "reverse"**
The selected sub-batches/serial numbers are unselected.
- **Function key "split"**
The selected sub-batches/serial numbers are assigned to a new merged batch and removed from the existing merged batch.
- **Function key "cancel"**

The dialog is closed by this function key.

Procedure:

- The user opens the "split batch" dialog in the basic screen of the terminal.
- The user selects the batch he/she wants to split off.
- Batch data of the entered batch is displayed:
 - Material
 - Quantity
 - Class
 - Reason
 - Batch status
- If it is a "merged batch" (indicator at the batch), the result list shows the serial numbers/subordinate batches assigned to this merged batch.
- The user chooses (multiple selection) the serial numbers/sub-batches he/she wants to split off into a new merged batch.
- The user selects the class for the new merged batch (and thus for the newly assigned serial numbers/sub-batches)
- The function key "split" generates the new merged batch with the split off serial numbers. The list of serial numbers is reduced and additional merged batches may be generated and, as a result, serial numbers can be split off.
- The remaining serial numbers/sub-batches remain with the original merged batch (existing number).
- Then the user closes the dialog.

Result**Result when splitting "simple" batches:**

- A new batch is generated for the quantity split off.
- The batch quality depends on the selection made
- Subject to the selected quality (yield/scrap), the batch status of the new batch is --> released/blocked
- The quantity of the old batch is reduced by the quantities split off. If the quantity is zero, the batch status of the old batch is "processed".
- Other data of split batches, such as the material number, designation, material type, storage location, material buffer, PPS batch is taken over from the original batch.
- The split event is displayed in the batch history (old batch and new batches).
- The graphic/tabular overview shows which batches have been split off from a batch.

Result when splitting a merged batch:

- The new merged batch is generated and includes all sub-batches/serial numbers selected for splitting
- The quality is identical for the merged batch and sub-batches/serial numbers (as defined)
- The quantity included in the new merged batch is the total quantity of all sub-batches/serial numbers
- Subject to the selected quality (yield/scrap), the batch status of the new merged batch and the sub-batches/serial numbers is --> released/blocked
- The old merged batch is no longer connected to the sub-batches/serial numbers split off
- The quantity of the original merged batch has been reduced by the quantity of the sub-batches/serial numbers split off. If the quantity is zero and/or if there are no longer sub-batches/serial numbers, the batch status of the old batch is "processed".
- Other data of sub-batches/serial numbers and the new merged batch, such as the material number, designation, material type, storage location, material buffer, PPS batch are taken over from the original batch.
- The split event is displayed in the batch history (old merged batch and new merged batches + serial number).
- The graphic/tabular overview shows which merged batches have been split off from a merged batch.



This dialog does not allow entering attributes/document links for individual serial numbers/sub-batches pertaining to the merged batch.