

1 Local configuration file caq_dc_t.ini

	→	
--	---	--

Some settings relating to functions of CAQ inspection data collection (AIP) can be modified individually in the file `caq_dc_t.ini`.

These settings relating to the function DLL of the same name (`caq_dc_t.dll`) can be made by the customer and/or as part of MPDV customizing.

Customizing: The customer may define versions specific to the system, terminal groups and terminals.

The configuration file can either be defined in relation to the system, terminal group or the terminal.

The file is stored according to the system by default.

The contents of configuration files that are specific to the system, the terminal or to the terminal group are NOT merged.

Example of default AIP configurations:

```
\ ctnet\win\ctaip\functions\caq_dc_t.dll  
\ ctnet\win\ctaip\functions\caq_dc_t.ini
```



Example of specific configurations:

```
\2\custom\aip\functions\caq_dc_t.ini  
\2\custom\aip\functions\tgrp_999\caq_dc_t.ini  
\2\custom\aip\functions\tnr_702\caq_dc_t.ini
```

Example of default AIP 8.2 configurations:

```
\ctnet\win\aip2\functions\caq_dc_t.dll  
\ctnet\win\aip2\functions\caq_dc_t.ini
```

Example of specific configurations:

```
\1\custom\aip2\functions\caq_dc_t.ini  
\1\custom\aip2\functions\tgrp_999\caq_dc_t.ini  
\1\custom\aip2\functions\tnr_702\caq_dc_t.ini
```



Changes to the caq_dc_t.ini file will not take effect until after the terminal software has been restarted.

Entry	Comment
[OPTIONS] section	
TIMER-CONTROLLER=[ON, OFF]	Option to control the "inspection list" GUI / data entry area when display errors occur (e.g. right section disappears or is considerably delayed or left section disappears or is considerably delayed). Default → OFF Example TIMER-CONTROLLER=ON PLEASE NOTE Also refer to the manual entitled aa_ctaip_inbetr.pdf / section: Description of the ctaip.ini file for CAQ terminal configuration / key word TIMER-CONTROLLER-MAIN Available as of ctaip.exe version 2.0.3.26 Available as of caq_dc_t.dll version 2.0.2.34 Available as of mpdv-aip.zip from 29 September 2014 onwards

Entry	Comment
. The following side effects might occur if this option is used: - The right section disappears or flickers for a short time; GUI recovers automatically after a short time - The left and right section remain open when an attempt is made to minimize ctaip.exe (Ctrl + ALT + F8) if the CAQ Inspection Results Recording is opened. Therefore, the application cannot be minimized completely if this is the case. - The right section hides the displayed screen if other dialogs or screens are opened that are not directly related to the CAQ Inspection Results Recording. The proportion of the displayed other dialog or screen varies subject to the resolution of the terminal. Consequently, working with the terminal is more or less impeded. (e.g. timer display). - Moreover, CAQ Inspection Results Recording is still focused even if another dialog or screen is opened. It might even be the case that it is difficult to make entries or entries cannot be made at all in the other dialog or screen. - The scroll bar of the inspection list might respond jerkily.	
	→
→	

Entry	Comment
[SYSTEM] section	
SCALE_FACTOR_INSPECTIONLIST= [0-100]	Option for scaling the GUI of the <i>inspection list/input area</i> at a screen ratio of 16:9 (relating to the AIP display). Default → 5 The greater the value, the smaller the display area for the “inspection list” and the greater the display area for “input functions”. The value can be changed at runtime. Effective once the “inspection list” is opened the next time. EXAMPLE SCALE_FACTOR_INSPECTIONLIST=20
[QUEUE_MODE_QM] section	
QUEUE_WARNING_SWITCH	The warning message can be switched off by setting OFF. Default: ON
QUEUE_WARNING_RESTRICTION_GLOBAL	Message text for actions modifying data Default text: Communication with the HYDRA server is currently restricted. Data are updated as soon as server communication runs without any more limitations and no dialog is open.

Entry	Comment
QUEUE_WARNING_NOT_UPDATED	Message text indicating data that may not yet have been updated. Default text: For the time being, communication with the HYDRA server is limited. The data may not be up-to-date.
QUEUE_WARNING_NOT_UPDATABLE	Message text for actions that need information from the server. Default text: For the time being, communication with the HYDRA server is limited. Data cannot be updated
[KNR] section	
DO_CHECK_KNR=[ON,OFF]	By setting this parameter, it is no longer mandatory to enter the inspector. But the "inspector" field is not removed from the dialog. Subject to the configuration of option 1130, the badge number can be checked/validated by the server. In this case, the parameter "DO_CHECK_KNR" must not be set to "OFF". The "inspector" field must not be removed from the dialogs as part of a configuration. It can only be removed via (extended) customizing.
[MW_TEIL] section	

Entry	Comment
ACRONYMS_MESSW_ESTCK_PPUNKT_SIMPLE_PART=<MM.AKRONYME><MW.AKRONYME>	The entry includes the text to be displayed in the inspection list for the relevant tree item. Context → MESSW_ESTCK_PPUNKT_SIMPLE_PART By default → ACRONYMS_MESSW_ESTCK_PPUNKT_SIMPLE_PART= MM.MMBEZ[~]MW.MW It is possible to configure several columns. The single columns are separated with a combination of characters [~]. The specific prefix followed by a dot must be put in front of each acronym. Example Displaying the OP sequence (AFO), characteristic name and measured value ACRONYMS_MESSW_ESTCK_PPUNKT_SIMPLE_PART=MM.AFO[~]MM.MMBEZ[~]MW.MW Warning: valid from version 2.0.1.1 onwards. The previous configuration with the separator [\$] instead [~] is still functioning.