

1 Local Configuration File ctaipbut.ini

Buttons are configured for specific terminals in the file ctaipbut.ini in the terminal directory c:\ctaip.

The button pages of the main view and the OP info dialog may be configured in the configuration file ctaipbut.ini.

The server directory \hydra\ctnet\win\aip includes complete INI files pertaining to the HYDRA standard. Any deviations from that are developed in specific, customized directories e.g. \hydra\1\custom\aip\trp_901.



The relevant, empty file (e.g.: ctaipbut.ini) is created here. All sections e.g. [ANR-ALL-Page1] are copied to this file. Then configuration takes place in this file.

After restarting the terminal, files from the main directory \hydra\ctnet\win\aip are merged with files from the customized directory \hydra\1\custom\aip\trp_901. Then the merged file is transferred to the local terminal directory C:\aip.



All sections including the string "page" are imported.

Entry	Comment
Definition of sections [LST-MODUS-PageX.]	General schematic structure of a button page Definition of a section LST = List identifier of the button page (MNR, ANR, LIST3) MODUS = Mode of the machine LN = MPL – Mode DN = DLL – Mode LR = RF – Mode (reel-based manufacturing) LS = RS – Mode (cutting reels) LC = Handling unit (packing station) or XX = <MPL_MOD>[1] + <TYPE>[] YY = Value from the MNR.LST column <MNRBTN.MODUS> Otherwise if no applicable entry is found for the machine mode, the section ...ALL will be used (if available) X = Button page The definition specifying the mode a machine is running on is implemented in the AIP application program.

Entry	Comment									
Sample configuration [MNR-...-Page1] 1=A_AN, L, log OP on 2=BLANK, L 3=\$MPL-PAL\$PAL_AN,L,log pallet on, 4=%BART:PZE=J%PZE,R,PZE,PZE. BMP <u>Please note:</u> In one section the numbering of entries has to be consecutive 1...n. A gap in numbering indicates the completion of a page!	<u>General structure:</u> x=<Function>,<Alignment>,<ButtonName>,<Icon> e.g. 1=A_AN,L,log OP on,AGAN.PNG - Function A_AN - Alignment L or R (from the first "R" on always "R") - ButtonName Log OP on - Icon optional icon name (PNG, resolution 24x24 px) <u>Special functions:</u> \$...\$ (e.g. \$MPL-PAL\$) License check fails → Button is deleted %...% (e.g. %BART:PZE=J% .) Check field with value in (T)terminal(K)label → only show if they match BLANK Insert distance between buttons									
Configuration of functions using wildcards x=A_AN*,L, log OP on x=A_UN*,R, interrupt OP	The dialog to be opened is located as described below if buttons are configured using wildcards ID A_UN* - calling dialog: A_AN - Determination of the machine type - Supplementing the dialog based on the machine type - Check whether or not the dialog is available if this is the case - calling dialog: A_AN_MPL - evaluation of the posting type (only with A_AN) - Supplementing the dialog based on the <i>posting type</i> - Check whether or not the dialog is available if this is the case - calling dialog: A_P_AN_MPL - Calling up the located workflow or dialog If the function is <A_UN*> or <A_AB*>, it will be checked whether or not the OP to be logged off is a merged OP. - If this is the case, <A_UN*> is changed into <SA_UN> or <A_AB*> into <SA_AB> If the virtual column <MNRDLG.SUFFIX> includes a value, it will always be used (if available). <table><tr><td>ButtonFkt</td><td>MNRDLG.SUFFIX</td><td>Dialog</td></tr><tr><td>e.g. A_UN*</td><td><XYZ></td><td>A(_P)_AN_XYZ</td></tr><tr><td>A_TR*</td><td><ABC></td><td>A_TR_ABC</td></tr></table>	ButtonFkt	MNRDLG.SUFFIX	Dialog	e.g. A_UN*	<XYZ>	A(_P)_AN_XYZ	A_TR*	<ABC>	A_TR_ABC
ButtonFkt	MNRDLG.SUFFIX	Dialog								
e.g. A_UN*	<XYZ>	A(_P)_AN_XYZ								
A_TR*	<ABC>	A_TR_ABC								

Entry	Comment
Further standard buttons: P_SPERRE VIEW ICON PDV_ISTW WF_BDE_KOM SA_AN DNC MINIMIZE	Block production status Switching of the basic view: List view ↔ presentation of individual machines Calling up icon view (only possible if configured in the machine configuration) Calling up the actual value view of PDV Input of BDE comments Log merged operation on Calling up the DNC startup screen Minimizing of the terminal program (as of V2.0.2.23) → Windows 7 requires the compatibility mode XP
USER1...USER9	User-defined buttons to show and start external software The programs are configured in ctaip.ini within the section [ext. software]
Button IDs for the machine info [MNR-ALL-Page2] 1=M_INFO.INFO, L, show information 2=M_INFO.PERS, L, staff 3=M_INFO.MSPROT, L, machine status log	Consequently, the relevant info dialog including the selected page is opened in the foreground (with focus). Switching to other pages is allowed. M_INFO may be used to show the info page in the foreground (with focus): M_INFO=M_INFO.INFO
Button IDs for OP info: [ANR-ALL-Page3] 1=A_INFO.DOKU, L, documents 2=A_INFO.HILF, L, production resources and tools 3=A_INFO.KOMP, L, components 4=A_INFO.BMK, L, RPA 5=A_INFO.FORT, L, progress 6=A_INFO.NOTE, L, notes A_INFO.TEXT1, L, User text1 A_INFO.PICT1, L, User image1 A_INFO.SCRINF1, L, User scriptInf1 A_INFO.DIALOG1, L, User dialogs	Consequently, the relevant info dialog including the selected page is opened in the foreground (with focus). Switching to other pages is allowed. A_INFO may be used to show the information page in the foreground: A_INFO= A_INFO.INFO Direct call of user-defined pages configured in ctaipplay.ini in the section [OP info]. Example: Dialog1=WF_BDE_KOM_LIST,BDE comments → A_INFO.DIALOG1, L, BDE comments

Entry	Comment
Configuration of a function with different modes Just as is the case for the configuration of the ANR/MNR info tabs, a function can be configured with different modes. 1=RES_WART.MNR,L,machine maintenance 2=RES_WART.RES,L,resource maintenance 3=RES_WART,L,other maintenance	In the configured examples, the dialog < RES_WART > is called with the below-mentioned modes. 1 < MNR > 2 < RES > 3 without mode The values can be read out as follows in the terminal script. VPar("BTN.FKT") Function + mode VPar("BTN.FUNC") Function VPar("BTN.MODE") Mode
Available button sections and buttons for pages of the OP info dialog: [A_INFO-Page1] [A_INFO.DOKU-Page1] 3=AI_VIEW,R,open document 4=AI_VIEW_CLOSE,R,close document [A_INFO.HILF-Page1] [A_INFO.KOMP-Page1] [A_INFO.BMK-Page1] [A_INFO.FORT-Page1] [A_INFO.NOTIZ] [A_INFO.DEFAULT-Page1] Recommended for all pages: 1=AI_CLOSE,L,close OP information	Overview Document view Production resources and tools Components Resource performance accounts Progress bar Notes (as of ADE 7.3) Configuration of a default page (is used if no section is defined for the tab). The IDs may also be used for the keys within the dynamic dialog (field "function").

Entry	Comment
Available button sections and buttons for pages of the machine info dialog: [M_INFO-Page1] [M_INFO.PERS-Page1] 2=P_AN,R,log person on 3=P_AB,R,log person off 4=P_AAB,R,log everyone off [M_INFO.MSPROT-Page1] [M_INFO.DEFAULT-Page1] For all pages: 1=MI_CLOSE,L,close machine information	Overview Staff logged on Machine status log Configuration of a default page (is used if no section is defined for the tab).

Entry	Comment
Definition of sections [ButtonPanel]	General section for the configuration of global settings for all used button panels → 2 in main view (MNR , ANR) → (W)ork(F)low
functionkey_visible=on	Shows function keys (e.g. "F3") in button panels in order for the selection to be performed using function keys (default = off).
radiobuttonkey_visible=on	Presentation of function keys in radio group boxes of a workflow (default = off).
functionkey_pze_visible=on	Display of function keys in PZE module (default = off).
Definition of sections [LIST3-ALL-Page1]	General section for the configuration of functions of the configurable third list of the main screen. INFO: The different types of the "3rd list" are configured in the machine label. The layout of a "3rd list" is defined in the "hytnrcfg.ini". → All used lists have to be configured with their identifier „“ as follows. → When changing machines, the "3rd list" may be hidden/shown and buttons for the "3rd lists" that are not configured may be disabled, if necessary.
as of CTAIP V# 2.0.2.33 ..=~<VISLIST-ID>~,L,,<BITMAP>	
The characters "~" (or previously "S", should no longer be used) have been designed to identify third list buttons. Correct processing/updating (disabled/enabled) is only given in the third grid list of the main screen.	
1=~M~,L,, PALETTE20x20.BMP	Entry for "material list" → "[VISLIST3(M)]" from "hytnrcfg.ini"
2=~P~,L,, PERSON20x20.BMP	Entry for "list of persons" → "[VISLIST3(P)]" from "hytnrcfg.ini"
3=~R~,L,, RESS20x20.BMP	Entry for "MNR_AMAT.LST" → "[VISLIST3(R)]" from "hytnrcfg.ini" with the configured Bitmap "
4=~A~,L,, NUM.BMP	Entry for "material list" → "[VISLIST3(A)]" from "hytnrcfg.ini"
5=~G~,L,, PERSON20x20.BMP	Entry for "list of persons GWP" → "[VISLIST3(G)]" from "hytnrcfg.ini"