

1 Recording of the Cavity-Related Partitioning on the AIP

Purpose

You use this function to document changes when tool cavities are opened or closed.

Integration

If you change the so-called partitioning (i.e. the parts per cycle), the partitioning stored for the operation selected is changed. The change of the partitioning is documented in the machine history.

If you use the Tool and Resource Management (WRM) and if you change the cavity-related partitioning, then the system also changes the partitioning that is stored for the currently logged on tool.

Requirements

This functionality requires a license. The configuration requirements are described in section [Configuration](#).

Function description

When you open the dialog, the order information is transferred from the operation selected and displayed in the dialog. Except the field *Comment*, all fields of the dialog must be filled.

Cavity number (*mandatory field*)

You can select the cavity number via list (only in connection with WRM) or enter the number manually.

Reason (*mandatory field*)

The selection list of the *Reason* shows reasons that you can select according to the "type of change" selected.

Configure the reasons on the client in the configuration "reasons". Distinguish between increase (reason type "E") and reduction (reason type "R").

Comment (*optional field*)

You can enter a comment for the posting.

Staff badge number (*mandatory field*)

Enter the ID/badge number of the person making the posting.

The person must be authorized in the HR master data to change the cycle/partitioning.



The partitioning is changed on the server. For this reason, you can only change the partitioning on the server in ONLINE mode because the lists on the terminal cannot be updated otherwise.

Configuration

Configuration on the MOC

To use the function, you must configure reasons for the increase or reduction of the partitioning. First create the [reason texts](#) on the MOC, then assign them to the [reasons](#). When you configure the reasons, you must distinguish between increase of partitioning (reason type "E") and reduction of partitioning (reason type "R").

Configuration AIP 8.1 or AIP 8.2 in list mode

In the standard configuration file ctaipbut.ini, the configuration has been prepared as follows.

Standard configuration

```
...
[MNR-ALL-Page2]
;1=M_TLG_NEST,L,Kavität ändern,Objects.png
1=M_TLG,L,Teiligkeit ändern,Objects.png
...
```

After change of the configuration

```
...
[MNR-ALL-Page2]
1=M_TLG_NEST,L,Kavität ändern,Objects.png
;1=M_TLG,L,Teiligkeit ändern,Objects.png
...
```

Configuration AIP 8.2 in tile mode



Please note the specifications made for any customer-specific configuration on the AIP. The configuration options are presented in the training EAT-AIP *Extended Application Training MES-Terminal*.

1. Close the shop floor software, if started.
2. Call the Windows Explorer (e.g. using the shortcut <Windows> + e).
3. Change to the AIP subdirectory *gui*.
4. Create a backup of the file *L_anr.xml*.
5. Start an editor (e.g. notepad) and open the file *L_anr.xml*.
6. Search for the line, that includes *M_TLG* :
 <OnClick Identifier="M_TLG" Parameterprozessor="TFocusedDataRows">Notify</OnClick>

7. Change the identifier from *M_TLG* to *M_TLG_NEST*:

`<OnClick Identifier="M_TLG_NEST" Parameterprozessor="TFocusedDataRows">Notify</OnClick>`

8. Save the file *I_anr.xml*.
9. Start the shop floor software.