

1 Controlling the Sequencing List

General

The sequencing list of the shop floor terminal is flexible and can be adjusted to meet specific requirements. The settings described below control how data is provided in the sequencing list. Please keep in mind that certain settings can only be made during the customizing process.

Workplace/ machine configuration: "Sequencing list" setting

Description

Which order pool is used to generate the sequencing list can be defined in the *sequencing list* configuration of the [workplace configuration](#) dialog.

The pool of orders is determined by planning in HYDRA shop floor scheduling or by the specifications from the PPS system and is a result of whether the OP was planned directly for a machine or a machine group.

Possible settings

S - Basic setting

The value is transferred from the option with the same name in the [HYDRA basic parameter settings](#).

M - Pool of workplaces

Only the operations planned for the workplace are displayed in the sequencing list at the terminal.

G - Pool of workplaces and groups

The sequencing list at the terminal displays those OPs that are either planned for the current workplace or for a different workplace in the group or that are still in the pool of groups.

K - Pool of workplaces and categories

The sequencing list at the terminal displays only the operations that are planned for workplaces in the same machine category.

H - Group control

The sequencing list at the terminal displays those OPs that are either planned for the current workplace or for a different workplace in the group.

Workplace/ machine configuration: "Number of OPs" setting

Description

The maximum number of OPs for the sequencing list can be configured by the option "number of OPs" within the [workplace configuration](#). The OPs are selected in ascending order based on how the sequencing list is sorted.

Possible settings

0 = no restriction (display all existing OPs)

1-999 = maximum number of OPs

Order types: "Sequencing list" setting

Description

The configuration is made at order level in the *sequencing list* option under [order types](#).

This setting can only be changed during customizing.

Possible settings

- J The OP should be displayed in the sequencing list.
- F The OP should only be displayed in the sequencing list if it is fixed.
- N The OP should not be displayed in the sequencing list.

Processing code: "Sequencing list" setting

Description

Whether or not an OP with this processing code should be displayed in the sequencing list can also be defined in the [processing codes](#) `..\..\functions\moc\MOC_ProcessingCodes.pdf` configuration.

This setting can only be changed during customizing.

Possible settings

- J The OP should be displayed in the sequencing list.
- N The OP should not be displayed in the sequencing list.

Order status assignment: "Sequencing list" setting

Description

Whether an OP should appear in the sequencing list based on its status can be defined using this option under [order status assignment](#). If an "N" is defined here, an OP in this status is not displayed in the sequencing list.

This is used as a standard feature to ensure that only prepared or interrupted OPs appear in the sequencing list.

Furthermore, it can be configured that running OPs also appear in the sequencing list.

This setting can only be changed during customizing.

Possible settings

- J The OP should be displayed in the sequencing list.
- N The OP should not be displayed in the sequencing list.

Miscellaneous notes

Generally, the following operations never appear in the sequencing list:

- Locked operations
- Individual operations from merged operations that were generated at MOC.
- The original operation for split operations
- Operations of inactive alternative sequences

Order of operations in the sequencing list

Generally, the data listed below defines how the operations are ordered in the sequencing list at the terminal:

1. Internal field for the planned start date (auftrags_bestand.sort_dat)
2. Internal field for the planned start time (auftrags_bestand.sort_dat)
3. HYDRA combined order/ operation number (auftrags_bestand.auftrag_nr)

The system fills in the internal fields for the planned start date and planned start time. This depends on how the operation was created in the system (transferred via the interface or manually created in the system) and on the planning functions used subsequently. How the system does this is described in each applicable documentation.

- [Manual editing via the user interface or via the system interface – initial data creation](#)
- [Manual editing via the user interface or via the system interface - modification](#)
- [Using HYDRA Shop Floor Scheduling](#)
- [Using HYDRA Order Sequencing](#)



When using order sequencing, we recommend to only use the "M" option (pool of workplaces) to configure the sequencing list; the order within the sequencing list at the terminal is not defined when the other options are used.