

1 PCC-DNCFICPY Log Module

1.1 DNC Driver for Filecopy

Driver name: dncficpy.dll
INI file: dncficpy.ini

Current version 7.2.2.5 as of 01/21/2013

1.2 Configuration in pccdll.ini

The element is registered in the PCCDLL.INI file:

driver=dncficpy.dll

Example:

```
[SERVICE]
tracing=1
ShowErrorWindow=0

[DRIVER_1]
driver=DNCFICPY.DLL
```

1.3 Configuration in "dncficpy.ini" File

Example configuration: for machines 4711 and 9999

1.3.1 Section [SERVICE]

[SERVICE]

info=dncficpy.dll

intervall=500

testmode=0

tracing=1 ;;activation of trace outputs.

TraceLevel=5 ;; Tracelevel (5) is suitable for output into a log file.

ExecuteQueue=0

DNCProtokoll=ON

1.3.2 Section [port x]

Within the driver, communication ports may be formed. Usually, one port is defined for each machine connected. The section names may be selected deliberately.

[DNC001] ;;(name of first group)

;;DNCTIMEOUT=300

TIMEOUT-DELETE-DOWNLFILES=10

UPL-SOURCE-EXT=nc

UPL-DEST-EXT=opt

CLR_AFTER_DOWNLOAD=OFF

;; for Upload: Configuration of separate machine directories ;; available as from version 7.2.2.2.

UPL-PATH_4711=d:\dnc\opt-4711\

UPL-PATH_9999=d:\dnct\opt-9999\

If a separate upload directory exists for a machine, when an upload takes place the file interface expects to find the machine file for an upload in this directory.

;; for Download/Upload:

;; this configuration must always exist for each machine. (Standard)

D:DNC_4711=d:\dnc_PathMaschine4711\

D:DNC_9999=d:\dnc_PathMaschine9999\

Meaning of IDs:

The ID for the DNC path assignment must always be entered as follows D:DNC_machine number
(in the example D:DNC_4711, the machine number is 4711)

d:\dnc_PathMaschine4711\ is the directory for data exchange with the machine

D:DNC_4711=d:\dnc_PathMaschine4711\

:: Polling

POLL=0 No polling must be activated

POLL_I=1000

No deletion of files in machine directory:

If the DNC file in the CTWIN directory is not to be deleted upon transfer to the machine directory, this can be achieved by the following parameter:

CLR_AFTER_DOWNLOAD=OFF

Deletion of files in machine directory:

Files in the machine directory are deleted after x minutes (in this example: 10 minutes). The time is indicated in minutes.

It must be ensured that the machine has read and processed the files in this period. If the parameter does not exist, the files are not deleted in the machine directory.

TIMEOUT-DELETE-DOWNLFILES=10

File extension of the DNC files, written by the machine, in the machine directory.

UPL-SOURCE-EXT=nc

DNC file extension with which the files are stored in the terminal directory by the driver.

UPL-DEST-EXT=opt

Download file extension of DNC files with which the files are stored in the machine directory by the driver.

DOWN-DEST-EXT=mpf