

1 MBL Advance Logon of Input Batches

Usage

Sometimes, the process may require an input batch to be already logged on in advance and set up on a machine while the preceding input batch for a material is still in use.

This situation frequently occurs in systems which are very long in design and process e.g. rollers or belts which are unwound as input batch at the system start and rewound as output batch at the system end.

Since the operator is mostly busy with activities at the system end at the time of the actual input batch change and is indeed not able to perform the input batch change at the right time, the operator may decide to log on the next input batch of an order/OP in advance.

The actual input batch change may then be achieved via a new OP logon, or a project-specific call may be established.

Procedure

The running/prepared order/OP shows the BOM. Input batches are logged on in relation to the individual BOM items.

The OP is started or is already running. At this point, the operator may log on the next input batch for this running OP or for another order/OP in advance.

For this purpose, the "Input batch advance logon" function is used. The procedure for an input batch advance logon is as follows:

- Selection of a prepared OP (OPs in running status are preassigned)
- Display/use of BOM of selected OP
- Current display of already logged on input batches relating to a BOM item
- Advance logon of an input batch for a selected BOM item/component
- The dialog also offers the possibility to log off and/or reset an already logged on input batch again (in this case, no consumption will take place → the input batch has the same condition as before the advance logon).



- Only one batch per BOM item, each, may be logged on in advance. It is not possible to log on several input batches for an OP/BOM item in advance.
- An input batch may only be logged on in advance once, i.e. it is not possible to log on the input batch in advance several times/in parallel.
- Should the input batch already be running/logged on to another order/OP and/or a BOM

item, this input batch can no longer be logged on in advance, either.

After an input batch has been logged on in advance, it will be visible in the third list in the AIP.

Input batches logged on in advance are then logged on by the OP Logon function. The prerequisite for this is

- A prepared/interrupted operation with appropriate input batches is logged on.
- If there is an input batch logged on in advance for a BOM item, this is proposed/displayed in the grid (color display).
- If there is no input batch logged on in advance for a BOM item, a batch may be logged on here → normal batch logon.
- By clicking the OK button, all batches in the list which are logged on in advance are logged on.
- The batch logged on in advance may be overwritten by a "real" batch logon.

- The input batch logon of batches with advance logon may not be used from the input batch change dialog.

This function is not included in the scope and has to be implemented via customizing if required. The BOM relating to the selected OP is displayed.

- The batch logged on in advance may not be logged off here.
- If a batch with advance logon has not been logged on, the advance logon of the input batch will be deleted by the OP interruption/logoff.



Display on MOC (Batch data overview)

Batches ("Running" status) with an advance logon for an operation and/or an integrated BOM item are marked accordingly in the batch data overview (Reservations tab → Advance logon section). A corresponding selection of these batches is then possible.

- These fields in the batch data overview cannot be changed. They are only assigned by postings on AIP.
- The display/posting of the preallocation is also deleted again if the advance logon is reversed.

- By logoff in the advance logon dialog.
- By interruption/logging off an OP (see settings) and omitted logon of the batch (OP interruption/logoff will delete advance logon of the input batch).

- The input batch advance logon is not shown in batch tracing (in tabular/graphical form).
- The input batch advance logon does not affect material movements.
- The input batch advance logon is recorded in the batch history.

