

1 Weighing Components

Usage

For operations that are not subject to batch management, it is possible to record batches in relation to discrete material components. In this special case, batches may be entered in relation to the charge via a special terminal function.

This entry function replaces the collection of quantities for the operation (e.g. partial upload) and records material consumption in relation to material components. This consumption is also posted as material movement in the system.

Prerequisites

- The function can weigh more than one charge. In this case, the operation's secondary quantity has to include the number of charges. The additional data fields of the components and operation regarding the weighing function (e.g. target quantity per charge, tolerances, etc.) also need to be taken into account.
- Every time an operation is changed, the target quantity for each charge is recalculated (formula: $\text{target quantity per charge} = \text{primary target quantity} / \text{secondary target quantity}$). It is neither possible to set the value for the target quantity per charge manually nor to display it on MOC. If the secondary target quantity is not set, the value 1 is assumed by default and only one charge is processed in the weighing operation.
- In this case, the machine does not allow to enter automatic quantities additionally.
- All components have to be managed by the "weight" unit (kilogram).



The entry function cannot be used offline.

Configuration

The configuration document describes the configurations required to use and enable the entry function at the terminal.

Posting

Data for label printing

The schema **a_vbrkomp** is provided in initial data for label printing.

This data can be printed on the label during weighing (dialog action KEW_RECORD):

Acronym	Type	Length	Description
DLG.MNR	C	10	Machine
DLG.ANR	C	40	Operation
DLG.ATK	C	40	Material number
DLG.SLP	C	40	BOM item
DLG.CHARGE	C	20	Batch
DLG.CST	C	1	Batch status F/S (free/blocked)
DLG.SGR:GUT	DEC		Target quantity
DLG.SGE:GUT	C	3	Unit of the target quantity
DLG.EGR:GUT	DEC		Actual quantity
DLG.EGE:GUT	C	3	Unit of the actual quantity
DLG.EGR:MENGE	DEC		Input quantity
DLG.EGE:MENGE	C	3	Unit of the input quantity
DLG.DAT	DATE		Date of the posting
DLG.ZEI	ZEIT		Time of the posting
DLG.KNR	C	10	The reporting person's badge number

This data can be printed on the label when completing the charge (dialog action KEW_ABSCHLUSS):

Acronym	Type	Length	Description
DLG.MNR	C	10	Machine
DLG.ANR	C	40	Operation
DLG.ATK	C	40	Material number
DLG.ATKBEZ	C	40	Material designation
DLG.CHARGE	C	20	Batch
DLG.EGR:GUT	DEC		Quantity of the batch
DLG.EGE:GUT	C	3	Unit
DLG.DAT	DATE		Date of the posting
DLG.ZEI	ZEIT		Time of the posting
DLG.KNR	C	10	The reporting person's badge number

Scale interfacing

The weight can also be entered in the weighing dialog by means of a connected scale. Upon opening the KOMP_WIEG dialog, the value is requested from the scale via the PCC driver interface and entered in the "input quantity" field.

This is an example for entering the scale value in the INI file of the driver:

<WAAGENTREIBER>.INI
V:WAAGE:NETTO=Nettogewicht_Waage

If an OPC interfacing is used, changed scale values can be sent automatically by the OPC server. For this purpose, the below-mentioned parameter has to be entered in the file "OPCMPDV.INI"
SETVALEVENTS=V:WAAGE:NETTO

<WAAGENTREIBER>.INI
SETVALEVENTS=V:WAAGE:NETTO ← additional entry V:WAAGE:NETTO=Nettogewicht_Waage