

1 Access Points

Overview

Menu	Master data → Access control → Access points
Transaction code	acpo
Function authorization	acpo

The access configuration includes different settings for the access. The reader's address and to which terminal the access is connected is defined here, for example. This application also provides for the assignment of the access to an [access group](#).

Field descriptions for the “access point” tab

Active

Specifies whether or not the access is active. Entrance is not permitted at an inactive access point.

Offline component

Offline components are access readers without permanent connection to the HYDRA server. Authorizations and access logs are synchronized via palm. This option has to be checked for offline components to enable synchronization with the palm.

Trigger clocking

This option defines whether or not a clock-in is to be generated automatically when entering this access or a clock-out when exiting this access. An auto-status clocking is generated when passing this access.

Access type

Specifies whether it is an entry, exit, passage or entry without checking. Any badge may open the access, provided that no checking is performed at this entrance.

Access group

[Access group](#) to which the access is assigned. An access can only be assigned to one access group. Access points having the same access authorizations and opening hours may be combined in an access group.

Terminal

Number of the terminal to which the access is connected. A maximum of nine entries may be assigned to terminals of the type CT-385 and CT-365.

Reader

Number of the reader that opens the door. The combination of terminal and reader results in a unique “hardware address”. For this reason, this combination has to be unique throughout the system. When it comes to time recording terminals to which additional readers are connected for access control, reader 1 is reserved for time & attendance and must not be assigned to an access point of this terminal.

The access may also be monitored without a reader, using an input of the machine interface. The “reader” field is empty in this case.

Field descriptions for the “settings” tab**Channel: opener (normally closed contact)**

Channel number of the terminal to which an opener is connected. The value “0” is entered if it does not exist. This processing is only relevant to readers by MBB Gelma and for access points that are connected to a machine interface. The opener of the reader is set automatically for remote readers of the ORIS type series (irrespective of this configuration).

Relay time: opener (normally closed contact)

Duration of the signal that is used for triggering the opener.

The maximum relay time takes nine seconds for remote readers of the ORIS type series. The terminal ignores larger entries and changes them automatically to nine seconds.

Channel opener 2 (normally closed contact)

Second channel for the opener to which a webcam or an electronic door opener can be connected, for example.

Relay time: opener 2 (normally closed contact)

Duration of the signal that is used for triggering the second channel for the opener.

Delay time: opener 2 (normally closed contact)

A delay time can be configured for the second channel of the opener. Therefore, it is possible to trigger an electronic door opener only once the door opener relay has actually been activated. The delay time can be entered in tenths of a second.



The fields "channel opener 2", "relay time: opener 2" and "delay time: opener 2" are only available if the upgrade [AccessPointOpener2](#) is enabled.

Channel shutter (normally open contact)

Channel number of the terminal to which a shutter is connected. Zero is entered if it is not available. The shutter is a door contact that is used to close the door after the maximum time that is configured for the "open" status has passed.



This channel is not set, once the permanent door opening has expired.

Relay time: shutter (normally open contact)

Duration of the signal that is used for triggering the shutter.

Channel status

Channel number of the terminal where the signal has arrived indicating whether the access is opened or closed or 0 if it does not exist.

Channel opening pushbutton

Number of the channel where a pushbutton for opening a door is connected. This allows for the authorizations of the badge to be checked when entering the room and to open it using a pushbutton when exiting the room. The opening/unlocking pushbutton can only be connected to a machine interface or an MBB reader.



If the pushbutton for opening a door is connected to a machine interface, the offset 20 used for machine interface channels is automatically replaced by the terminal program and set to offset 60. This makes sure that apart from reading the current status of the pushbutton via the electrical input of the machine interface, it is also identified if the button has been pressed briefly and released immediately since the last communication with the reader. Channel 69 displayed in the terminal program corresponds to the machine interface channel 9.

Channel sabotage

Channel number of the terminal where the monitoring signal "sabotage" has arrived or 0 if it does not exist. This channel indicates when the terminal or badge reader (subject to the model) is opened without permission.

Maximum duration allowed for "open" status

The alert "opened too long" is triggered if an access, which was opened with permission, is opened longer than the time specified here. If 0 is entered in this field the terminal assumes that the door frame contact is not connected and suppresses all alerts referring to the opening time of the access.



The maximum time for opening the door amounts to 99 seconds for remote readers of the ORIS type series and Kaba Benzing terminals. The terminal ignores larger entries and automatically sets them to 99 seconds.

Block badge after successful access (anti pass back)

Within the specified time it is impossible to open all entries of an access group that are connected to the same terminal with the same badge. A value that is greater than 0 has to be entered to enable this processing. This function is only provided by terminals of the type CT-385 (not by Kaba Benzing terminals).

Report access status

This selection defines whether or not the access point status is to be sent to the HYDRA server. Possible values are "none" or "open and closed". Provided that the "alert system" function (ZKS-ALS) has been licensed, the selection is extended by "alarms only" and "all". The options "open and closed" as well as "all" result in an enhanced server communication and should only be selected for entries that are less frequently opened or where the "open" status is to be monitored by the escalation management function.

Cycle duration for reporting the access status

The current access status is sent to the HYDRA server, once the specified time has expired.

Reload access configuration

The access configuration is downloaded from the HYDRA server to the terminal after the specified time has expired. If several entrances are connected to a terminal all access points are configured with the cycle duration of the access point assigned to the least access number.

Reload authorizations

Authorizations are downloaded from the HYDRA server to the terminal, once the time specified here has expired. If several access points of the same access group are assigned to a terminal this setting is only processed by the access with the lowest access number of the access group and also applies for the other access points.



The values of all channels to be configured (opener, closer/shutter, status, sabotage) range between 1 ... 2, 21 ... 49 or 91 ... 92. The channels 1 + 2 are internal reader relays, while the channels 21 ... 49 are set on a machine interface that might be connected (channel 21 = machine interface channel 1, ...) or that set the corresponding relays for Kaba Benzing

terminals of the type 9290. The channels 91 and 92 are internal inputs and outputs of Windows terminals. With DOS terminals internal terminal inputs and outputs can be addressed via the channels 1 and 2. 0 is to be assigned to a channel that is not to be used.

Field descriptions for the “advanced settings” tab

Trigger alarm

Defines whether or not the alarm is to be triggered on the configured channel. If this field is not activated the alarm is not triggered.

Channel alarm

Number of the terminal channel where the alarm is output. A siren might be connected to this channel, for example. The internal relays 1+2 at the terminal or machine interface outputs (entry 21-49, whereas 21 corresponds to the machine interface channel 1) may be triggered.

Delay time alarm

In case a delay time is entered, the “open w/o permission” status is no longer set. Instead of this, the access switches to the “opened too long” status after this delay time and the maximum time for opening the door have expired.

Acoustic alarm at reader

Defines whether or not an acoustic alarm is to be triggered if one of the statuses “opened w/o permission”, “opened too long” or “sabotage” is available. This function is only provided by readers of the type series ORIS and S6D at Windows terminals as of ctwin version 7.2.3.67 onwards.

Channel alarm system

Number of the terminal channel to which an alarm system is connected. Access attempts are generally rejected if the alarm system is activated and this input is set.



The fields of the “alarm configuration” are only available, provided that the “alarm system” license (ZKS-ALS) has been purchased.

Entrance to room zone

A [room zone](#) that is entered through the access point may be entered in this field.

Exit from room zone

A room zone that is exited through the access point may be entered in this field.

Floor

A separate access can be created for each floor when an elevator control is in use. Consequently, different authorizations may exist for each floor. The access points of an elevator control are connected to the same reader and, as a result of this, the same value is entered in the fields “terminal” and “reader”. The floor number must be unique at a reader.

Security gate with access points

If an access is entered in this field, the currently selected access as well as the entered access build a security gate. When it comes to a security gate, only one of the assigned access points may be opened at a time. The entries of a security gate have to be connected to the same terminal.



The fields in the groups "room zone monitoring", "elevator control" and "security gate function" are only available if the license "room zone, elevator control/security gate function" (ZKS-RAS) has been purchased.

Channel signal (bag check)

Number of the terminal channel where a signal is output, when a bag check is to be made. A rotating flashing beacon may be connected, for example, to this channel.

Relay time: signal (bag check)

Time in seconds of the signal that is used to activate the rotating flashing beacon.



The fields in the "bag check" group are only available if the "personnel check" license (ZKS-PKT) has been purchased.

Channel biometry, validity period

A stand-alone biometric system can be connected to HYDRA access control at this channel. The entrance is only opened if an authorized badge is read within the specified "validity period" after the biometric hardware has set the input (contact).



The fields "biometry channel" and "validity period" are only available if the upgrade [AccessPointBiometry](#) is enabled.