

1 Cycle Parameters

Summary

Menu	Master data → Workplaces/ machines → Cycle parameters
Transaction code	cycpa
Function authorization	mdcycl

Usage

HYDRA provides the ability to monitor cycle times within the machine data recording function without requiring HYDRA process data processing to be used.

The purpose of this function is to configure the action and tolerance limits.

Integration

Values are marked in different colors in the *Workplace overview* depending on whether the action or tolerance limit was exceeded:

Standard	Black
If the value drops below or exceeds the action limit	Blue
If the value drops below or exceeds the tolerance limit	Red



If a limit is exceeded, no further processing steps are taken in HYDRA.

Requirement

Before defining any configurations, you must first set up the [machine](#).

Selection criteria

The application provides the following selection criteria:

Machine

Selection by machine/ workplace

Field descriptions

Machine

Machine for which the configuration applies.

Tolerance limit positive, negative

Values may not drop below or exceed the percentage values defined here. The cycle time of the logged on operation is always used as the target value for cycle time monitoring. This can be corrected at the terminal. The limit value is entered as a percentage of the target value.

Example: Target value: 20 sec/ cycle
tolerance positive: 10 %
tolerance negative: 5 %

Thus, this results in the following limit values:

Upper limit value: 22 sec/ cycle
lower limit value: 19 sec/ cycle

Action limit positive, negative

Percentage values can be entered here, triggering a warning once they have been reached. This is why the action limits should be defined more narrowly than the tolerance limits. The limit value is entered as a percentage of the target value.