

1 Dynamic Dialogs - Function Keys

Overview

Menu	System administration → Terminals → Dynamic dialogs, tab "Dynamic dialogs - function keys"
Transaction code	ddconf
Function authorization	ddconf

Other option:

Menu	System administration → Terminals → Dynamic dialogs - function keys
Transaction code	ddconfb
Function authorization	ddconfb

Purpose

You can use the dialog configuration to change the AIP input dialogs in a quick and efficient manner according to the user's requirements.

The system delivery includes a basic dialog configuration. You can edit and change this configuration using the functions described in the following.

You can edit the function keys of dialogs in two places: in the tab integrated in the application "Dynamic dialogs" and in the application "Dynamic dialogs - function keys". You can change existing function keys (e.g. positioning), create new function keys or delete others.



The complete functionality of the dialog configuration includes a lot of options, but it is also very complex. For this reason, we recommend to change the dialogs only after consultation with MPDV and only by experts.

Integration

To define dialogs; fields and the order of tabs, you must not only use the application "Dynamic dialogs - function keys", but also the applications "Dynamic dialogs - workflow", "Dynamic dialogs" and "Dynamic dialogs - fields".

Requirements

The dialog that you want to configure must already exist in the "Dynamic dialogs".



Some of the functions require the development license MDS-AIS to be fully available. The restricted functions are marked in the document using "(*)".

Basics of the functions without development license:

- Existing data can be changed. Only data for default dialogs with user 0 must not be changed without development license.
- You cannot create new data without development license, except fields in existing dialogs.
- You can copy the existing data to terminal groups or terminals and then change them. Without development license, you cannot copy to default dialogs with user 0.

Selection criteria

The application provides the following selection criteria:

Dialog

Selection by dialog

Type

You can select from different dialog types:

- DEF – standard dialog
- TNR – terminal dialog
- TGRP – dialog for terminal group

User

Selection by terminal number or terminal group

Editing functions

The application "Dynamic dialogs - function keys" only provides the usual editing functions: insert, edit and delete.

If you use the application "Dynamic dialogs", you can change into the toolbar tab "Dynamic dialogs - function keys". This toolbar provides the usual editing functions and additionally the detail application "Edit function keys". Using this editing application, you can easily manage and edit the function keys of a dialog.

Detailed application "Process function keys"

In the detail application "Edit function keys", you can right-click the table view to open a **context menu**. The context menu provides the following functions:

New row (*)

The function "New row (*)" adds a new empty row to the grid to define a function key.

Several new rows (*)

The function "Several new rows (*)" adds the specified number of new empty rows to the grid.

Copy row (*)

The function "Copy row (*)" copies the currently selected row and adds it to the grid.

Delete row(s) (*)

The function "Delete row(s) (*)" deletes the currently selected row(s) from the grid.

Swap function keys (*)

Using the function "Swap function keys (*)", the selected rows are swapped. The following types of swapping exist:

- **Swap position**

With "Swap positions", the X and Y positions for function keys of the two selected entries are swapped (relevant CTWIN + ACTIONBUTTON).

- **Swap button no.**

With "Swap button no.", the button number and therefore also the tab order of the function keys is swapped.

Align buttons (*)

Using the function "Align buttons (*)", an automatic alignment of the buttons in the x or y direction is possible.

Move buttons (*)

Using the function "Move buttons (*)", you can move one or several function keys in the x or y direction. Buttons are moved using the specified offset ("Move by").

Apply function keys from other dialog (*)

Using the function "Apply function keys from other dialog (*)", you can take over several function keys from the dialog selected.

Field description

Button no.

The field "Button no. (*)" specifies the sequence number of the button in the dialog. This number specifies the tab order.

Return code

The field "Return code" defines the further processing after confirmation of the function key.

0: Dialog is closed and the dialog string is sent to the server.

1: Dialog is canceled.

7: Dialog is closed, the dialog string is returned, but not sent.

8: Dialog is not closed; the virtual keyboard must still be displayed.
(relevant with CTWIN)

9: Dialog is not closed.

Identifier

The field "Acronym" includes the value of the acronym for the return value; is returned as `BTN=<acronym>`

ID index

The field "Acronym index" includes the index for the return value in case of several similar data fields; is supplied with KENN, e.g. `"..|BTN=BTN:UNDO|.."`

Activated

This option is only available for reasons of downward compatibility. Select the option "Always" as of MW 3.x.

Key

Only CTWIN: You can use the field "Key" to configure the function key for the activation (hotkey) F1 to F12. By default, the key assignment is displayed on the button. The display is blocked if you place a "*" before the definition (e.g. `KEY=*F1`)

AIP: The function keys of the dialog are automatically assigned in the order of display to the function keys F1 to F12 of the keyboard.

Text

The field "Text" includes the button text (label) displayed.

X pos.

The field "X pos." specifies the X position of the button (top left corner of the button). (Relevant with CTWIN + ACTIONBUTTON).

Y pos.

The field "Y pos." specifies the Y position of the button (top left corner of the button). (Relevant CTWIN + ACTIONBUTTON).

Width

The field "Width" specifies the button width. (Relevant CTWIN + ACTIONBUTTON).

Height

The field "Height" specifies the button height. (Relevant CTWIN + ACTIONBUTTON).

Information

The field "Information" specifies the info text displayed as tooltip if the button is moused over.

	dialog "Log on input batch (CE_AN, CE_AN_RF)"
	General functions for navigating in tables (only CTWIN)
GRID_DOWN	next row
GRID_UP	previous row
GRID_LEFT	column left
GRID_RIGHT	column right
GRID_PAGEDOWN	next page
GRID_PAGEUP	previous page
PRINT	Calling the print (only CTWIN and in the dialogs "Form pallet (C_PAL_ASW)" and "Pallet (C_PALETTE)")
SEND	General function to perform server posting (only in the dialogs "Enter GR batch (C_GEN)" and "Repost batch (C_UMB)")
VERBRAUCH:RELOAD (consumption:reload)	Function "Reset (refresh consumption)" only in dialog "Component consumption posting (A_VERB)"
VERBRAUCH:START (consumption:start)	Calling the dialog "Component consumption posting (A_VERB)"
VTST	Showing/hiding the virtual keyboard (only required with CTWIN)

License

Optional: The field "License" includes the license required to activate the function key. If the field is empty, the key is always active.

User defined 1

The field "User def. 1" can include additional configuration options.

If you specify the value ACTIONBUTTON in field "User def. 2", you can configure the button layout in field "User def. 1".

Example: „clYellow,2,5,clBlack“

Syntax	color	clYellow	(default \$0080FF)
	layout	2=rectangle	(0=capsule (default), 1=ellipse, 2=rectangle)
	corner radius	5	(default 10, only with layout 2=rectangle)
	font color	clBlack	(default clBlack)

User defined 2

In field "User def. 2", you can configure the following configuration options:

FORM-VALIDATION

Before executing the button function, the system checks if the contents of the input fields are valid, as it does when the dialog is closed.

ACTIONBUTTON:

As with "FORM-VALIDATION", the system checks if the contents of the input fields are valid.

You are free to position the ACTIONBUTTONS in the dialog. You specify position and size using the fields "X pos.", "Y pos.", "Width" and "Height". You specify the layout in field "User def. 1".

Blocked

If the field "Blocked" is selected, the button is not displayed and not processed. If dialogs are activated, the button is not passed to the terminal.