

1 Dynamic Modification Norm

Summary

Menu	Master data → Quality Management → Dynamic modification norm
Transaction code	dynn
Function authorization	dynn

The dynamic modification norm defines how much items/parts are to be checked with which inspection severity taking the batch size into account ("actual quantity" field in the inspection requirement of the goods receipt and goods issue dialog).

Provided that a skip lot variant is to be used, this one is also defined/activated here.

Utilization

The "norm" field uniquely identifies a dynamic modification norm in the corresponding QM applications. This field is the key field at the same time, i.e. when saving it is checked whether there is already a data record with this key information.

The norms "ISO_2859" and "ISO_3951" are initial entries, which can neither be changed nor deleted. Inspection levels, AQLs and sample tables are defined for the norms "ISO 2859" and "ISO 3951" and the methods s and sigma are additionally defined for ISO 3951.

Different dynamic modification norms can be created. An inspection severity definition is assigned to these dynamic modification norms. A selection list that includes the previously defined inspection severities is available for this assignment process.

In addition, a radio button in the "inspection type" field decides whether this norm applies for attributive or variable characteristics only or for attributive and variable characteristics. Consequently, within the inspection plan characteristics of a variable characteristic it is later only possible to choose the dynamic modification norms that have been defined for variable or for variable and attributive characteristics. If the "variable" inspection type is selected the sampling plan type may be indicated additionally. When it comes to the inspection types "attributive" and "attributive + variable", "n-c-d + skip lot" is taken automatically as sampling plan type. The "variable" inspection type additionally provides the option "n-k + skip lot".

n = Sample size

c = Acceptance number (number of errors/defects which is still allowed to achieve a "pass" result)

d = rejection number (number of errors/defects as of which the inspection result is "failed", i.e. the batch is to be rejected)

k = k factor as limit value for the acceptance or rejection / inspection result is classified as "pass" or "fail" (please refer to the corresponding norms for further information on this k factor.)

Integration

The following applications use dynamic modification norms.

- Inspection planning (inspection plan characteristics) for goods receipt and goods issue.

Prerequisite

Inspection severities and transitional definitions need to be created beforehand to be able to define dynamic modification norms. The "dynamic modification norm" application, if considered individually, is not functional. Consequently, it has to be used and assigned in the inspection plan characteristics, which in turn requires the dynamic modification to be activated in the inspection plan header.

Selection criteria

Selection criteria are self-explanatory and are not described separately.


Field descriptions

The available fields are self-explanatory and are not explained separately.

There is a selection list including acceptance functions to assign inspection severity definitions.

Toolbar

Sampling plan



Assignment of sampling plans to dynamic modification norms

Function to assign sampling plans to a previously defined and selected dynamic modification norm.

Detail applications

Detail application sampling plan

The fields "AQL value", "inspection level" and "method" are only available in the initial DIN norms that cannot be changed. The same applies to the sampling plan type "n-k + skip lot". For this reason, the field for the k factor only appears in these sampling plans.

This detail application connects increments of the sample size with a defined batch size for every inspection severity. A selection list is available for the inspection severity.

If an entry is made without specifying the batch size, the specifications of all batch sizes apply that are greater than the highest batch size that is defined.

The copy dialog allows for all sampling plans of the indicated norm and inspection severity to be copied to the specified target norm and target inspection severity.

Field descriptions

Inspection severity

Inspection severity for which the below-mentioned inspection specifications are defined.

Batch size

Gradation for which batch size the below inspection specifications are defined. The indicated batch size represents the upper limit that is included. The lower limit is the next smallest batch size that is defined for the same inspection severity.

Sample size

Defines the number of measured values to be recorded for the combination of inspection severity and batch size.

Acceptance quantity

Limit value for the number of allowed failures/defects with respect to the combination of inspection severity and batch size, which still results in the batch to be accepted or the characteristics to be rated as "pass" for dynamic modification relating to characteristics.

Quantity rejected

Limit value for the number of allowed failures/defects with respect to the combination of inspection severity and batch size, which results in the batch to be rejected or the characteristics to be rated as "fail" for dynamic modification relating to characteristics. Ideally, the rejection quantity is increased by 1 (compared to the acceptance quantity) to be able to make a unique decision.

Skip lot

Provided that a skip lot is to be defined for the specified inspection severity, a value greater than 1 is to be entered here. If the value 3 is entered, this means that only one batch out of three is to be checked as soon as this inspection severity is reached. The sample size as well as the acceptance and rejection numbers that are indicated here apply when checking the inspection severity.