

1 Edit Order Components

Summary

Menu	Order management → Order management → Edit components of the order
Transaction code	edorcomp
Function authorization	edorcomp

Utilization

Materials required for manufacturing an article/item are assigned to an operation or order as "(material) components". This function allows for material components of an order to be displayed or edited.

Normally, these components are transferred to HYDRA using an interface from the higher-level ERP system, as these components are already defined in the ERP work plan.

Prerequisite

The relevant order has to be created.

Selection criteria

The following selection criteria are available in the application:

Order

The components assigned to an order may be selected by entering an order.

Field descriptions

Order

The order number to which the production resources and tools are to be assigned can be entered in this field.

Material

The material number of the material component can be entered here.

Designation

The material designation can be entered in this field.

Comment 1 / comment 2

These are comment fields.

BOM item

In a bill of material the components of a product are referred to as items. The number entered here arranges the BOM items within the BOM. Consequently, identical material numbers may occur in the component list but data will still be assigned to the correct position of the component.

When it comes to reel-based manufacturing, it refers to the position of the component within the layer structure.

Please note that the BOM item is an integral part of the identification key.

BOM level

A component can also have several levels. Enter the BOM level here, provided that it is available and known.

Please note: Postings can only be made for materials of the BOM level 0. If a BOM level > 0 is entered, the component type (see next field) will generally be set to "I" (information component).

Component type

Component type. Possible values are:

- | | |
|---|---|
| M | Material component. The component type is to be indicated here. The other types might also be relevant for MPL or its reel-based solution MPL-RF. |
| I | Info component. Information components can be shown in the component list without having to be posted. |
| T | Carrier material (MPL-RF).
A maximum of one input batch may be logged on to the machine as carrier material (T) or added material (Z). |
| Z | Added material as alternative for the carrier |
| A | Scrap/waste material |

Material type

Material type of the material component. The material type controls processing specific to the material in HYDRA.

Unless otherwise stated in the project, the material type SYSTEM is to be assigned.

The material type must exist in HYDRA. If no material type is entered, HYDRA tries to determine the material component (prerequisite: the assignments of material to the material type are up-to-date). If no material type is found HYDRA assigns the material type SYSTEM.

Please note: A separate material type (e.g. INFO) should be defined and assigned for information components (material type "I").

Consumption type

The following input options are planned for material components. The definition of individual options and their usage depends, among other things, on which HYDRA modules are in use.

K = None

This option specifies that no consumption is collected for this material component. In this case, the material component is only displayed.

"Info components" (see above: material type) have to be set to this option.

D = Discrete

With this component, the consumption is determined in a retrograde manner at the Windows terminal, i.e. based on the last produced quantity and suggested in the posting dialog. The consumption is posted for the component and a material movement (goods issue from production) is generated that can be uploaded to the higher-level ERP system (however, this requires the relevant interface for uploading goods movements).

This type of material consumption recording needs to be configured especially while HYDRA is customized.

L = with batch reference (relevant if MPL/TRT is in use)

This option results in the material component to be logged on and off as HYDRA batch. Calculating the consumption for this material component (retrograde, with logging the input batch off) depends on the configuration of the material type to which the material component is assigned.

Required quantity/unit

Planned total quantity of the component within the operation.

It is calculated automatically from the target quantity of the operation (primary quantity unit) multiplied by the input quantity of the component.

The required quantity is only shown in the table as well as in the detail panel.

Input quantity

Planned input quantity of the component for each unit of the operation's primary quantity.

MPL, consumption type D: Planned input quantity of the component for each unit of the operation's primary quantity

Unit

Quantity unit for the input quantity

Input quantity in % / upper tolerance limit / lower tolerance limit

Reserved. No processing. Should be set to 0.

Replaceable

If this flag is set, another than the planned material may be used for the component. However, in this case, only material of the same material type can be used.

Requirement to change output batch

The input batch change for a batch of this material also requires an output batch change. Please note in this context:

☒, if type = T or Z

☐, if type = I or A

☒☐, if type = M

Otherwise: N

Superior component: BOM item/BOM level

Reserved. No processing.

Toolbar



Edit operations

Starts the application [edit operations](#).



Edit orders

Starts the application [edit orders](#).



Order information

Starts the application [order information](#).