

1 Elevator Control

Summary

The elevator control allows for several entrances (floors) to be controlled via one reader. When a badge is read, the terminal checks all entrances (floors) that are configured for this reader and releases the door opener contacts of the authorized accesses, which are linked with the pushbuttons of the elevator and release the appropriate buttons.

The door status contact indicates which button was pushed. Provided that the door status contacts are configured in accesses, the access protocol is only generated, once a button has been pushed and thus it is possible to check in the access protocol which floor the employee entered. In case the door status contacts are not configured in entrances, an access protocol is generated for each authorized floor. Thus, it may be checked who might be in a floor, however without knowing whether the employee has actually entered this floor.

A separate access/entrance is created for every floor of an elevator control. Consequently, each floor may have different authorizations. If several accesses/entrances are created for one reader it is verified that the floor number is unique. The floors are defined in the “advanced settings” tab of the [access](#).



Online-checks are not performed for the elevator control to avoid one or several online checks from being made every time the elevator is used by employees who are not allowed to enter all floors.



A maximum of nine entrances and, as a result, nine floors may be managed by one ZKS terminal.