

1 Automatic generation of orders - processing

Overview

	→	
Menu	Production facility (resource) management → Current information → Maintenance calendar → button "Generate order"	
Function authorization	rmcalgenorder	
Menu	Production facility (resource) management → Current information → Resource overview → button "Generate order"	
Function authorization	-	
Menu	Production facility (resource) management → Resource analysis → Resource history → button "Generate order"	
Function authorization	reshigenorder	
Menu	Production facility (resource) management → Resource analysis → Machine history → button "Generate order"	
Function authorization	wphigenorder	

Purpose

You can call the function "Generate order" from different MOC applications. Use this function to generate an order from a work plan.

Integration

You can use one of the following applications to create an order:

- Maintenance calendar
- Resource overview
- Resource history
- Machine history
- Production variants



For this purpose, the toolbar of these applications provides the button "Generate order".

Requirements

You need a license to call the function "generate order".

You also have to configure the following in the MOC:

- Correct configuration of [Number ranges](#):
 - o Object: order number
 - o Key: order type
 - o Value: 6
 - o Type: automatic number assignment
 - o Prefix: IH *)
 - o Ranging from: 100000 *)
 - o Ranging to: 999999 *)
- *) Assumption: 8-digit order number length.
- The work plans used according to the configuration must exist
(By default: work plan IH100000)

Generating orders

Proceed as described below to execute the function "generate order":

- Select a resource / data record.
- Click the function "generate order".
- Enter the data requested in the respective dialog.

Once you have entered and confirmed the data, the system transfers the data entered in the input fields (including invisible fields) to the service. The order is generated based on the transferred work plan.

Result of order generation

The system generates the order.

If order generation was successful, the application *Edit orders* opens automatically. The input field *Order* includes the new order number and data is requested automatically.

Note:

If the *Additional data* tab does not include the order number (or the dialog has been customized and the field is no longer available), you have to configure the automatic number assignment since no target order number is indicated.

The system issues an error message (e.g. order number is missing) if the order could not be generated.

Configuration

By default, work plan number "IH100000" (the number of zeros matches the order number length defined in the basic settings) is predefined for all maintenance orders. The work plan number is configured in the MOC application [Order generation](#). If necessary, you can change this number according to your requirements. To do so, you need the corresponding license.

You can change the work plans, if you have purchased the corresponding license.

Default dialogs

Maintenance calendar

Field	Default assignment
Resource type	Resource type
Resource	Resource
OP name/designation	Description of the activity
Basic start date	Current date
Basic end date	(none)
Order	Work plan number The system takes the number of the work plan that should be used to generate an order from the configuration " Order generation ". You have to select a work plan if the configuration does not include a work plan.
Final article	Resource
Transfer as production resources and tools	Resource type = MNR No default assignment Resource type <> MNR Checked by default " ☒ ". In this case, the resource is also created as production resource and tool.

Resource overview

Like the maintenance calendar, except for the OP name. Here, the OP name is "maintenance order".

Resource history, machine history

Like the maintenance calendar, except for the OP name. Here, the OP name is "maintenance order".



You can use the MES Development Suite to configure the default assignments in the MOC application dialogs where you started the *Generate order* function. You need a license and training in order to use the MES Development Suite.