

1 Editing Serial Numbers

Overview

Menu	Order management → Order management → Edit serial numbers
Transaction code	edser
Function authorization	edser

Usage

Serial numbers are assigned in order to be able to distinguish individual material items from each other. The combination of material number and serial number clearly identifies an individual item. Serial numbers are usually assigned in the ERP system when a production order is created.

Integration

Serial numbers are created in the ERP system and transferred from the ERP system via the order data interface. In the system, they are administered as details for the order header. Each serial number is unique within a production order and is composed of a character string with a maximum of 20 characters.

Serial numbers are entered at the AIP when operations are interrupted or logged off. Serial numbers are entered individually with quantity 1 for a running OP and then uploaded to the ERP system as a partial confirmation.

In addition, a serial number may be administered as a batch in the MPL. In this application case, the serial number exists as a batch number with quantity 1 and may be used upon entry for tracking material which is kept in batches.

Selection Criteria

The following selection criteria are available in the application:

Order

HYDRA order number or MES order number (combined order/OP number)

Order type

Operation and/or order header

Serial number

Available or entered serial number

Usage

F = Free/not entered yet
A = Serial number entered as scrap
G = Serial number entered as yield
P = Serial number entered as open quantity
N = Serial number entered as rework
X = Serial number locked

Field Descriptions

--	--	--	--

Order

HYDRA order number for "Order header" order type and/or
MES order number for "Operation" order type.

Order type

Order type AU or AG (AU = order header, AG = operation)

Usage

Stock = Free / not entered yet
Yield = Serial number, entered as yield
Scrap = Serial number, entered as scrap

Reason

If a serial number was entered as scrap, the scrap reason is indicated here.

Reason text

Display of text entered as the scrap reason

Serial number

Available or entered serial number

Editor

User who created or last edited the entry.

Toolbar



Insert

This function can be used to create a new serial number for an order (order header). It is only possible to create one serial number for an order and with "Stock" usage.

**Edit**

This function can be used to modify the usage and/or the scrap reason for an existing serial number.

If "Scrap" is used, the scrap reason is defined here. The scrap reason must have been defined as the SYSTEM reason in HYDRA.

**Delete**

This function is used to delete an existing entry for a serial number. By selecting them, several entries can be deleted at the same time.

**Order information**

Calls up the [order information](#) application.