

1 Print Status List

Summary

Menu	Master data → Workplaces/ machine status assignment → Status list
Transaction code	- (mst for machines/ workplace status assignment)
Function authorization	mdmst.print

Usage

The purpose of this function is to generate a status list with clear text and barcodes. A barcode provides the ability to enter the status at a terminal using a barcode reader (e.g. a scanner gun).

Integration

The function is called up from the status assignment of machines/ workplaces.

A printed barcode provides the ability to enter the status at a terminal using a barcode reader (e.g. a scanner gun).

To print a status list, follow the steps listed below:

1. In the list, highlight the status you would like to print out on the status list. Click on the top left-side corner of the table if you want to highlight all statuses.
2. Click on the "status list" icon to call up the print preview screen. In it, there will be one new page for each workplace/ machine.
3. Click on the icon "Print report"  in the print preview to print out the status lists on the default printer set in MOC.

Structure of the workplace/ machine status barcode

NNNNN0

Place	Designation	Length
*	Asterisk	1
N	Machine status, with preceding zeros	5
0	fixed: 0	1
*	Asterisk	1
Length of status barcode without asterisks		6

Please note:

By default, HYDRA supports the barcodes "39", "128" and "Interleaved 2 of 5"

The system only supports barcode detection and automatic assignment to the corresponding input fields at the terminal for barcode readers that are connected at the serial port (COM port). This is not possible for barcode readers that are "looped in" through the keyboard.