

1 Reasons

Summary

Menu	Master data → Workplaces / Machines → Reasons
Transaction code	reas
Function authorization	mdreas

Usage

Use this configuration to create or to change the reasons available in the system. Reasons may either be created for the entire system or referred to a workplace

Integration

The reasons that are saved to the system will be available for collection on the terminal as well as in different applications. They are used to classify quantities of materials or modifications.



In order for the settings or the changes made to be able to be interpreted by the terminal shop floor program, the terminal, which the workplace/machine is assigned to, has to be restarted. All terminals should be restarted, provided that new reasons have been created or reasons affecting the entire system have been changed.

Requirements

You have defined [reason texts](#) in the system.

Selection criteria

The following selection criteria are available in the application:

Type

Reason type, e.g. scrap

Workplace

Workplace selection.



Reasons that are configured for the "workplace" SYSTEM, will always be displayed even if a workplace will explicitly be restricted.

Reason

Unique reason number

Designation

Designation of the reason. Wildcards can be used.

Superior reason

Selection of a superior reason. All reasons will be selected that have the selected reason as (direct) superior reason.

Field descriptions

Workplace

Assignment of a reason text to a workplace. If "SYSTEM" is entered, this will apply as system-wide assignment.



System-wide reasons will always apply in addition to the workplace-specific reasons and will therefore also be displayed in the terminal's selection list.

Type

Classification and/or grouping of reasons

Possible values:

A	Scrap reason
N	Rework reason
P	Open quantity reason (before: problematic quantity)
G	Yield reason: will be interpreted as deviation reason
L	Reasons for batch logs (relevant in connection with MPL)
R	Reduce (partitioning) reason (relevant in connection with WRM)
E	Increase (partitioning) reason (relevant in connection with WRM)

Reason

Identification number of the reason.



As system-wide reasons always apply in addition to reasons relating to workplaces, their numbers have to be unique, i.e. a scrap reason with the number 99 for the SYSTEM workplace must not be defined at the same time as workplace-related scrap reason assigned to the number 99.

Reason text no.

Identification number of the [reason text](#)

Designation

Related reason text from the reason text configuration.

Ext. reference

For each assignment exists an alphanumeric representation that can be uploaded back to the interface, for example

Scrap material

Is used in connection with HYDRA-MPL

Superior reason

The reference to a superior reason is reserved for further extensions/modifications; at present it has no function and should consequently not be completed.

“Copy“ detail application

The "copy" button can be used to copy reasons defined in relation to a workplace from one workstation to the next. Reasons of the "workplace" SYSTEM cannot be copied.

The below-mentioned options are supported while copying:

- Copy currently selected reason

This option can be used to copy the currently selected reason. For this purpose, enter the below pieces of information in the fields below "To":

- Workplace: target workplace for which the reason is to be copied
- Type: Choose the reason type under which the reason is to be created for the target workplace. The field is assigned by default to the type of the currently selected reason.
- Reason: Enter the reason number under which the reason is to be created for the target workplace. The field is assigned by default to the type of the currently selected reason.

- Copy all reasons

This option allows copying of all reasons defined for a workplace to another workplace. However, a prerequisite for this is that reasons have not yet been configured for the target workplace. To do so, enter the target workplace for which the reasons are to be copied in the "workplace" field. Please note that all workplace reasons are always copied, irrespective of the type of the reason.

- Copy missing reasons

In contrast to the previous option, this function allows for reasons to be copied to another workplaces, even if reasons are already assigned to this workplace. To do so, enter the target workplace for which the reasons are to be copied in the "workplace" field. Please note that all workplace reasons will always be copied, irrespective of the type of the reason.