

1 Group assignment

Overview

HYDRA menu	Master data → Workplaces/machines → Group assignment
FEDRA menu	Detailed scheduling → Master data → Group assignment
Transaktionscode	grpa
Function authorization	mdgrpa

Purpose

This function allows for resources to be assigned to groups.

Integration

At the moment, this is needed to assign workplaces/machines to

- Capacity groups that are used in the shop floor scheduling module,
- location groups that may be taken into account for scheduling,
- evaluation/report groups that may be used as selection criterion in versatile evaluations/reports,
- line groups that are used by the industry solution "bottling".

Additional assignments may be performed but they are not relevant to the system processing.

Requirements

The requirement for assigning a resource is that the group you want to assign the resource to has already been created. This is performed by the configuration Master data => Workplaces/machines => [Groups](#).



Please note in this context the "[Notes on editing groups and group assignments](#)".

Selection criteria

The application provides the following selection criteria:

group

Group ID

Resource

Selection of the assigned resource

Resource type

Selection of the resource type

Field descriptions**group**

Identification number of the group

→ If the group is a capacity group it may only be 8 characters long at most. In case of numeric machine numbers (configured in the basic parameter settings of HYDRA), the number has to be filled up to 8 characters with leading zeros.

Resource type

Resource type of the resource that is to be assigned to the group. The following has to be taken into account:

Assignment of people from the HR master:	"PNR"
Assignment of workplaces/machines:	"MNR"
Assignment of other resources (WRM/DNC):	Respectively configured resource type in WRM/DNC

Resource

Unique resource number. Subject to the resource type, it is

"PNR"	Personnel number with leading zeros according to the length configured in the basic parameter settings of system.
"MNR"	Workplace/machine number, a max. of 8 characters. The number has generally to be filled up to 8 characters with leading zeros.
<Resource type>	Resource according to WRM/DNC

Position

This field allows for the sequence of workplaces within a capacity group to be defined for capacity groups that are planned in the graphic planning board.