

1 Signature Matrix

Summary

Menu	System administration → System settings → Signature matrix
Transaction code	sigmat
Function authorization	sigmat.*

Usage

The signature matrix is used in the signature collection to define which posting must be entered within the system under which conditions and with which [signature type](#).

Integration

These settings will be taken into account for both, editing dialogs of the MES Operation Center (MOC) and entry dialogs of the terminal.

Requirements

You have defined signature types in the system.

You have maintained users in the [user master data](#) and persons in the [HR master data](#). You have linked both objects. This will ensure that each signature contains the name as well as the personnel and the badge number.

Field descriptions

Dialog

The dialog for which these signatures/ levels/ conditions are saved

Formula

The condition that must apply for the dialog to ensure that the indicated signature(s) will be requested.

Numerous [logical and mathematical operators](#) are available to the formula's formulation.

Values are compared with each other by inputting double equal signs "==". The value which the comparison is based on has to be put in double inverted commas.

Example:

It has to be checked whether it is an operation or an order header:

ANR.ATYP == "AU" (retrieves the order header)

ANR.ATYP == "OP" (retrieves the operation)

The values available in each dialog are presented in the dialog's documentation.



Documentation / contents	Link
BDE – master data	here
BDE – input dialogs	here
MDE – master data	here
MPL – master data	here
MPL – input dialogs	here
MW – master data	here
PDV – master data	here
HR master	here
WRM – master data	here
WRM – input dialogs	here

If postings are rejected at the terminal with an error that can be overridden by a so called mandatory posting, the terminal will transfer the field BZWRET together with the entered data. In the authorization matrix this field can be retrieved as follows in order to admit this compulsory posting for specific authorized persons only, for example.



The mandatory posting codes 1110 (person is not logged on at order), 1243 (with the posting an overproduction according to the target quantity check is detected for a person) and 1249 (with the posting an underproduction according to the target quantity check is detected for a person) can, for example, be retrieved as follows from the authorization matrix of the signature collection:

```
(( "1110" in BZWRET) || ("1243" in BZWRET) || ("1249" in BZWRET))
```

A customer-specific extension by additional variables (e.g. user fields) is possible via the getdata function of the hyd_sig_getdata.hsc script.



The dialog data is available as import variable DLG_DATA (C32000) in this script. Moreover, the desired field identification for that field that is not included in the dialog data will be entered into the script together with the import variable VAR_NAME (C255). In the export variable VAR_DATA the value of the field (C255) will be given back.

Comment

A freely selectable designation option for comments.

Priority

The condition will be evaluated according to the priority order, in which the lowest priority comes first.

Signature 1/ 2

One or two signatures may be configured for each posting dialog.

Both, identical and different signature types may be combined.

Level 1/ 2

The authorization level that is necessary for the corresponding signing signature.

The authorization level is stored to the [HR master data](#) (BDE authorization) for each individual person.

In order to execute the action, the authorization level of the person must be same or higher than the specified level.