

1 Station Andon Board

Overview

Menu	Production facility/Resource management → Current information → Station Andon Board
Transaction code	stab
Function authorization	stab.view (application) stab.editor for the button "edit layout"

Purpose

Use the Station Andon Board to visualize the status of the production line for management, supervisors and/or staff working on the production line.

Integration

The Station Andon Board shows up-to-date status information on objects from various HYDRA products:

- DMC: data from the DMW (Dynamic MES Weaver) including machines (stations) and their statuses.

Requirements

Set up the relevant objects you want to visualize on the Station Andon Board in the system master data.

Layouts specify the visualization of data. Use the [layout editor](#) to generate the layouts you want to use in the Station Andon Board.

Configure the MQTT communication in order to use the Station Andon Board. Required configurations are described [here](#).

Selection criteria

The application provides the following selection criteria:

Layout

List of available layouts.

The list includes centrally stored data and local user data.

The system uses the path "DMCSTATA" created in the [HYDRA path configuration](#) to identify centrally stored data.

Store local user layouts in the directory %APPDATA%\MPDV\MOC\user\StationAndon on the local PC.



The list of available layouts is created on opening the application. Close and reopen the application if you want to update the list.

Visualization

The selected layout specifies the visualization of data. The layout specifies what data is shown and how.

Use the messaging protocol MQTT to transfer DMW data to the HYDRA-MW and to show this data in the MOC.

Toolbar



Editor

Starts the [layout editor](#) to change existing or create new layouts.