

1 Activating Palletizing/ Packaging/ Assembling

Requirements

Ensure that:

- The flag "Batch management requirement" is set at the operation
- The operation material type does not have the flag "Consumption balance"
- The primary quantity unit for the operation is "KG"

Ensure that at the [workplace](#):

- The flag "Batch administration" is set
- The machine type "Packing location" is selected
- Machine monitoring is not activated

Procedure

Assign the [workplace to a terminal](#). Reboot the terminal.

Results

The following specific dialogs are available at the terminal for the configured packing location:

<i>Dialog</i>	<i>Description</i>
A_AN_HU	Log packing OP on (no input batches)
A_P_AN_HU	Log packing OP on (no input batches, with person)
CE_AN_HU	Assign batch to running OP/ TPU
CA_WL_HU	Complete TPU (output batch change)
A_UN_HU	Interrupt packing OP
A_AB_HU	Finish packing OP
A_AUT_HU	Log off/ interrupt OP selection
C_VLOS_HU	Display preceding TPU



The TPU batch numbers created are permanently generated at the terminal with the prefix HU.
The prefix is not currently configurable.



There is no off-line entry capability

