

1 Configuration QM/CAQ Status

Processing

Details to process or create status as well as the handling of system options can be taken from the manual "MOC_status.pdf" and "QMStatus".

2 Description and Configuration of Statuses

Status type: BEWERTART Evaluation Type

Default entries:

Status	System status	Status Short name	Long description of status	Inactive	Addition
DEP	0	Abt.bewert.	Evaluation of department	0	
LFB	0	Lief.bewert.	Supplier evaluation	0	

Description:

Categorization can be done using the assignment of an evaluation type in the evaluation management (supplier evaluation).

Editable/extensible:

Yes / Yes

Subject to area

No

Additional parameters:

None

Status type: BEWSTATUS – Evaluation type

Default entries:

Status	System status	Status Short name	Long description of status
ABGESCHL (completed)	0	compl.	Completed
BEARB	0	in proc.	in process
BEWERTBAR	0	assessable	assessable
BEWERTET	0	evaluated	evaluated
ERZEUGT	0	generated	generated

Description:

Possible status of the supplier evaluation.

Editable/extensible:

Yes / Yes

Subject to area

No

Additional parameters:


The assigned additional parameter in the standard for this status is currently not considered functionally.

[ABG]

Indicates evaluations which have been completed.

[INIT:BEWERTET]

Identifies the status that is assigned when an outstanding supplier evaluation has been evaluated.

Status type: CPLFREIGABE – List item of released control plans

Default entries:

Status	System status	Status Short name	Long description of status	Inactive	Addition
1	1	Manufacturer/ site	Manufacturer/ site	0	
2	1	customer	customer	0	
3	1	Customer development	Customer development	0	
4	1	Customer quality	Customer quality	0	
5	1	other	other	0	

Description:

These statuses make up the list of releases in the production control plan.

Editable/extensible:

Yes / Yes

Subject to area

No

Additional parameters:

none

Status type: EGWEINS – Action probability for unilateral distribution
Default entries:

Status	System status	Status Short name	Long description of status	Inactive	Addition
1	1	84.1345% (1 Sigma)	84.1345% (1 Sigma)	0	
1.28	1	90% (1.28 Sigma)	90% (1.28 Sigma)	0	
1.64	1	95% (1.64 Sigma)	95% (1.64 Sigma)	0	
1.96	1	97.5% (1.96 Sigma)	97.5% (1.96 Sigma)	0	
2	1	97.725% (2 Sigma)	97.725% (2 Sigma)	0	
2.33	1	99% (2.33 Sigma)	99% (2.33 Sigma)	0	
2.58	1	99.5% (2.58 Sigma)	99.5% (2.58 Sigma)	0	
3	1	99.865% (3 Sigma)	99.865% (3 Sigma)	0	
3.09	1	99.9% (3.09 Sigma)	99.9% (3.09 Sigma)	0	
3.72	1	99.99% (3.72 Sigma)	99.99% (3.72 Sigma)	0	
4	1	99.9968% (4 Sigma)	99.9968% (4 Sigma)	0	

Description:

Selection options and/or calculation values for Sigma to compute unilateral limit values (warning and action limits).



No status must be added. It is only allowed to deactivate in order to reduce the selection list.

Editable/extensible:

No / No

Subject to area

No

Additional parameters:

none

Status type: EGWZWEI – Action probability for bilateral distribution

Default entries:

Status	System status	Status Short name	Long description of status	Inactive	Addition
1	1	68.27% (± 1 Sigma)	68.27% (± 1 Sigma)	0	
1.28	1	80% (± 1.28 Sigma)	80% (± 1.28 Sigma)	0	
1.64	1	90% (± 1.64 Sigma)	90% (± 1.64 Sigma)	0	
1.96	1	95% (± 1.96 Sigma)	95% (± 1.96 Sigma)	0	
2	1	95.45% (± 2 Sigma)	95.45% (± 2 Sigma)	0	
2.28	1	97.5% (± 2.28 Sigma)	97.5% (± 2.28 Sigma)	0	
2.33	1	98% (± 2.33 Sigma)	98% (± 2.33 Sigma)	0	
2.58	1	99% (± 2.58 Sigma)	99% (± 2.58 Sigma)	0	
3	1	99.73% (± 3 Sigma)	99.73% (± 3 Sigma)	0	
3.09	1	99.8% (± 3.09 Sigma)	99.8% (± 3.09 Sigma)	0	
3.45	1	99.95% (± 3.45 Sigma)	99.95% (± 3.45 Sigma)	0	
3.72	1	99.98% (± 3.72 Sigma)	99.98% (± 3.72 Sigma)	0	
3.9	1	99.99% (± 3.9 Sigma)	99.99% (± 3.9 Sigma)	0	
4	1	99.9937% (± 4 Sigma)	99.9937% (± 4 Sigma)	0	

Description:

Selection options and/or calculation values for Sigma to compute bilateral limit values (warning and action limits). It is not allowed to add further entries during customizing.



No status must be added. It is only allowed to deactivate in order to reduce the selection list.

Editable/extensible:

No / No

Subject to area

No

Additional parameters:

none

Status type: EGWZWEI_RS – Action probability for bilateral distribution (r and s chart)

Default entries:

Status	System status	Status Short name	Long description of status	Inactive	Addition
0.9	1	90%	90%	0	
0.95	1	95%	95%	0	
0.975	1	97.5%	97.5%	0	
0.99	1	99%	99%	0	
0.995	1	99.5%	99.5%	0	

Description:

Selection options and/or calculation values for Sigma to compute bilateral limit values (warning and action limits) for the r and s chart.). It is not allowed to add further entries during customizing.



No status must be added. It is only allowed to deactivate in order to reduce the selection list.

Editable/extensible:

No / No

Subject to area

No

Additional parameters:

none

Status type: EMUMMTYP_VDA24 – Initial sampling assignment of characteristics VDA volume 2, 4th edition

Default entries:

Status	System status	Status Short name	Long description of status	In-active	Addition
MASS	1	Measure	Size check	0	
FUNKTION	1	Function	Function test	0	

WERKSTOFF	1	Material	Material testing	0	
HAPTİK	1	Haptics	Haptic test	0	
AKUSTİK	1	Acoustics	Acoustics test	0	
GERUCH	1	Odor	Odor test	0	
AUSSEHEN	1		Visual test	0	
OBERFLÄECHE	1	Surface	Surface test	0	
EMV			EMV test (electromagnetic compatibility)		
	1	EMV		0	
ZUVERLÄESSIG	1	Reliability	Reliability test	0	

Description:

Depending on the status of the EMUFORM status type, possible assignments are made in the EMUMMTYP_VDA24 status type. The selection made can be printed on the form.

Editable/extensible:

No / No

Subject to area

No

Additional parameters:

None

Status type: ERFASSART – Input types

Default entries:

Status	Status Short name	Long description of status	Addition
BEWERT_ESTCK	Eva. Single unit	Single unit evaluation	[DYNDLG:Q_MW_B_EST], [BAPI:CPAUMW],[M_MAX:1]
BEWERT_ESTCK_	Eva. Single unit Insp. pt.	Evaluation of a single unit of an inspection point	[DYNDLG:Q_MW_B_EST], [BAPI:CPAUMW],[M_MAX_NUM:1]
BEWERT_ESTCK_STICHPR	Eva. Single unit sample	Evaluation of single unit of a sample	[DYNDLG:Q_MW_B_EST], BAPI:CPAUMW]
BEWERT_MERK	Eva. Charac.	Evaluation of a characteris- tic	[DYNDLG:Q_MW_B_MER], [BAPI:CPAUSP],[M_MAX:1]
BEWERT_STICHPR	Eva. sample	Evaluation of a sample	[INIT_A],[DYNDLG:Q_MW_B_STP], [BAPI:CPAUSP]
BEWERT_STICHPR_SIMPLE	Eva. sample	Evaluation of a sample (once).	[RK]
BEWERT_STICHPR_FSK	Eva. FSK (in- spection chart) sample	Evaluation of a sample (in- spection chart)	[BAPI:CPAUMW],[BEURTBASIS:S P],[FEHLERERF:FU,FO]

BEWERT_STICHPR_PPUNKT	Eva. sample Insp. pt.	Evaluation of an inspection point in a sample	[DYNDLG:Q_MW_B_MER], [BAPI:CPAUSP],[M_MAX_NUM:1]
BEWERT_STICHPR_PPUNKT_FSK	Eva. FSK (inspection chart) insp.pt.	Evaluation of sample belonging to an inspection point (inspection chart)	[BAPI:CPAUMW],[M_MAX_NUM:1], [BEURTBASIS:SP],[FEHLERERF:F U,FO]
BEWERT_STICHPR_PPUNKT_SIMPLE	Eva. sample Insp. pt.	Evaluation of sample belonging to an inspection point (once).	[DYNDLG:Q_MW_B_MER],[BAPI:CPAUMW],[M_MAX_NUM:1],[BEURTBASIS:SP],[RK]
CODE_ESTCK	Sing. unit code	Code for single unit	[DYNDLG:Q_MW_C_EST], [BAPI:CPAUMW],[M_MAX:1]
CODE_ESTCK_PPUNKT	Sing. unit code Insp. pt.	Code of single units of an inspection point	[DYNDLG:Q_MW_C_EST], [BAPI:CPAUMW],[M_MAX_NUM:1]
CODE_ESTCK_STICHPR	Sing. unit code sample	8.3.11 Code of single unit of a sample	[INIT_V],[DYNDLG:Q_MW_C_EST], [BAPI:CPAUMW]
CODE_MERK	Code charac.	Code for characteristic	[DYNDLG:Q_MW_C_MER], [BAPI:CPAUSP],[M_MAX:1]
CODE_STICHPR	Code sampl.	Code for sample	[DYNDLG:Q_MW_C_STP], [BAPI:CPAUSP]
CODE_STICHPR_PPUNKT	Code sampl. Insp. pt.	Sample code of an inspection point	[DYNDLG:Q_MW_C_MER], [BAPI:CPAUSP],[M_MAX_NUM:1]
MESSW_ESTCK	Meas. val. Single unit	Measured value for single unit	[DYNDLG:Q_MW_M_EST], [BAPI:CPAUMW],[M_MAX:1], [HIST]
MESSW_ESTCK_PPUNKT	Meas. val. Single unit Insp. pt.	Measured value of single units of an inspection point	[DYNDLG:Q_MW_M_EST], [BAPI:CPAUMW],[M_MAX_NUM:1], [HIST]
MESSW_ESTCK_PPUNKT_SIMPLE	Meas. val. Single unit Insp. pt.	Measured value of a single unit belonging to an inspection point (once).	[DYNDLG:Q_MW_M_EST],[BAPI:CPAUMW],[M_MAX_NUM:1],[HIST],[RK]
MESSW_ESTCK_STICHPR	Meas. val. Single unit sample	Measured value of single units of a sample	[DYNDLG:Q_MW_M_EST], [BAPI:CPAUMW],[HIST]
MESSW_ESTCK_STICHPR_SIMPLE	Meas. val. Single unit Insp. pt.	Measured value of a single unit of a sample (once).	[BAPI:CPAUMW],[HIST],[RK]
MESSW_MERK	Meas. val. Charac.	Measured value for a characteristic	[DYNDLG:Q_MW_M_MER], [BAPI:CPAUSP],[M_MAX:1]
MESSW_STICHPR	Meas. val. sample	Measured value of a sample	[DYNDLG:Q_MW_M_STP], [BAPI:CPAUSP]
MESSW_STICHPR_PPUNKT	Meas. val. sample Insp. pt.	Measured value of a sample of an inspection point	[DYNDLG:Q_MW_M_MER], [BAPI:CPAUSP], [M_MAX_NUM:1]
PROBENZUG_PPUNKT_SIMPLE	Tak. samples Insp. pt.	Taking samples within an inspection point (once).	[BAPI:CPANUMP],[CONST_CAPTURE_STATE:NECESSARY]
PROBENZUG_PPUNKT_ERWEITERT	Ext. sampling Insp. pt.	Taking samples with an inspection point (extended)	[BAPI:CPAUMW],[M_MAX_NUM:1], [BEURTBASIS:SP],[PRBZUG]

Description:

Status to define and structure the dialogs in the terminal.



Only a limited amount of statuses are available which is dependent on the CAQ version.

Editable/extensible:

Yes / No

Subject to area

No

Additional parameters:

[DYNDLG:Q_MW_B_EST]	Dialog to evaluate single unit
[DYNDLG:Q_MW_B_MER]	Dialog to evaluate a single unit of an inspection point
[DYNDLG:Q_MW_B_STP]	Dialog to evaluate single unit of a sample
[DYNDLG:Q_MW_C_EST]	Dialog to enter the code of the single unit
[DYNDLG:Q_MW_C_MER] [DYNDLG:Q_MW_C_MER]	Dialog to enter the code of the inspection point
[DYNDLG:Q_MW_C_STP]	Dialog to enter the code for the sample
[DYNDLG:Q_MW_M_EST]	Dialog to enter measured values for the single unit
[DYNDLG:Q_MW_M_MER]	Dialog to enter measured values for the inspection point
[DYNDLG:Q_MW_C_STP]	Dialog to enter measured values for random sample
[BAPI:CPAUMW]	BAPI for single units
[BAPI:CPAUSP]	BAPI for samples and inspection points
[M_MAX:1]	
[M_MAX_NUM:1]	
[INIT_A]	
[HIST]	

[RK]

from CAQ 8.2 deleting this parameter deactivates the display of the control charts in the collection dialog for all collection types.

- BEWERT_STICHPR_SIMPLE
- BEWERT_STICHPR_PPUNKT_SIMPLE
- MESSW_ESTCK_PPUNKT_SIMPLE
- MESSW_ESTCK_STICHPR_SIMPLE

Using CAQ 8.1 version activates/deactivates the behavior customer specifically.

Status type: FEHLER_KLASSE – Defect classes

Default entries:

Status	System status	Status Short name	Long description of status	Inactive	Addition
	0			0	[INIT],[IFCRCK:]
01	0	Critical	Critical defect	0	[IFCRCK:01]
02	0	Major def. A	Major defect A	0	[IFCRCK:02],[INIT_V]
03	0	Major def. B	Major defect B	0	[IFCRCK:03]
04	0	Min. def. A	Minor defect A	0	[IFCRCK:04]
05	0	Min. def. B	Minor defect B	0	[IFCRCK:05]
A1	0	QM def. proven	Defined in the QM system proven	0	[IFCRCK:A1]
A2	0	not def. proven	not defined proven	0	[IFCRCK:A2]
A3	0	def. main. proven	Defined, mainly proven	0	[IFCRCK:A3]
A4	0	not def., main. proven	not defined, mainly proven	0	[IFCRCK:A4]
A5	0	not prov.	not proven	0	[IFCRCK:A5]

Description:

The status defines the possible QMS defect class and can only be used for QMS. By default, all defect classes available in SAP are included.

Editable/extensible:

Yes / Yes

Subject to area

No

Additional parameters:

[IFCRCK:<Status>]

controls which data value is returned to SAP via the QM-IDI interface for the respective defect class.

[INIT_V] Statuses with this parameter are suggested in certain QMS input dialogs when defects occur in variable characteristics.

[INIT]

If the parameter is used for other applications, then it needs to be checked how it is used in the system and its functionality.

Status type: FHLBEW_EINHEIT – Units of defect evaluation**Default entries:**

Status	System status	Status Short name	Long description of status	Inactive	Addition
	0			0	[INIT]
EUR	0	Euro	Euro	0	
MIN	0	Min.	Minutes	0	

Description:

This status enables a QMS environment to evaluate the defect.



This status is only available for QMS defect collection.

When using HYDRA QMS, these status entries must possibly be adapted to the units available in SAP to evaluate defects.

The upload interface for QM IDI defects only provides space for three characters. Therefore, only the first three characters of the corresponding status ID are used for reporting/confirmation via QM IDI.

Editable/extensible:

Yes / Yes

Subject to area

No

Additional parameters:

The parameter assigned to this status in the standard is currently not considered functionally.

Status type: INTERVAL – Intervals**Default entries:**

Status	System status	Status Short name	Long description of status	Inactive	Addition
JAH	1	Year(s)	Year(s)	0	31557600
MIN	1	Minute(s)	Minute(s)	0	60
MON	1	Month(s)	Month(s)	0	2629800
SEK	1	Second(s)	Second(s)	0	1
STD	1	Hour(s)	Hour(s)	0	3600
TAG	1	Day(s)	Day(s)	0	86400

Description:

Defines the interval units based on which calculations are made in HYDRA. This status list is available for characteristics to specify inspection intervals.



No status of this type must be added manually.

It is only allowed to deactivate in order to reduce the selection list. But it must be safeguarded in this case that the deactivated status is not used anywhere else.

Editable/extensible:

No / No

Subject to area

No

Additional parameters:

This additional parameter defines the factor to multiply the interval in order to convert into seconds.



Additional parameter to assign to the status must not be changed.

Status type: MASSNTYP – Measure types

Default entries:

Status	System status	Status Short name	Long description of status	Inactive	Addition
KEINE	0	no assignm.	no assignment	0	[INIT],[RECTYPE:REK]
KURZF	0	Short-term	Short-term	0	[RECTYPE:REK]
LANGF	0	Long-term	Long-term	0	[RECTYPE:REK]
MITTELF	0	Medium-term	Medium-term	0	[RECTYPE:REK]

Description:

This status defines possible measure types.

Editable/extensible:

Yes / Yes

Subject to area

No

Additional parameters:



The assigned additional parameter in the standard for this status is currently not considered functionally.

Status type: MASSTATUS – Measure status

Default entries:

Status	Sys-tem status	Status Short name	Long description of status	Inacti-ve	Addition
BEARB	0	in process	in process	0	[BEARB],[BGC:65535],[FGC:0],[NUMWERT:50],[OUTLSTAT:1,4,3]
ERLEDIGT	0	completed	completed	0	[FERTIG],[INIT:FERTIG],[BGC:652]

(done)					80], [FGC:0],[NUMWERT:100],[OUTLS TAT:2]
To do	0	open	open	0	[INIT],[OFFEN],[BGC:255], [FGC:0],[NUMWERT:0],[OUTLSTA T:0]
SICHT (view)	0	sighted/re ad	sighted/read	0	[OFFEN],[BGC:255],[FGC:0], [NUMWERT:0],[OUTLSTAT:0]

Description:

Status entries for the possible statuses of a measure.

Editable/extensible:

Yes / Yes

Subject to area

No

Additional parameters:

The following additional parameter are supported functionally from CAQ 8.1.

- [NUMWERT:50]
- [NUMWERT:0]
- [NUMWERT:100]

These parameter control the quantifier in the supplier evaluation.



All other assigned additional parameter in the standard are currently not supported functionally.

Status type: MT_NORM – Standards for measuring tolerances

Default entries:

Status	System Status	Status Short name	Long description of status	Inactive	Addition
EN 12420	1	EN 12420	DIN EN 12420 (drop forgings	1	[ID]

			of material group 1; cat. A and B)		
ISO 2768	1	ISO 2768	General tolerances according to DIN ISO 2768	0	
ISO 7168	0	ISO 7168	Shape and position tolerance ISO 7168	0	
ISO_PASS	0	ISO fit	ISO fit measures	0	[ID]

Description:

This status defines the standards available for the calculation of characteristic tolerances.



This status must only be edited or extended for configuration from CAQ 8.2.

Editable/extensible:

Yes / Yes

Subject to area

No

Additional parameters:

[ID] Identifier indicating that for an unambiguous selection of an entry from the `caq_passung` table, the field `passung_id` is additionally required.

If this additional parameter is not set, it is sufficient to select the standard.



Some standards use texts to describe the fit ID (burr, misalignment, etc., e.g. with EN12420). These are not translated in multi-lingual installations.

Status type : PANVERWENT -**Inspection requirement usage decision****Default entries:**

Status	System status	Status Short name	Long description of status	In-active	Addition
BEDFREIGABE (conditional release)	0	cond. rel.	conditional release	0	[DYN:NIO],[BEWPENT
FREIGABE (release)	0	Release	Release	0	[INIT:IO],[INIT:SKL],[D
NACHARBEIT (rework)	0	Rew.	Rework	0	[DYN:NIO],[BEWPENT
RUECKWEISEN (reject)	0	Rej.	Reject	0	[INIT:NIO],[DYN:NIO],[
SORTIEREN (sort)	0	Sort	Sort	0	[DYN:NIO],[BEWPENT

Description:

These statuses define the usage decisions available when inspection requirements are completed.

Editable/extensible:

Yes / Yes

Subject to area

No

Additional parameters:

[DYN:IO]	Inspection requirements with this status are considered as a "Pass".
[DYN:NIO]	Inspection requirements with this status are considered as a "Fail".
[INIT:IO]	If all inspection steps (PAUERG) = Pass
[INIT:SKL]	If all inspection steps are (PAUSTATUS) = SKL
[INIT:NIO]	If at least one inspection step (PAUERG) = Fail
[BEWPENT:xyz]	Weighting of the usage decision in the supplier evaluation module

Status type: PRFERG_STPR – Inspection results of samples
Default entries:

Status	System status	Status Short name	Long description of status	Inactive	Addition
BEDINGT_IO	1	cond. pass	conditionally pass	0	[IO],[DYN:NIO]
IO	1	pass	pass	0	[IO],[DYN:IO]
NIO	1	fail	fail	0	[NIO],[DYN:NIO]
UNGEPR (unchecked)	1	unch.	unchecked	0	[INIT],[IO],[DYN:IO]

Description:

Defines the statuses of samples

Editable/extensible:

No / No

Subject to area

No

Additional parameters:

[IO]

Samplings with this status are considered a "Pass".

[NIO][IO]

Samplings with this status are considered a "Fail".

[INIT]

Initial default assignment when generating a sample

[DYN:IO]

Within the dynamic modification the sampling is considered a "Pass"

[DYN:NIO]

[DYN:IO]

Within the dynamic modification the sampling is considered a "Fail" .



Within the available configuration options only the assignments of parameter „[DYN:IO]“ and „[DYN:NIO]“ can be changed.

Status type: QMS_ART – QMS - Type of inspection requirements

Default entries:

Sta- tus	System status	Status Short name	Long description of status	Inac- tive	Addi- tion
01	0	Receiving insp.	Goods receipt inspection for order process	0	

		Best.			
0101	0	Goods receipt samp. inspec. f. ord. Best (order)	Goods receipt sample inspection for order process	0	
0130	0	Receiving insp. Fremdb. (external contracting)	Goods received inspection from external processing	0	
02	0	Goods issue	Goods issue WAP	0	
03	0	Done!	Production order FEP	0	[INIT]
04	0	Goods receipt FA	Goods receipt from production order	0	
05	0	Gen. goods receipt	General goods receipt	0	
06	0	Return	Returns from customer	0	
07	0	Audit	Audit	0	
08	0	Stock transfer	Stock transfer	0	
0800	0	Insp. batch if QM active	Inspection batch with Q-stocks when activating QM.	0	
10	0	Del. with cust. ord.	Delivery to customer with customer order	0	
11	0	Del. without cust. ord.	Delivery to the customer without customer order	0	
12	0	Gen. del.	General delivery	0	
89	0	All	All	0	

Description:



The status is only used with HYDRA QMS (subsystem SAP QM).

Editable/extensible:

Yes / Yes

Subject to area

No

Additional parameters:



The assigned additional parameter in the standard for this status is currently not considered functionally.

Status type: QMS_HERKUNFT – QMS - origin of the inspection requirement

Default entries:

Status	System status	Status Short name	Long description of status	Inactive	Addition
01	0	Receiving insp.	Goods receipt inspection	0	
02	0	Goods issue	Goods issue WAP	0	
03	0	Done!	Production order FEP	0	[INIT]
04	0	Goods receipt FA	Goods receipt from production order	0	
05	0	Gen. goods receipt	General goods receipt	0	
06	0	Return	Returns from customer	0	
07	0	Audit	Audit	0	
08	0	Stock transf.	Stock transfer	0	
10	0	Del. with cust. ord.	Delivery to customer with customer order	0	
11	0	Del. without cust. ord.	Delivery to the customer without customer order	0	
12	0	Gen. del.	General delivery	0	
89	0	All	All	0	

Description:



The status is only used with HYDRA QMS (subsystem SAP QM).

Editable/extensible:

Yes / Yes

Subject to area

No

Additional parameters:



The assigned additional parameter in the standard for this status is currently not considered functionally.

Status type: REKART – Complaint types

Default entries:

Status	System status	Status Short name	Long description of status	In-active	Addition
INTERN	0	internal	Internal complaint	0	[AW:('ABTEILUNG','PERSON')]
CUSTOMER	0	Cutomer compl.	Customer complaint	0	[AW:KUNDE],[INIT]
LIEFERANT (supplier)	0	Supplier compl.	Supplier complaint	0	[AW:LIEFERANT]

Description:

Defines the type of complaint. Complaint types as well as additional parameters can be extended and/or modified as part of customizing the system.

Editable/extensible:

Yes / Yes

Subject to area

Yes

Additional parameters:



The assigned additional parameter in the standard for this status is currently not considered functionally.

Status type: REKBEFUND – Complaint results

Default entries:

Status	System status	Status Short name	Long description of status	Inactive	Addition
GERECHTF (justified)	0	justif.	justified	0	
TEILWGER (partly justified)	0	Partly justif.	Partly justified	0	
UNBESTIMMT (undetermined)	0	indetermined	indetermined	0	[INIT]
UNGERECHTF	0	unjustif.	unjustified	0	[IGN]

Description:

Defines possible results in the complaint header.

Editable/extensible:

Yes / Yes

Subject to area

Yes

Additional parameters:

[INIT] Initial default assignment when creating a complaint

[IGN]

Complaints containing this status are not considered in the supplier evaluation.



The additional parameter „[INIT]“ assigned to this status in the standard is currently not considered functionally.

Status type: REKDETBEFUND – Results of complaint details
Default entries:

Status	System status	Status Short name	Long description of status	Inactive	Addition
GARANTIE	0	Warranty	Warranty	0	
GERECHTF (justified)	0	justif.	justified	0	
KULANZ	0	Fair dealing/goodwill	Fair dealing/goodwill	0	
TEILWGER (partly justified)	0	Partly justif.	Partly justified	0	
UNBESTIMMT (undetermined)	0	indetermined	indetermined	0	[INIT]
UNGERECHTF	0	unjustif.	unjustified	0	[IGN]

Description:

Defines the possible results of complaint details

Editable/extensible:

Yes / Yes

Subject to area

Yes

Additional parameters:

[INIT]

Initial default assignment when creating a complaint details

[IGN]

Complaints containing this status are not considered in the supplier evaluation.



The additional parameter „[INIT]“ assigned to this status in the standard is currently not considered functionally.

Status type: REKDETSTATUS – Status of complaint details
Default entries:

Status	System status	Status Short name	Long description of status	In-active	Addition
ABGESCHL (completed)	0	compl.	Completed	0	[ABG],[BGC:65280],[FGC:0],[NUMWERT:100]
BEARBEIT	0	in process	in process	0	[OFFEN],[BGC:65535],[FGC:0],[NUMWERT:50]
ERFASST	0	collected	collected	0	[INIT],[OFFEN],[BGC:255],[FGC:0],[NUMWERT:0]

Description:

Defines the possible statuses of a complaint detail

Editable/extensible:

Yes / Yes

Subject to area

Yes

Additional parameters:

[INIT]

Initial default assignment when creating a complaint detail

[ABG]

Identifies the statuses for which the complaint detail is considered being "completed".

[ABG]

Identifies the statuses where the complaint detail is considered being "completed".

[BGC:xyz]

Background color

[FGC:xyz]

Foreground color

[NUMWERT:xyz]

Evaluation number for the supplier evaluation.



Only the additional parameter „[NUMWERT:xyz]“is functionally considered in the standard.

Status type: REKDOKZUORD – Assignment of documents for complaints

Default entries:

Status	System status	Status Short name	Long description of status	Inactive	Addition
BEMERKUNG (comment)	0	Comm.	Comment	0	
ERFOLGSKONTR (performance review)	0	Perf. rev.	Performance review	0	
KEINE	0	none	no assignment	0	
VORHERSAGE (prediction)	0	Predict.	Prediction	0	

Description:

Defines the possible assignments of documents when assigning documents in the failure tree analysis. They are also printed with the relevant reports.

Editable/extensible:

Yes / Yes

Subject to area

No

Additional parameters:

none

Status type: REKSTATUS – Complaint status
Default entries:

Status	Sys-tem Sta-tus	Status Short name	Long description of status	Inac-tive	Addition
ABGESCHL (completed)	0	compl.	completed	0	[ABG],[BGC:65280],[FGC:0],[NUMWERT:100]
BEARBEIT	0	in pro-cess	in process	0	[OFFEN],[BGC:65535],[FGC:0],[NUMWERT:50]
ERFASST	0	collec-ted	collected	0	[INIT],[OFFEN],[BGC:255],[FGC:0],[NUMWERT:0]

Description:

Defines the possible statuses of a complaint

Editable/extensible:

Yes / Yes

Subject to area

No

Additional parameters:

[INIT]

Initial default assignment when creating a complaint detail

[ABG]

Identifies the statuses for which the complaint detail is considered being "completed".

[ABG]

Identifies the statuses where the complaint detail is considered being "completed".

[BGC:xyz]

Background color

[FGC:xyz]

Foreground color

[NUMWERT:xyz]

Evaluation number for the supplier evaluation.



Only the additional parameter „[NUMWERT:xyz]“ is functionally considered in the standard.

Status type: VERANTWTYP – Types of responsibilities

Default entries:

Status	System status	Status Short name	Long description of status	Inactive	Addition
ABTEILUNG (department)	1	Department	Department	0	
HERSTELLER (manufacturer)	1	Manufacturer	Manufacturer	0	
INTERN	1	int. company	internal company	0	
CUSTOMER	1	customer	customer	0	
LIEFERANT (supplier)	1	supplier	supplier	0	
PERSON	1	ext. pers.	external person	0	
PZE_PERSON	1	Person	Person	0	
VERTEILER (distributor)	1	Distribution list	Distribution list	0	

Description:

Defines the possible types of responsible parties.



The status „PZE_PERSON“ is synonymous to the HYDRA HR masterdata. This status is only effective when HR masterdata has been set up for a previous version. In order to transfer people from the HYDRA HR masterdata into the CAQ responsible list, the relevant person must be set up in the HR masterdata. It is sufficient to process and save without having to change data.

It is not permitted to create a new status of this type.

Editable/extensible:

No / No

Subject to area

No

Additional parameters:

none

Subject to area

No

Status type: VERTEILVTYP – Types of responsibilities for distribution lists

Default entries:

Status	System status	Status Short name	Long description of status	Inactive	Addition
ABTEILUNG (department)	1	Department	Department	0	
HERSTELLER (manufacturer)	1	Manufacturer	Manufacturer	0	
INTERN	1	int. company	internal company	0	
CUSTOMER	1	customer	customer	0	
LIEFERANT (supplier)	1	supplier	supplier	0	
PERSON	1	ext. pers.	external person	0	
PZE_PERSON	1	Person	Person	0	

Description:

Defines the responsible person in the distribution.



The status „PZE_PERSON“ is synonymous to the HYDRA HR masterdata. This status is only effective when HR masterdata has been set up for a previous version. In order to transfer people from the HYDRA HR masterdata into the CAQ responsible list, the relevant person must be

set up in the HR masterdata. It is sufficient to process and save without having to change data.

It is not permitted to create a new status of this type.

Editable/extensible:

No / No

Subject to area

No

Additional parameters:

none

Status type: ZERTIFDRU – Print options for certificates
Default entries:

Status	System status	Status Short name	Long description of status	Inactive	Addition
AUSW (selection)	1	Selection	Show selection	0	
IMMER	1	always	print always	0	
NIE	1	never	never print	0	

Description:

Defines the options for printing certificates in the configuration of characteristics:



The status selection of the characteristics configuration can be used in Reporting to select/group of inspection characteristics to be printed.

Editable/extensible:

No / No

Subject to area

No

Additional parameters:

none