

1 Configuration of Material Availability Check

Overview

The application "Planned inventory levels" and the detail application "Planned inventory levels" integrated in the HYDRA Shop Floor Scheduling module are used for the presentation of the predicted inventory development over a selectable period. In order to display the inventory development for a specific article/material, several assignments have to be made in advance; they are described in this document.



The application is available for HYDRA 8 from service pack 6.

This document describes how to enable the function "Planned inventory levels" in the HYDRA Shop Floor Scheduling module. The required settings can be made by a trained user or a consultant in the course of implementing the system.

ATP inspection group configuration

Menu	Master data → Production control → ATP inspection groups
Transaction code	atpig
Function authorization	atpig

The ATP (Available To Promise) inspection group can be used to enter various models for calculating the inventory development. You can find more information about the ATP inspection groups application [here](#).

Configuration of ATP inspection group assignment

Menu	Master data → Production control → ATP inspection group assignment
Transaction code	atpiga
Function authorization	atpiga

By assigning an ATP inspection group to an article and/or material you can define how the development is to be calculated for the selected material and/or selected article.



Each material/article can be assigned to exactly one ATP inspection group.

You can find more information about the ATP inspection group assignment application [here](#).

Configurations of operation

An increase in stock of a material/article can be represented via producing operations. The stock of the article from the operation ("article" field) increases by the target quantity (P) entered in the operation.

A decrease in stock of a material/article can be represented via consuming operations. In this case, the materials/articles entered in the component list of the operation are consumed.

The inventory development for production and/or consumption is calculated on the basis of the ATP inspection group assigned to the article.

Configuration of initial inventories

The function "planned inventory levels" considers initial material stocks. These initial stocks are to be entered in the system as batches. For this purpose, the batches can be created either via the interface EIS-MCL or manually in the system.



Only batches which are not reserved for an operation and which have a "free" status and batch class "yield" are included in the initial inventory. For the purpose of calculating the initial inventory, the existing remaining quantity is used.

Calling up the application

Menu	Production control → Production preparation → Planned inventory levels
Transaction code	invlev
Function authorization	invlev

The detail application of the HYDRA Shop Floor Scheduling module can be activated via the "planned inventory levels" tab. If the button is not visible, this may be due to a missing **HLS-MVP** license or the missing function authorization **grapv.invlev**.

You can find more information about the "planned inventory levels" application [here](#).