

1 Implementation of EMS

Usage

Implement the connection to an Engel-Monitoring-System (EMS) if you use it in one production area at least.

Requirements

You have activated the connection to the Engel-Monitoring-System in the Basic settings BDE → Other settings → EMS machine interface.

Approach

Terminal configuration

Use the [terminal configuration](#) to select whether the EMS interfacing must be active at this terminal (if this is terminal type CT 76x or CT 8xx).

Configuration machines/ workplaces

The serial number of the Engel machine may be stored under [configuration of the machines/ workplaces](#). Since any information available in the Engel Monitoring System is based on the serial number provided by the company Engel and since the customer can specify individual machine numbers in HYDRA, this serial number is used for the communication between HYDRA and EMS.

Copying of a machine's status

With an Engel interfacing the machine statuses from 0 to 9799 are reserved for Engel (in line with the Engel alarms that are automatically registered). These statuses are machine-specific and are therefore not automatically copied when the machine status is copied to the extent that the EMS interfacing is activated in the basic settings.

Recommendation for the machine status occupation in HYDRA for EMS machines:

Status	Comment
0 - 9799	Alarms in accordance with the definition from EMS
9801 - 9899	Manual downtime causes according to the definition in EMS. The company Engel will only supply them on request
9900	Production
9901	Setup
9902-97	Only those downtime reasons that are manually defined in HYDRA
9998	Others: Alarm (here: unknown EMS alarm)

Status	Comment
9999	General malfunction