

1 Setting Outputs Depending on Status and Posting Scenario

Usage

Under advanced configurations, it is possible to set the machine's digital outputs to account for when a certain machine status and a defined posting scenario coincide.

The following combination of machine status and posting scenario can be configured:

- A status is active without a production lock
- A status is active with a production lock
- A status is active, but no operation is logged on
- A status is active and at least one operation is logged on
- A status is active, but no person is logged on
- A status is active and at least one person is logged on

If the situation changes (status modification, activate or deactivate P lock, OP posting, personnel posting), the terminal checks the logical configured outputs and sets them as necessary.

In doing so, there is the option to set exactly the same logical output for several statuses within one machine as well as several statuses of different machines.

If a logical output is set for different conditions at the same status, then it will be set if one of the conditions is met (OR link).

Requirements

- This function is only available at the Windows CTWIN or AIP terminals.
- For this purpose, the terminal must be configured in operation mode "MDE".
- The machine must be permanently assigned to the "MDE terminal".
- Output signals that are used for this function may not be configured anywhere else at the same time (e.g. machine lock). This must be assured during configuration. This is not checked automatically.
- The terminal must be restarted any time a change is made to the configuration of the logical outputs.
- The outputs configured here may not be used simultaneously with the "inputs/ outputs" configuration that exists in the [resource configurations](#).

Procedure

The configurations required for this are defined in the so-called "[object-related configuration](#)".

Object type	fix "MSTAT" (Machine STATus)
ID1	Machine number for a numeric machine number, always add leading zeros to make it eight digits
ID2	Machine status number
ID3	(leave empty)
ID4	(leave empty)
Parameters	The following parameters are supported: MST_NO_PLOCK Output/ signal for "Status active without production lock" MST_PLOCK Output/ signal for "Status active with production lock" MST_NO_ANR Output/ signal for "A status is active, but no operation is logged on" MST_WITH_ANR Output/ signal for "A status is active and (at least) one operation is logged on" MST_NO_PNR Output/ signal for "A status is active, but no person is logged on" MST_WITH_PNR Output/ signal for "A status is active and (at least) one person is logged on"
Parameter value	The parameter value is always the number of the logical output that is to be set.
Active	Fix "J"

Example

Output 1 is to be set at machine 100 if either setup (status 2) or dismantling (status 9) is active with a production lock.

Output 2 is to be set at machine 100 if production (status 1) is active although no operation is logged on.

Object type	ID 1	ID 2	ID 3	ID 4	Parameters	Parameter value	Active
MSTAT	100	2			MST_PLOCK	1	Y
MSTAT	100	9			MST_PLOCK	1	Y
MSTAT	100	1			MST_NO_ANR	2	Y