

1 Protecting fields of planned operations

Purpose

Use the configuration described in this document to prevent specific data fields of a (planned) operation from being overwritten when the operation is transferred once more via the ERP interface.



This function only affects ANR.MODIFY and/or ANR.UPDATE and operations.

Operations are only updated if the status of the order/operation generally allows it. The configuration described below does not apply if the status (see [order status assignment](#)) cannot be changed in general.

Requirements

You require the relevant function authorization to access [INI configuration](#) and [INI data configuration](#).

Procedure from service pack 12 onwards (b_anr.dll version 8.1.1.354)

Create a new entry in the [INI configuration](#):

Field name	Value
Name	BAPINOUPDATE
Description	Enter a description.

For this entry, create an entry including the following values in [INI data configuration](#):

Field name	Value
Section	ANR
Key	List the fields (HYDRA BAPI acronyms) that are not overwritten.
Value	The value includes a condition. Enter the condition, for example, as follows: ANR.ATYP=AG
Active	Yes

Use "@" to separate the single fields or conditions in the fields "key" or "value". The fields and conditions are processed one after the other.

You can define the values for "key" and "value" separately. The entries are processed one after the other. The conditions entered in the "value" field correspond to an AND operation.



As of service pack 12 only use the "@" character as separator if you create new entries or change existing ones. You do not have to change existing configurations (prior to service pack 12). In this case, the "|" character is still supported.



You can enter multiple entries for the function BAPINOUPDATE in the [INI data configuration](#), as you define the values for "key" and "value" separately.

Procedure up to service pack 11

Create a new entry in the [INI configuration](#):

Field name	Value
Name	BAPINOUPDATE
Description	Enter a description.

For this entry, create an entry including the following values in [INI data configuration](#):

Field name	Value
Section	ANR
Key	List the fields (HYDRA BAPI acronyms) that are not overwritten.
Value	Enter the condition that has to be met to make sure fields will not be overwritten. Enter BAPI acronyms including value.
Active	Yes

Use "|" to separate the single fields or conditions in the fields "key" or "value". The fields and conditions are processed one after the other.



Up to service pack 11 only use the "|" character as separator.

You can define the values for "key" and "value" separately. The entries are processed one after the other. The conditions entered in the "value" field correspond to an AND operation.



You can enter multiple entries for the function BAPINOUPDATE in the [INI data configuration](#), as you define the values for "key" and "value" separately.

If you cannot enter the pipe character ("|") using the GUI, you can still enter the values via the database:

- To do so, create a new entry as described above via the [INI configuration](#). Now use the following SQL statement to determine the internal DB counter for the header entry in the INI configuration:

```
select * from hyd_ini
```

- Determine the value of the "VERWEIS" column for the new entry.
- Create the required entries. Use the following SQL statement to assign the database table fields and application fields as described below:

```
insert into hyd_ini_data (ini_verweis, section, ident, value, bemerkung, aktiv)
values (<reference from previous SQL>, 'ANR', '<fields to be protected>', '<values>',
'<comment>', 'J')
```

Use the "|" (pipe) character to separate the acronyms of the fields you want to protect and the acronyms of the values.



Use a pipe character "|" to complete the list of the fields you want to protect and the list of values.

Database field	Values/content
INI_VERWEIS	The value of the VERWEIS column identified from the HYD_INI table via SQL.
SECTION	Section
IDENT	Key
VALUE	Value
BEMERKUNG (comment)	Comment
AKTIV	Active

List of frequently used acronyms

The following table lists the most frequently used acronyms and their meaning. Please contact MPDV Support if the list does not include the acronym you require.

Acronym	Meaning
ANR.MGRP	Machine group
ANR.MNR	Workplace/ machine
ANR.OPT:PLAN	Planning indicator: M Planned for workplace/machine G Planned for machine group
ANR.DATB	Start date planned (via HLS)
ANR.ZEIB	Start time planned (via HLS)
ANR.DATE	End date planned (via HLS)
ANR.ZEIE	End time planned (via HLS)

Example: protect the planned workplace

If the operation is planned on a workstation, you have to prevent the ERP interface from cancelling this planning. To do so, enter the below-mentioned data:

Field name	Value
Section	ANR
Key	ANR.MGRP@ANR.MNR@ANR.OPT:PLAN@
Value	ANR.ATYP=AG@ANR.OPT:PLAN=M@
Active	Yes

SLQ statement:

```
insert into hyd_ini_data (ini_verweis, section, ident, value, bemerkung,
aktiv) values (<reference from previous SQL>, 'ANR',
'ANR.MGRP@ANR.MNR@ANR.OPT:PLAN@', 'ANR.ATYP=AG@ANR.OPT:PLAN=M@', '<comment>',
'J')
```

Example: protect the start/end dates of a planned OP

If the operation is planned on a workstation and, as a result, its start time is specified, you have to prevent the ERP interface from cancelling this planning. To do so, enter the below-mentioned data:

Field name	Value
Section	ANR
Key	ANR.DATB@ANR.ZEIB@ANR.DATE@ANR.ZEIE@
Value	ANR.ATYP=AG@ANR.OPT:PLAN=M@
Active	Yes

SLQ statement:

```
insert into hyd_ini_data (ini_verweis, section, ident, value, bemerkung,
aktiv) values (<reference from previous SQL>, 'ANR',
'ANR.DATB@ANR.ZEIB@ANR.DATE@ANR.ZEIE@', 'ANR.ATYP=AG@ANR.OPT:PLAN=M@',
'<comment>', 'J')
```