

1 Siplace Batch Data Transfer and Synchronization of Quantities

Overview

Purpose

This application carries out automatic batch data transfer from HYDRA to the Siplace line. It also synchronizes batch quantities between the Siplace line and HYDRA.

Integration

HYDRA batch data are an essential part in order to use the Siplace connector and generating input and output batches (traceability data) to transfer from the connector to HYDRA.

Features

Batch data transfer from HYDRA to Siplace

The Siplace connector transfers periodically all free batches of a defined material type located in a defined material buffer in HYDRA to the Siplace line. If a batch number is existent in the Siplace line, then there is not transfer/update of that batch data.

The following data of a batch are transferred to Siplace:

- MES batch number
- Material
- Quantity
- Remaining quantity
- Expiry date

Please configure the material type and material buffer in config.xml.

```
<ComponentConfiguration Name="BatchListGetter">
```

```
  <Parameter Name="MaterialType" Value="Materialtype" />
```

```
  <Parameter Name="MaterialBuffer" Value="Material buffer" />
```

```
</ComponentConfiguration>
```

You can define several material buffers. Please separate the material buffer in this case in the configuration file with a comma.

The cycle transfer is also configured in the Sidplace connector file config.xml. (Unit seconds)

```
<ComponentConfiguration Name="TimedTrigger">
```

```
<Parameter Name="[GetBatchList]" Value="3600"/>
```

```
</ComponentConfiguration>
```

Synchronizing quantities between Siplace and HYDRA

Synchronizing quantities select batches in HYDRA using the same process as in the batch data transfer (batch status "Free", material type, material buffer) and synchronizes the remaining quantities as follows:

If the remaining quantity of a batch in Siplace is smaller than the one in HYDRA, then the quantity is updated in HYDRA according to the information from the Siplace line.

The cycle transfer is configured in the Sidplace connector file config.xml. (Unit seconds)

```
<ComponentConfiguration Name="TimedTrigger">
```

```
<Parameter Name="[UpdateBatchConsumption]" Value="7200"/>
```

```
</ComponentConfiguration>
```