

1 DNC Configuration

Basic Configuration

In the case of subsequent installation of DNC on an existing HYDRA 8 system, please follow the steps below:

1. Save the existing dialog configuration:
 - a. UNIX systems (to be performed on server prompt in HYDRA directory): *hydlgcfg.out DLGCFG.TYP=% DLGCFG.DLGUSR=% DLGCFG.DLG=% DATEI=dialog.dlg*
 - b. Windows systems (to be performed in a DOS window in HYDRA directory): *hydlgcfg.exe DLGCFG.TYP=% DLGCFG.DLGUSR=% DLGCFG.DLG=% DATEI=dialog.dlg*
2. Now load the new dialog configurations with the following command:
 - a. UNIX systems:
hymw.out -u9999 -b db_sql/aip_dnc.dlg
 - b. Windows systems:
hymw.exe -u9999 -b db_sql/aip_dnc.dlg

This means that the DNC dialog is read **as default** (with type "DEF" and dialog user "999") and/or the existing one is updated.

3. Copy the DNC dialog from the default (type "DEF" with dialog user "999") to type "DEF" and dialog user "0" on MOC using the System settings→Terminals→Dynamic dialogs application (transaction code ddconf). For this purpose, you have to change to HYDRA Professional Mode.
4. Activate the new dynamic dialogs:
 - a. UNIX systems:
hydialog.scr AIPTNR 0
 - b. Windows systems:
sh.exe hydialog.scr AIPTNR 0

Please note: This command will activate the default dialogs. If the system uses terminal-specific dialogs, these must be adapted by an MPDV consultant.

Configuration at AIP

The button for calling up the DNC is already included in the standard configuration. It is activated if the DNC-BP license is available.