

1 Splitting Batches at AIP

Usage

You use the function to split up a batch into several batches at AIP. Subject to the batch type, batches may be split in the following ways:

- Splitting off quantities into individual batches
- Splitting off individual batches from existing merged batches into a new merged batch

Dialog configuration

Dialog configuration (CNR.SPLIT)

Define the AIP function keys in the file *ctaipbut.ini*:

```
[ANR-LN-Page3]
...
3=BATCH_INFO,L,Los splitten,Los_splitten.png
```

The sections [BATCH_S_SPLIT] and [BATCH_SPLIT] are required in the layout configuration of *ctaisplay.ini*:

```
[BATCH_S_SPLIT]
GRID_FONT=Arial
GRID_FONTSIZE=9
GRID_COLOR=clBlack
GRID_BACKGROUND=clWhite

GRID_CELLPAINT=ON
EXAMINE_CELLBKCOLOR=SELECT,SELECT,X-clLime

SELECT=C1,50,Z,*
DLL=C20,150,Z,batch
ATK=C20,150,L,article
SGR:REST=N12.0,100,R,quantity
```

```
EINH=C3,60,Z,unit
```

```
;CKL=C1,150,Z,class
```

```
[BATCH_SPLIT]
```

```
GRID_FONT=Arial
```

```
GRID_FONTSIZE=9
```

```
GRID_COLOR=clBlack
```

```
GRID_BACKGROUND=clWhite
```

```
GRID_CELLPAINT=ON
```

```
EXAMINE_CELLBKCOLOR=CKL,CKL,G-clLime|A-clRed|N-clBlue|O-clYellow
```

```
EGR=N12.3,250,R,quantity
```

```
CKL=C1,150,Z,class
```

```
EGG=C4,100,Z,reason
```

System configuration

Further system configurations are not required to split batches.