

# 1 Configuration of Discrete Consumption Input

|  |   |  |
|--|---|--|
|  | → |  |
|--|---|--|

## Summary

Material consumption can be entered at the AIP shop floor terminal while an operation is being interrupted, while an operation is being logged off or when entering a partial confirmation/upload

## System configuration

The relevant utilization material must be assigned to the operation in order to discretely record consumption. The meaning of the following fields must be observed in particular (logical consideration). The material components can be assigned in HYDRA manually ([Order management: edit components](#)) or from the upper level system

### Material number

The material number uniquely identifies a material. In the component list, a material is only unique in association with a BOM item.

### BOM item

The BOM item combined with the material number forms a unique key for a material component at an operation.

### Material designation

The material designation is used to describe a material more exactly. It functions as commentary and is displayed in the input dialog.

### Material category (type)

The material category controls, among other things, the way a material is technically processed in the HYDRA system. Relating to the material consumption input (not batch-related), the following value is important:

"M" Material component, should be entered in terms of consumption

### Material type

The material type is another parameter used for processing control in HYDRA. The material type is used to control whether goods movement created from the material consumption should be uploaded to the ERP system or not. Unless defined otherwise assign the material type SYSTEM here.

To assure that a goods issue is uploaded via the interface, the option "Transfer to interface" must be set at the material type that the utilization material is based on.

When launching HYDRA for the first time or during discrete consumption input, it will need to be coordinated whether or for which material components consumption should be uploaded to the ERP system. If the MPL module is not used, this configuration is to be made during the HYDRA customizing process.

### Consumption type

Set the consumption type to "D" (discrete consumption input) for material components that this function is used for to collect material consumption.



It is possible to transfer the consumption type using the relevant component segment of the ERP interface (EIS-ERP). When using the HYINFO interface as a part of the PP-PDC interface, the consumption type is made available by customizing the system accordingly.

The interface necessary to upload material consumption is not a part of this function.

### Input quantity

The input quantity is a component quantity needed to manufacture one unit (one piece, for example) of the output material (article/item) being produced. It is used to calculate the theoretical material consumption based on the produced quantity.

### Unit

Quantity unit of the material component in which material consumption is recorded.

## Dialog configuration

In addition to making the necessary programs available, please also consider the following:

- Activate the dynamic dialog A\_VERB, accounting for existing terminal groups in some cases
- Integrate the button used to call up the consumption input dialog in the relevant posting dialogs. The following configurations are possible here, whereas a) can be seen as an alternative to b) and c):
  - a. Integration into the workflow step WF\_AA\_QUA.  
The button is found in the standard dialogs
    - Interrupt OP (A\_UN),
    - Log off OP (A\_AB), and
    - Partial confirmation/upload (A\_TR)
    - in each workflow step in which quantities are entered manually.
  - b. Integration into the workflow dialog WF\_AUN\_CHK  
The button is available in the standard dialog Interrupt OP (A\_UN) in the confirmation workflow step.
  - c. Integration into the workflow dialog WF\_AAB\_CHK  
The button is available in the standard dialog Log off OP (A\_AB) in the confirmation workflow step.
- Integrating or checking the grid configuration for the dialog A\_VERB (ctaipay.ini)

- Optional: Uploading the material consumption as goods movement
  - Determining which material type is transferred to the material component from the ERP system (typically SYSTEM)
  - Setting the flag "Transfer to interface" at the material type. Options:
    - Directly via the master data configuration (only possible, if MPL/ TRT is active)
    - Per SQL to the HYDRA server (hysql -r -):  
update hz\_typen set we\_ext\_kz = 'J' where hz\_typ = 'SYSTEM';
    - Per SQL via the SQL tester in MOC: update hz\_typen set we\_ext\_kz = 'J'  
where hz\_typ = 'SYSTEM'
    - Per BAPI to the HYDRA server (Observe system!):  
hymwb -u9999 -  
c"DLG=MATTYP.UPDATE|MATTYP.MATTYP=SYSTEM|MATTYP.WEEXT:GEN  
=J|DAT=today|ZEI=now|"
  - Check per SQL: select hz\_typ, we\_ext\_kz from hz\_typen
  - Activate the material upload interface (see relevant documentation).