

1 Line Andon Board: Configuration

Editing Machines/Workplaces and Lines

Configure a production line's machines/workplaces/workstations and the production line itself in the [Configuration of Workplaces and Resources](#):

Category	Workplace category
Machine / workplace / workstation	"N" or "P"
Line	"L"

Line assignment

Use the [Line assignment](#) to assign the corresponding machines/workplaces/workstations to the production line. Identify the reference aggregate of the production line.

Create a report group

Create at least one report group in the [Groups](#). If required, you can create the report group for a specific user. Create a global report group if you want all users to make use of this report group.

Assign production line(s) to the report group

Assign production line(s) to the report group. The *position* field does not affect display in the Line Andon Board.

Configuration of OEE calculation

This [document](#) describes how to configure the OEE calculation.

Data maintenance for (continuous monitoring) orders/OPs

Log on an operation to the production line in order for the Line Andon Board to show a target cycle. Use a continuous monitoring order/operation for this purpose. Create this order with at least one operation and the following data:

Field	Value
Target cycle	Target cycle of the production line

Machine	Workstation of the production line
Planned for	Machine