

1 Configuration of Transport Orders

Overview

Purpose

In the Material and Production Logistics, you can use so-called transport orders to integrate the transport of batches or resources.

If you want to use transport orders, you must first make the following configurations for the different objects.

Configuration of the workplace/machine

In the workplace configuration (Master data → Workplaces/machines → Workplace configuration), you must configure if the system must automatically generate transport orders for a specific workplace.

The configuration options are as follows:

- Generate transport order for [output material](#)
- Generate transport order for [input material](#)



If you make these setting for the material type, the settings of the workplace/machine are overwritten.

Configuration of the material type

In the master data configuration (Master data → Material → Material type), you must make the following settings for the [Material type](#) if you want to automatically generate transport orders for a material type.

The configuration options are as follows:

- Generate transport order for [output material](#)
- Generate transport order for [input material](#)

Configuration of the order type

A transport order is integrated in HYDRA using a specific order type (e.g. TRNS).

Default setting of the order type transport orders

Fields in Order types	Transport orders
Order type	TRNS

Fields in Order types	Transport orders
Order type for composition	M
Category	FA
Upload	YNN N NNNN NNN NY
Plan	F
Planned dates	O
Symbol	fa.bmp
Sequencing list	Y
Recordable	Y
May OPs of the order be finished	Y
Combined order logon	T
Log on again when shift starts	Y
Log person off when shift ends	Y
Serial numbers required	N
Assignment of serial numbers	N
Change after upload	N
Check status preceding OP	N
Check min. send-ahead qty. of preceding OP when order is logged on	N
Quantity check of send-ahead quantity	N
Plausibility check if PERS IN	N
Priority control	GN
Check if shop floor papers are printed	N
Consideration of production variants	NE
Active	Y
Designation	Transport order
Order is not logged off automatically	N
Milestone processing only for the last OP	N
Only OPs of the same order type can be logged	Y

Fields in Order types	Transport orders
on simultaneously	
Generate inspection order number	N

Configuration of the order/operation status

[Order status assignment](#) for the order type "TRNS" (identical to the order type = 0 production orders):

- Prepared (I) (initial status)
- Reserved (V)
- Transport (L)
- Finished (E)

Configuration of the work plan

If you want to use the functions of the transport management, a work plan must exist in the system and this work plan must be activated using the application "Work plan determination".

The work plan must be configured as follows:

- Order header
 - Order type: specifically configured order type for the transport management (e.g. TRNS)
 - Article
 - In case of transport of a batch: article number
 - In case of transport without batch: empty
- Operation
 - Exactly 1 operation
 - Article
 - In case of transport of a batch: article number
 - In case of transport without batch: empty
 - Planned for: Group
 - Recordable: yes
 - Batch manag. requirement: no
 - Parallel logon possible: no

Activate the work plan using the application "Work plan determination". Make the following settings:

- Work plan: store the previously defined work plan
- Active: yes
- Order type: specifically configured order type for the transport management (e.g. TRNS)
- Article: enter the article of the work plan in field "Article".

Configuration for AIP functions (general)



You must have run the database patch ***dbp_mpl_transportation.hsc*** for all functions listed in the following.

You must make the following configuration. It does not matter if you use AIP or AIP 8.2.

To display the columns in the grid, the following entries in the file ctaiplay.ini are required:

```

;*** Section for transport-specific ANR - fields
;*** in TGRP X for terminals with transport functions
[ MPL-TRA - transport orders ]
GRID_LIST_TYP=ANR
; Additional fields in the order list
AGR_TRANR_ART= ; ..
AGR_TRANR_CNR= ; ..
AGR_TRANR_RES= ; ..
AGR_TRANR_RESTYP= ; ..
AGR_TRANR_SMP= ; ..
AGR_TRANR_TMP= ; ..
AGR_TRIGGER_ANR= ; ..

;*****
[ TRANRLIST ]
GRID_FONT=Arial ; font
GRID_FONTSIZE=9
GRID_COLOR=clBlack ; font color
GRID_BACKGROUND=clWhite ; background color

GRID_CELLPAINT=ON
EXAMINE_CELLBKCOLOR=AST,AST,I-clCyan|V-clGray|U-clGray|L-clLime

EXAMINE_SCANEXPR1=AST=I
EXAMINE_SCANCOLOR1=clBlue
EXAMINE_SCANEXPR2=AST=L
EXAMINE_SCANCOLOR2=clGreen
EXAMINE_SCANEXPR3=AST=E
EXAMINE_SCANCOLOR3=clRed

;MNR=C8,100,L,Maschine
AST=C10,60,Z,Status
ANR=C10,150,L,AG
ATK=C25,125,L,Artikel

SGR:GUTP=N10.3,80,R,Sollmenge
SGE:P=C3,50,Z,Einheit

AGR_TRANR_CNR=C10,100,L,Los
AGR_TRANR_SMP=C10,80,L,Quellpuffer
AGR_TRANR_TMP=C10,80,L,Zielpuffer
AGR_TRANR_RES=C10,80,L,Ressource
;AGR_TRANR_RESTYP=C10,50,Z,Res.typ

AGR_TRANR_ART=C10,40,Z,Art

```

Configuration for the AIP

Configuration of the dialog "[Generate transport order](#)"

AIP configuration

If you want to use the function [Generate transport order \(MBL\)](#), you must configure the entry TRANR_GEN in the button configuration (ctaipbut.ini/<tgrp>).

Exactly store the following entry:

```
6=U_TRANR_GEN,R,Transportauftrag anlegen
```

Display configuration of the "[Sequencing list](#)"

If you want to use this function, you must configure the respective entry in the ctaipbut.ini button configuration.

If the button configuration is customized, e.g. using "ctaipbut.ini", the function can be configured for the required button by manually adding "TRANRLIST".

Example:

```
[ANR-ALL-Page2]
""
2=TRANRLIST,R,Transportmanagement
```

Configuration of the dialog ["Start transport order"](#)

If you want to use the function [Start transport order \(MBL\)](#), you must configure the respective entry in the ctaipbut.ini button configuration.

The dynamic dialog TRANR_AN must be available in the terminal.

Configuration of the dialog ["Finish transport order"](#)

If you want to use the function [Finish transport order \(MBL\)](#), you must configure the respective entry in the ctaipbut.ini button configuration.

The dynamic dialog TRANR_AB must be available in the terminal.

Configuration for the AIP 8.2

You must explicitly configure the function calls for the dialogs TRANR_GEN (Generate transport order) and TRANRLIST (List of transport orders) in the AIP 8.2. If required, the configuration of the function calls can be customized.

Configuration of the dialog ["Generate transport order"](#)

Add the following section, for example in the file "I_mnr.xml".

From file "I_mnr.xml"

```
[...]
<!--Buttons-->
<ScrollBar>
[...]
<!--Create transport order-->
<element class="TGUIButton">
  <Align>alTop</Align>
  <AlignWithMargins>true</AlignWithMargins>
  <BorderWidth>5</BorderWidth>
  <Height>50</Height>
  <Margins>
```

```
<Top>0</Top>
<Left>0</Left>
<Right>10</Right>
<Bottom>7</Bottom>
</Margins>
<Alignment>taLeftJustify</Alignment>
<Color Define="COLOR_MENU">$E0E0E0</Color>
<Caption Function="Translate" LanguageKey="lkCreateTransportOrder">Transportauftrag generieren</Caption>
  <OnClick Identifier="TRANR_GEN" Parameterprozessor="TFocusedDataRows">Notify</OnClick>
</element>
</ScrollBar>
[...]
```

The dynamic dialog TRANR_GEN must be available in the terminal.

Display configuration of the "[List of transport orders](#)"

Add the following section, for example in the file "l_mnr.xml".

From file "l_mnr.xml"

```
[...]
<!--Buttons-->
<ScrollBar>
[...]
```

```
<!--Create transport order-->
<element class="TGUIButton">
  <Align>alTop</Align>
  <AlignWithMargins>true</AlignWithMargins>
  <BorderWidth>5</BorderWidth>
  <Height>50</Height>
  <Margins>
    <Top>0</Top>
    <Left>0</Left>
    <Right>10</Right>
    <Bottom>7</Bottom>
  </Margins>
  <Alignment>taLeftJustify</Alignment>
  <Color Define="COLOR_MENU">$E0E0E0</Color>
  <Caption Function="Translate" LanguageKey="lkTransportManagement">Transportmanagement</Caption>
    <OnClick Identifier="TRANRLIST" Parameterprozessor="TFocusedDataRows">Notify</OnClick>
  </element>
</ScrollBar>
[...]
```

In this function, you can make a [reservation](#) for transport orders.

The dynamic dialog TRANRLIST must be available in the terminal.

Configuration of the dialog "[Start transport order](#)"

To use the function [Start transport order \(MBL\)](#), use the dialog TRANRLIST.

The dynamic dialog TRANR_AN must be available in the terminal.

Configuration of the dialog "[Finish transport order](#)"

To use the function [Finish transport order \(MBL\)](#), use the dialog TRANRLIST.

The dynamic dialog TRANR_AB must be available in the terminal.