

Manual

Advanced Shop Floor Data Posting Functions BDE-EBF 8.2

Version 1.1.23049

Last changed on: 01.09.2020

Copyright

©Copyright 2020 All rights reserved.

SAP® and R/3® are registered trademarks of SAP AG.

WINDOWS® is a registered trademark of Microsoft Corporation.

MPDV® and HYDRA® are registered trademarks of MPDV Mikrolab GmbH.

ORACLE® is a registered trademark of ORACLE Corporation, California, USA.

Copying and distribution of this documentation or any part thereof, for any purpose or in any form, is prohibited without prior written permission from MPDV Mikrolab GmbH.

The information contained in this documentation is subject to change without prior notice.

Contents

1	Overview: Advanced Shop Floor Data Posting Functions.....	4
2	Reasons	6
3	Reason Texts	9

1 Overview: Advanced Shop Floor Data Posting Functions

Purpose

The function package "advanced shop floor data posting functions" enhances the BDE module with additional collection methods and options.

Implementation notes

You use the advanced shop floor data posting functions if

- You would also like to enter the reasons associated with the scrap quantities recorded in order to be able to evaluate them and, if necessary, assign a monetary value to them.
- You would like to have a system-supported recording of free text information in production that is available for later shifts and, if required, for evaluations.
- The materials to be produced are stocked in several different quantity units and you would like to manage these quantity units at the operation level, record them during production, and you need the system to convert the various quantity units accordingly.
- You would like to have additional validation checks during posting of operations in order to increase the quality of the data collected and/or to increase or ensure process reliability.

Integration

The scrap reasons recorded:

- are used as a basis in the evaluations of the function package "controlling shop floor data / order data"
- can be uploaded to an upper-level ERP system via interfaces along with the entered quantities

The comments entered are available in the order information of the function package "monitoring shop floor data / order data".

Features

- Order-related data entry and posting functions
 - Entry of scrap reasons
 - Entry of OP-related comments (free texts) added to any particularities documented during the course of the order
- Automatic conversion of the quantities entered into other units and posting to special quantity accounts (requires that the conversion factors have been defined for the operation).
- Order-related entry and posting functions:

- Extensive, configurable validation checks for OP postings (e.g. checking whether quantities are under or over delivered)
- Entry of reasons for deviation in the event of over or underdelivery

2 Reasons

Summary

Menu	Master data → Workplaces / Machines → Reasons
Transaction code	reas
Function authorization	mdreas

Usage

Use this configuration to create or to change the reasons available in the system. Reasons may either be created for the entire system or referred to a workplace

Integration

The reasons that are saved to the system will be available for collection on the terminal as well as in different applications. They are used to classify quantities of materials or modifications.



In order for the settings or the changes made to be able to be interpreted by the terminal shop floor program, the terminal, which the workplace/machine is assigned to, has to be restarted. All terminals should be restarted, provided that new reasons have been created or reasons affecting the entire system have been changed.

Requirements

You have defined [reason texts](#) in the system.

Selection criteria

The following selection criteria are available in the application:

Type

Reason type, e.g. scrap

Workplace

Workplace selection.



Reasons that are configured for the "workplace" SYSTEM, will always be displayed even if a workplace will explicitly be restricted.

Reason

Unique reason number

Designation

Designation of the reason. Wildcards can be used.

Superior reason

Selection of a superior reason. All reasons will be selected that have the selected reason as (direct) superior reason.

Field descriptions**Workplace**

Assignment of a reason text to a workplace. If "SYSTEM" is entered, this will apply as system-wide assignment.



System-wide reasons will always apply in addition to the workplace-specific reasons and will therefore also be displayed in the terminal's selection list.

Type

Classification and/or grouping of reasons

Possible values:

A	Scrap reason
N	Rework reason
P	Open quantity reason (before: problematic quantity)
G	Yield reason: will be interpreted as deviation reason
L	Reasons for batch logs (relevant in connection with MPL)
R	Reduce (partitioning) reason (relevant in connection with WRM)
E	Increase (partitioning) reason (relevant in connection with WRM)

Reason

Identification number of the reason.



As system-wide reasons always apply in addition to reasons relating to workplaces, their numbers have to be unique, i.e. a scrap reason with the number 99 for the SYSTEM workplace must not be defined at the same time as workplace-related scrap reason assigned to the number 99.

Reason text no.

Identification number of the [reason text](#)

Designation

Related reason text from the reason text configuration.

Ext. reference

For each assignment exists an alphanumeric representation that can be uploaded back to the interface, for example

Scrap material

Is used in connection with HYDRA-MPL

Superior reason

The reference to a superior reason is reserved for further extensions/modifications; at present it has no function and should consequently not be completed.

“Copy“ detail application

The "copy" button can be used to copy reasons defined in relation to a workplace from one workstation to the next. Reasons of the "workplace" SYSTEM cannot be copied.

The below-mentioned options are supported while copying:

- **Copy currently selected reason**

This option can be used to copy the currently selected reason. For this purpose, enter the below pieces of information in the fields below "To":

 - **Workplace:** target workplace for which the reason is to be copied
 - **Type:** Choose the reason type under which the reason is to be created for the target workplace. The field is assigned by default to the type of the currently selected reason.
 - **Reason:** Enter the reason number under which the reason is to be created for the target workplace. The field is assigned by default to the type of the currently selected reason.
- **Copy all reasons**

This option allows copying of all reasons defined for a workplace to another workplace. However, a prerequisite for this is that reasons have not yet been configured for the target workplace. To do so, enter the target workplace for which the reasons are to be copied in the "workplace" field. Please note that all workplace reasons are always copied, irrespective of the type of the reason.
- **Copy missing reasons**

In contrast to the previous option, this function allows for reasons to be copied to another workplaces, even if reasons are already assigned to this workplace. To do so, enter the target workplace for which the reasons are to be copied in the "workplace" field. Please note that all workplace reasons will always be copied, irrespective of the type of the reason.

3 Reason Texts

Summary

	Doku-Eigenschaft „Version“ hinzugefügt	
Menu	Master data → Workplaces / Machines → Reason texts	
Transaction code	reat	
Function authorization	mdreat	

Usage

Use this function to create or to change the reason texts available in the system.

Integration

The basic texts saved to the system will be shown upon the definition of the [Reasons](#) as reference.

Field descriptions

Reason texts

Unique number to identify the text

Designation

Designation of the reason text