

Manual

Download/Upload Service DNC-DUN 8.1

Version 1.0.23049

Last changed on: 01.09.2020

Copyright

©Copyright 2020 All rights reserved.

SAP® and R/3® are registered trademarks of SAP AG.

WINDOWS® is a registered trademark of Microsoft Corporation.

MPDV® and HYDRA® are registered trademarks of MPDV Mikrolab GmbH.

ORACLE® is a registered trademark of ORACLE Corporation, California, USA.

Copying and distribution of this documentation or any part thereof, for any purpose or in any form, is prohibited without prior written permission from MPDV Mikrolab GmbH.

The information contained in this documentation is subject to change without prior notice.

Contents

1	Download/Upload Service	4
---	-------------------------------	---

1 Download/Upload Service

Purpose

The DNC administration treats NC programs or setting data records as resources in the HYDRA system. This package forms the basis for uploads and downloads. A terminal client is required to control the function.

You use the function package when:

- You wish to transmit DNC records from HYDRA to the machine (download), or to transmit new or optimized programs and setting data records from the machine to HYDRA (upload).

Integration

The DNC-PVW basic module is a precondition for the use of the functions. A terminal client is required to operate and control the functions. There are no further operating functions on the MOC client. The changing of status is made possible by the DNC-MON package on the MOC.

The HYDRA process communication controller (SCS-PCB) and the corresponding logging modules contained in the MPDV compatibility list must be licensed for communication with the machines and for transmission of the NC data records.

Features

Application service for downloading NC files to machine controllers and for uploading optimized NC programs from the machines to the HYDRA MES:

- Functions for editing the existing programs and assignment of status information (e.g. barring and enabling NC programs).
- Assignment of the NC record to be transmitted by entering in the FHM list of the operation
- Assignment of the NC record to be transmitted by manual input of the DNC number
- Transfer of the NC data records to the BDE/DNC terminals
- Plausibility check with automatic restriction by assignment of the NC data records to the machines via the defined attributes
- Transfer of the NC data records from the BDE/DNC terminal to the machine controller (download or loading function)
- Transfer of NC data records which, e.g. for optimization reasons, were edited in the machine controller, incl. storage of the NC files in the BDE/ DNC terminal
- Recording of attributes for the transferred NC data record at the BDE/DNC terminal.
- Transfer of the NC data records from the BDE/DNC terminals to the HYDRA database
- Saving of the edited NC programs to the HYDRA database

