

Manual

HYDRA Personnel Data Manager SCS-HRM 8.1

Version 1.0.23049

Last changed on: 02.09.2020

Copyright

©Copyright 2012 All rights reserved.

SAP® and R/3® are registered trademarks of SAP AG.

WINDOWS® is a registered trademark of Microsoft Corporation.

MPDV® and HYDRA® are registered trademarks of MPDV Mikrolab GmbH.

ORACLE® is a registered trademark of ORACLE Corporation, California, USA.

Copying and distribution of this documentation or any part thereof, for any purpose or in any form, is prohibited without prior written permission from MPDV Mikrolab GmbH.

The information contained in this documentation is subject to change without prior notice.

Contents

1	HYDRA Personnel Data Manager - Summary	4
2	HYDRA Production Data Manager HR – PZE/PZW/ZKS/PEP	6
2.1	Optional data transfer from SAP	6
2.2	Sending HR data to HYDRA.....	6
2.2.1	Transfer of PZE and ZKS time events	6
2.2.2	Transfer of access statuses and access logs.....	10
2.3	Reading HR data from HYDRA	11
2.3.1	Requesting PZE access authorizations	11
2.3.2	Requesting the ZKS access authorizations	12
2.3.3	Requesting the list of access time models	14
2.3.4	Requesting the public holidays	16
2.3.5	Requesting opening hours.....	16
2.3.6	Requesting the terminal list	17
2.3.7	Requesting the access list	22
2.4	Online requests	25
2.4.1	Online check of PZE authorizations.....	25
2.4.2	Online check of ZKS authorizations.....	26
2.4.3	Online request of a person's account balances.....	26
2.5	Pre-processed data from third-party systems	27
2.5.1	Import of day-related (clocking) data	27
2.6	Transferring configurations from third-party systems	33
2.6.1	Transfer of the planned working time.....	33
2.6.2	Absence planning	39
2.6.3	Creating account limits in HYDRA	44
2.6.4	Assigning authorizations for PZE and ZKS terminals.....	46
2.7	Data collection for the incentive wage	47
2.7.1	List of bonus reasons (ZUSCHLGR.LIST)	47
2.7.2	Recording of bonuses on the terminal (P_ZUSCHL).....	48

1 HYDRA Personnel Data Manager - Summary

Possible fields of application

The HYDRA Personnel Data Manager is a data interface by means of which personnel data of all kinds can be exchanged with the HYDRA system. This may be, for example, clocking records, absences and access protocols provided by external time & attendance systems or access control systems or any other systems.

The data is transferred to the HYDRA database and processed within the installed HYDRA applications.

Prerequisite: the external systems can operate the HYDRA Personnel Data Manager in HYDRA standard format.

The HYDRA Personnel Data Manager, for example, allows for the input data of the time & attendance/incentive wages/personnel scheduling and access control modules to be transferred directly to the HYDRA system or retrieved from HYDRA without using a terminal for the entry.

In the same way, data can be transferred or called up, which is normally entered or retrieved at the HYDRA clients.

The data can be transferred to HYDRA online or offline via an external application.

Implementation notes

You use this component if you would like to:

- Exchange personnel data with HYDRA on your own or using 3rd party applications
- Connect existing applications to HYDRA

Integration

For integration purposes, the HYDRA Personnel Data Manager provides a separate program library as well as corresponding interface calls.

Functions

- Programming libraries:
 - For integration into the individual application
- Description of the functions:
 - According to the HYDRA objects and their functions

- Special workshops:
 - For goal-oriented integration and utilization of the HYDRA Personnel Data Manager

Contents

This document describes the formats used for transferring personnel data to HYDRA or to read out personnel data from HYDRA.

The technical description of the interface is included in the document entitled SCS-PDM "Production Data Manager".

2 HYDRA Production Data Manager HR – PZE/PZW/ZKS/PEP

2.1 Optional data transfer from SAP

You use the structures described in the following to transfer data from SAP in HYDRA dialog data format using a customer-specific function module.

Message type: Z*

IDoc type: Z*01

Segments: Z2BAPI000

NOTE

To generate segment names in HYDRA inbound processing as described above, the segments must have been created in SAP according to the pattern Z1<segment name>. Versioning in SAP outbound processing then creates the segment names in the form Z2<Segment name><Version>.

Example: Z1BAPI becomes Z2BAPI000

Field name	Type		Description	Example
Transaction	CHAR	20	Transaction ID (dialog ID in HYDRA)	TGERG.MODIFY
Description	CHAR	40	Plain text designation as comment	Zeitwirtschaftsergebnisse.an.HYDRA
Data	CHAR	940	Dialog data string for HYDRA	DLG=TGERG.MODIFY TGERG.PNR=12345678 ... For more details see the sections that follow

2.2 Sending HR data to HYDRA

2.2.1 Transfer of PZE and ZKS time events

The time events listed below can be transferred to HYDRA online.

Structure of dialog data

The different fields are separated by the "|" symbol:

Header data

Field	Description
DLG={P_KOM, P_GEH, ...}	Dialog ID (see below) (e.g. clocking-in DLG=P_KOM)

	The dialog ID should be transferred as the first field.
DAT={mm/dd/yyyy}	Date of the event in the format "mm/dd/yyyy" (e.g. clocking date DAT=03/30/1999)
ZEI={seconds}	Time of the event in seconds after midnight (e.g. clocking time 10:00:03 is ZEI=36003)
USR={hy_user}	"Hydra User" (see above) With terminals, 2000 is added to the terminal number. (terminal 4 is USR=2004)
OFF={J N}	Offline flag. Enter "OFF=J" if data has been entered offline and buffered. In this case, data is processed separately. ("OFF=N" need not be specified)

Field data

Field	Description
TNR={...}	Terminal number
KNR={...}	Badge number with a maximum of 10 characters (0...9, A...F). The badge number has to be uploaded with the same number of digits (length) because it has been transferred while downloading authorizations.
PNR={...}	Personnel number with a maximum of ten digits (0..9)
FIR={...}	Company with a maximum of four digits. As an alternative to the staff badge number, the personnel number can be transferred with the company with some dialogs.
KST={...}	Cost center with a maximum of eight digits
ZART={...}	Time type (S = daylight saving time, W = standard time). If this field is not transferred, HYDRA automatically identifies the time type using the change between daylight saving time and standard time. Daylight saving and standard time cannot be distinguished properly on the day the time is reset.
FGR={...}	Absence reason for P_VB, P_NB or P_FGR.
PIN={...}	The person's PIN code or password (e.g. for Internet clocking records). If this field is transferred, the PIN code is always checked (against the PIN code of the HR master) and the access authorization is also checked (with Internet, it is always the terminal number 255).
PARAM02={...}	This field can include up to two references (separated by comma) to a message displayed on the terminal. You use this field to count down the number specifying how often a message is displayed (or if escalation management is used, an escalation can be finished by the message display).

	Examples: "PARAM02=143" or "PARAM02=143,178"
--	--

Note

Enter either the personnel number and the company or the staff badge number.

Dialog IDs

Identification	Description
P_KOM	Clocking-in
P_GEH	Clocking-out
P_PAU	Clocking out for break
P_AST	Automatic status clocking (subject to the status, it is like a clocking-in or clocking-out)
P_VB	Advance clocking: Clocking-out including reason. The number of the absence reason is transferred by FGR=x without leading zeros. For business trip clocking records FGR=1 is set.
P_NB	Subsequent clocking: Clocking-in including reason. The number of the absence reason is transferred by FGR=x without leading zeros.
P_FGR	Absence reason clocking (subject to the status, it is like an advance posting or subsequent posting): the number of the absence reason is transferred by FGR=x without leading zeros.
Z_ZUT	Logging of an access. (Using the fields BDAT (date until) and BZEI (time until), you can additionally transfer the time specifying how long the door was open. DAT and ZEI are interpreted as start date and start time).
Z_ZV	Logging of an access attempt (The field ZVG includes the reason for the access attempt: 2001=Unauthorized badge 2002=No badges loaded (number of badges = 0) 2003=Beyond access time model 2004=Beyond opening hours 2005=Wrong PIN code 2006=Wrong company number 2010=Double posting within the blocking time (anti-passback) 2013=Missing PIN code 2014=Badge beyond validity period 2020=Other access point of the security gate opened 2030=Already present in room zone 2031=Not present in room zone 2032=Room zone completely occupied 3000=Wrong badge number length

Example of a clocking-out on 15 January 2010 at 16:32:53:

DLG=P_GEH|KNR=001365|DAT=01/15/2010|ZEI=59573|TNR=17|

2.2.2 Transfer of access statuses and access logs

The status of an access point can be sent to HYDRA using the dialog "Z_STA":

Field	Description
DLG=Z_STA	Dialog ID for the access point status
ZNR={...}	Access point number
DAT={...}, ZEI={...}	Date and time (in seconds since beginning of the day)
DATB={...}, ZEIB={...} DATE={...}, ZEIE={...}	As an alternative to DAT and ZEI, DATB and ZEIB can be used to transfer the start time of the status and DATE and ZEIE can be used to specify the end time. With cyclic status postings, DATE and ZEIE include the current point in time. With this alternative, the fields DATB, ZEIB, DATE and ZEIE must be populated.
STA={...}	Status of the access point: Z: The access point is closed O: The access point is open U: The access point is open without permission L: The access point has been opened too long S: Sabotage: The terminal has been opened A: Malfunction: The terminal is not connected with the reader F: The alarm is suppressed at the access point. One of the statuses "closed" or "open" (Z, O) specify the end of the alert (U, L, S, A).
KNR={...}	Badge that has opened the access point (with status "opened too long").
BERANZ={...}	Number of authorized badges
BERDAT={...}, BERZEI={...}	Point in time when authorizations have last been read.
PRO={J/N}	This button controls whether or not HYDRA logs are generated from access statuses (PRO=J). As an alternative, log records about access point statuses may also be sent to HYDRA (PRO=N).

Access point statuses are sent to HYDRA in cyclic intervals. The cyclic status time is defined for each access point in the access list (ZYKL:STA).

Access status logs are sent to HYDRA using the dialog "Z_PRO":

Field	Description
DLG=Z_PRO	Dialog ID for access status logs
ZNR={...}	Access point number
DATB={...}, ZEIB={...} DATE={...}, ZEIE={...}	DATB and ZEIB can be used to transfer the start time of the status and DATE and ZEIE can be used to specify the end time.
DAUER={...}	Duration of the status at the access. If this field is not transferred, the duration is calculated automatically.
STA={...}	Status of the access point (the same values as for the access point status)
KNR={...}	Badge that has opened the access point (with status "opened too long").

2.3 Reading HR data from HYDRA

2.3.1 Requesting PZE access authorizations

Access authorizations are provided by the command DLG=LIST;27 and filed in HYDRADIR\spool\{file name}.

Structure of dialog data:

"DLG=LIST;27|DATEI={file name}|DAT=...|ZEI=...|USR=...|TNR=...|..."

{File name}

Specification of ".\spool\hyu{Hydrauser}.c27"; with {Hydra user} ranging between 2001 and 2999 (user numbers of the terminals). The external interface 1 corresponds to the HYDRA user number 3001.

The list is sorted by the badge number and includes the following data:

KNR=Badge number ...	The first row includes the column caption and the field ID	KNR=Badge number ...
{Badge1} ...	The other rows include the values for the field ID. The individual badges are sorted in ascending order in the file.	0001 ...
{Badge1} ...		0004 ...

When data is interpreted, the field abbreviations of the 1st line must be interpreted. Future versions can have a different column sequence or new columns are inserted at any place. Columns with unknown field abbreviations must be ignored and must not lead to a program error or termination.

The following table shows further columns that are included in each row. The columns are separated from each other by the "|" pipe symbol:

DGBE= Business trip authorization	Business trip authorization (J/N)	e.g. J
PNR=Person	The person's personnel number	e.g. 142234
FIR=Company	Company the person is assigned to	e.g. DBI
KTO:x=Designation	Up to 8 columns including accounts can be listed. The number depends on how many accounts have been activated in HYDRA. Behind the equals sign, the account name is shown that is displayed on the terminal, if possible.	Example for an account balance: 123:43

2.3.2 Requesting the ZKS access authorizations

Access authorizations are provided by the command DLG=LIST;28 and filed in HYDRADIR\spool\{file name}. The file name should be structured as follows: .\spool\hyu{Hydra user}.c{number of the list};

Example: .\spool\hyu2017.c28

Structure of dialog data:

"DLG=LIST;28|DATEI={file name}|DAT=...|ZEI=...|USR=...|ZNR=...|..."
with ZNR being the corresponding access point number.

The list is sorted by the staff badge number and includes the following data:

KNR=Badge number	Valid badge number	e.g. 0111
PIN=PIN code	PIN code; transferred uncoded. The PIN code is only requested during the access periods when PIN code request is enabled.	e.g. 4711
DAT_VON=Date from	Beginning of the validity period of the badge. Access authorizations, which are valid next week, are transferred. For this reason, the validity period must be checked. If this field is empty, the validity of the badge is not restricted in the future.	e.g. 05/30/1999
DAT_BIS=Date until	End of validity of the badge. If this field is empty, the badge is valid for an unlimited period.	e.g. 12/31/1999
WTAG=Weekday	The access authorization is valid on the specified weekdays. This 8-digit field contains a "J" on the days when the authorization is valid. The first digit stands for Sunday, the 7th digit for Saturday and the 8th digit for a public holiday. Note: This field is no longer relevant as of HYDRA 7.1, as it has been replaced by the weekdays (WTAG) in the access time models.	e.g. NJJJJJNN
ZZ=access time model	Number of the access time model to specify a time limit for the access authorization.	e.g. 2

2.3.3 Requesting the list of access time models

The list of access time models is provided using the command `DLG=LIST;29` and stored in `HYDRADIR\spool\{file name}`. The list is identical for all access points and, as a result, does not have to be requested for each access point.

Structure of dialog data:

"DLG=LIST;29|DATEI={File name}|DAT=...|ZEI=...|USR=...|..."

The list includes the following data:

ZZ=access time model	Number of the access time model.	e.g. 2
ZEIVON=beginning of the access period	Start time of an interval of the access time model in seconds since beginning of the day. If values < 0 are transferred for this time, they are interpreted as times of the previous day. Example: -3600 is 23:00 on the previous day (only with the terminal programs AIP and ctwin).	e.g. 21600
ZEIBIS=end of the access period	End time of an interval of the access time model in seconds since beginning of the day. If values > 86400 (= 24 hours) are transferred for this time, this end time is interpreted as a time of the following day. Example: 90000 is 01:00 on the next day (only with the terminal programs AIP and ctwin).	e.g. 86400
GETKNR=Requesting the badge number	Defines whether or not the badge is required to open the door during that time interval (J/N). This field is only interesting for opening hours because the check if the badge number request is activated can only be performed when the badge has been read.	e.g. J
GETPIN= Request PIN code	Defines whether or not a PIN code is required to open the door during that time interval (J/N).	e.g. N
PRO=Logging	Specifies the postings that are logged in this access period:	e.g. Z

	- 'Z': accesses and access attempts - 'V': only access attempts - 'N': no logging	
WTG=Weekdays	The access period is valid on the specified weekdays. This 10-digit field contains a "J" on the days when the authorization is valid. The 1st character stands for Sunday, the 7th character for Saturday and the 8th to 10th characters stand for three types of public holidays.	e.g. NJJJJJNNNN

The list can include several intervals for an access time model each having the same number.

2.3.4 Requesting the public holidays

The list of public holidays is provided by the command `DLG=LIST;30` and filed in `HYDRADIR\spool\{file name}`. It includes the public holidays for the next 30 days as of yesterday. The list is made up for an access group. When you make a request for an access, the system must request the list of the relevant access group.

Structure of dialog data:

„DLG=LIST;30|DATEI={file name}|DAT=...|ZEI=...|USR=...|ZNR=...|...“

The list includes the following data:

DAT=Date	Date of the public holiday	e.g. 06/03/1999
BEZ=Designation	Designation of the public holiday	e.g. Feast of Corpus Christi
ART=Type	Type of the public holiday (1/2/3): three types of public holidays are possible as of HYDRA 6.5. In the access time models, you can assign authorizations for these 3 types of public holidays.	e.g. 1

2.3.5 Requesting opening hours

The list of opening hours is provided by the command `DLG=LIST;32` and filed in `HYDRADIR\spool\{file name}`. The list is made up for an access group. When you make a request for an access, the system must request the list of the relevant access group.

Structure of dialog data:

„DLG=LIST;32|DATEI={file name}|DAT=...|ZEI=...|USR=...|ZNR=...|...“

The list includes the following data:

DAT_VON=Date from	Beginning of the validity period for opening hours. Opening hours that are valid next week are transferred. For this reason, the validity period must be checked.	e.g. 05/03/1999
DAT_BIS=Date until	End of validity of opening hours. If this field is empty, the validity of opening hours is unlimited.	e.g. 31/12/1999
WTAG=Weekday	The opening hours are valid on the specified weekdays. This 8-digit field contains a "J" on the days when the opening hours are valid. The first digit stands for Sunday, the 7th digit for Saturday and the 8th digit for a public holiday. Note: This field is no longer relevant as of HYDRA 7.1, as it has been replaced by the weekdays (WTAG) in the access time models.	e.g. NJJJJJNN
ZZ=access time model	Number of the access time model to specify a time limit for the opening hours.	e.g. 2

2.3.6 Requesting the terminal list

The list of terminals is provided by the command DLG=LIST;45 and filed in HYDRADIR\spool\{file name}. You can request this list for a specific or for all terminals.

Structure of dialog data:

„DLG=LIST;45|DATEI={file name}|DAT=...|ZEI=...|USR=...|TNR=...|“

The list includes the following data:

TNR=Terminal number	Number of the terminal	e.g. 13
TYP=Terminal type	Terminal type (series). MBB terminals range between 10, 40-44 or 50. Benzing terminals range between 100 and 109 and between 120 and 129. Terminals by MECS range between 201 and 204 (201 = Staff Port 2.0, 202 = Time Port 2.0, 203 = Access Port 2.0, 204 = Job Port 2.0)	e.g. 331 or 380
CFG:1=Configuration 1	Configuration ID 1: includes the terminal class for MBB, Benzing and MECS terminals	e.g. 1
HWADR=Hardware address	Hardware address of the terminal. The bus address is entered after a semicolon for a bus at the COM interface.	e.g. COM1;5 e.g. 192.168.10.123
TZ=Time zone	Time zone of the terminal. The following entries are processed: GMT+2DST Eastern Europe (Bucharest, Sofia, ...) GMT+1DST Central Europe (Berlin, Vienna, ...) GMT0DST Great Britain (London, ...) GMT-6DSTU USA Central Standard Time (Chicago, Dallas, Kansas City, Winnipeg) GMT-5DSTU Mexico (Quintana Roo) GMT-6DSTU Mexico (Mexico City, ...) GMT-7DSTU Mexico (Chihuahua, ...) GMT-8DSTU Mexico (Baja California Tijana) If no entry is made in this field, Central Europe is the default value (with change from standard to daylight saving time).	empty
LANG=Language	Language (empty or 1=German, 2=English, 3=Dutch, 4=French, 5=Danish, ...) Please note: With old installations, a letter might be included in this field --> ignore	e.g. 1
BEZK=Location	Location of the terminal (char 8)	e.g. Entrance
BEZL=Designation	Designation of the terminal (char 20)	e.g. Time at the entrance
AKTIV=Active	Specifies whether or not the terminal is active (J/N). Inactive terminals are not polled.	e.g. J

LEN_KNR=Length of badge number	Authorized badges are transferred to the terminal with the length that is configured here. This length must also be integrated when clocking records are uploaded.	e.g. 4
BART:MDE=MDE active	Operation mode of the terminal. This field shows whether or not the machine data collection module (HYDRA MDE) is active on this terminal (J/N).	N
BART:ADE=ADE active	Operation mode of the terminal. This field shows whether or not the shop floor data collection module (HYDRA ADE) is active on this terminal (J/N).	N
BART:PZE=PZE active	Operation mode of the terminal. This field shows whether or not the time and attendance module (HYDRA PZE) is active on this terminal (J/N). Access control (ZKS) terminals are also presented as time and attendance (PZE) terminals.	J
PZEBART=PZE operation mode	Operation mode for PZE and ZKS ("AST"=automatic status (rhythm posting), empty = enter status using the keyboard, "Z*" = ZKS operation modes)	e.g. AST
PZESTA:VORG=Default status	Default status to which the terminal automatically returns (currently not processed).	e.g. "A" for automatic status
SYSNR=Company number/system number	Company number/system number that is to be included in the badge number.	e.g. empty
TTXT:KOM=Key IN	Labeling of the IN key	e.g. clock-in
TTXT:GEH=Key OUT	Labeling of the OUT key	e.g. clock-out
TTXT:PAU=Break key	Labeling of the break key	e.g. break
TTXT:INFO=Key INFO	Labeling of the INFO key	e.g. info
FGR:1=Absence reason 1	1th absence reason (char 3)	e.g. bus
TTXT:FGR1=Key Absence reason 1	Labeling of the first absence reason key	e.g. business trip
FGR:2=Absence reason 2	Second absence reason (char 3)	e.g. 97
TTXT:FGR2=Key Absence reason 2	Labeling of the second absence reason key	e.g. doctor
FGR:3=Absence reason 3	Third absence reason (char 3)	e.g. empty
TTXT:FGR3=Key	Labeling of the third absence reason key	e.g. empty

Absence reason 3		
FGR:4=Absence reason 4	Fourth absence reason (char 3)	e.g. FGL
TTXT:FGR4=Key Absence reason 4	Labeling of the fourth absence reason key	e.g. list of absence reasons
FGRCFG= Input of absence reason	Configuration of absence reason input: Entry "3" stands for the absence reason list of the 4th function key	e.g. empty
OPT:FGRAUTO=Recordi ng of absence reasons	Automatic input of absence reasons if beyond planned time (entry "G").	e.g. empty
PLAUS:PZEONL=Online check	Online checking of rejected badges (not yet processed)	e.g. empty
PLAUS:PZESTA=Status sequence	Checking of the status sequence: "S"=checking whether the status sequence is correct "P"=checking whether clocking-in is available at the same terminal With the operation mode "AST" the entry "S" results in the status to be requested and displayed online.	e.g. empty
ZYKLLOAD:PZE= cyclic loading PZE	Specification in seconds how often the terminal cyclically reloads its configuration and authorizations.	e.g. 3600
ZEI:BERLESEN1	1. Time for reading PZE authorizations	e.g. 7200
ZEI:BERLESEN2	2. Time for reading PZE authorizations	e.g. 10800
RELZUG:DAUER= Duration of opener	Relay time for door opener	e.g. 3
PZESTA:DAUER= Duration of status	General return time for display outputs to the default status	e.g. 5
PZEINFO:DAUER= Duration of info	Display duration of the information	e.g. 8
PZEINFO:CFG=Informati on display	"S" for displaying the last clocking records	e.g. empty
PZEINFO:NR=Information number	Number of the information to be displayed	e.g. 1
INFOZEIB:1=Info from 1	Start of the first period for displaying the information on the terminal	e.g. 0
INFOZEIE:1=Info to 1	End of the first period for displaying information on the terminal	e.g. 86400
INFOZEIB:2=Info from 2	Start of the second period for displaying the	e.g. 0

	information on the terminal	
INFOZEIE:2=Info to 2	End of the second period for displaying information on the terminal	e.g. 0
INFOZEIB:3=Info from 3	Start of the third period for displaying the information on the terminal	e.g. empty
INFOZEIE:3=Info to 3	End of the third period for displaying information on the terminal	e.g. empty
INFOZEIB:4=Info from 4	Start of the 4th period for displaying the information on the terminal	e.g. empty
INFOZEIE:4=Info to 4	End of the 4th period for displaying information on the terminal	e.g. empty
INFOZEIB:5=Info from 5	Start of the 5th period for displaying the information on the terminal	e.g. empty
INFOZEIE:5=Info to 5	End of the 5th period for displaying information on the terminal	e.g. empty

2.3.7 Requesting the access list

The list of access points is provided by the command `DLG=LIST;46` and filed in `HYDRADIR\spool\{file name}`. You can request this list for a specific or for all terminals. The list is sorted by the terminal number and by the access point number if several access points are connected to one terminal.

Structure of dialog data:

„DLG=LIST;46|DATEI={file name}|DAT=...|ZEI=...|USR=...|TNR=...|“

The list includes the following data:

ZNR=access point	Number of the access point	e.g. 17
BEZK=Short name	Short name	e.g. gate S
BEZL=Designation	Designation	e.g. Southern gate factory building
ZGRP=Access group	Number of the access group	e.g. 21
AKTIV=Active	Specifies whether or not the access point is active (J/N). Inactive access points are blocked (no access authorization applicable).	e.g. J
RAUM=Room number	Room number (not yet processed at the moment)	e.g. 0
ART=Access type	Access point type: 'E' : Entrance 'A' : Exit 'D' : Passage 'O' : Without check of badge number (check of system number SYSNR only)	e.g. E
TNR=Terminal number	Number of the terminal to which the access point is connected.	e.g. 10
LESER=Reader	Number of the reader. The access point is uniquely defined by the combination of terminal number and reader. The access point number is a logical number for the "physical" address. Local readers at the MBB terminal get an offset of 100. Subbus readers with MBB terminals are without offset.	e.g. 5
ZAUF:DIGOUT=Channel opener	Output (relay) for door opening contact	e.g. 1

ZZU:DIGOUT=Channel closer	Output (relay) for door closing contact	e.g. 2
ALARM:DIGOUT=Channel alarm	Output (relay) for a connected alarm (e.g. warning lights or alarm system).	e.g. 3
ZV:DIGOUT=channel attempt	currently not processed	e.g. 0
ZST:DIGIN=Channel status	Input for monitoring the door status (open/closed)	e.g. 1
ALRAM:AKTIV=Alarm active	Specifies whether the access point generates alarm messages (J/N).	e.g. N
ALRAM:TIMER=Alarm "open"	Delay time in seconds for triggering the alarm.	e.g. 30
OPT:PRO=Trigger posting	'N' : Protocol messages are not written. '0' : (Zero) Alarm messages are written only. '1' : Access attempts are recorded in addition to alerts. '2' : All accesses are recorded in addition to the alerts and access attempts. As of HYDRA 7.1 this setting is overwritten by the logging configuration specified for the access periods of the opening hours.	e.g. 2
OPT:OFFEN=Message "open"	currently not processed	e.g. 2
MAXZAUF=Duration "open"	Maximum duration of "access point open"	e.g. 10
ZAUF:DAUER=Duration of opener	Duration of opener signal in seconds.	e.g. 4
ZZU:DAUER=Duration of closer	Duration of the closer signal in seconds.	e.g. 4
ZV:DAUER=Duration of the attempt	currently not processed	e.g. 0
WDHSPERR=anti repeat function (blocking)	Minimum time to open the access point with the same badge (seconds).	e.g. 600
ZYKL:STA=cyclic status	Time for sending the access point status to the server in cyclic intervals (seconds).	e.g. 300

ZYKL:CFG=cyclic configuration	Time for reading the access configuration from the server in cyclic intervals.	e.g. 3600
ZYKL:BERLESEN=cyclic authorizations	Time for reading authorizations from the server in cyclic intervals.	e.g. 3600
CFGANZTG=Number of days	Specifies for how many days in advance access configurations are to be loaded onto the terminal.	e.g. 7
CFGANZ=Number of records	currently not processed	e.g. 0
OPT:PZEAUTO=Trigger PZE	Specifies whether an access includes a PZE clocking (entry "J") or not (entry "N"). A clocking-in record is generated if it is an entry and a clocking-out record is generated if it is an exit. An automatic status clocking record (P_AST) is generated if it is a passage.	e.g. N
SAB:DIGIN=Channel sabotage	Channel number of the terminal to which a sabotage signal is connected or 0 if not available. This channel indicates when the terminal or badge reader (subject to the model) is opened without permission.	e.g. 0
DIGIN:1=channel in 1	currently not processed	e.g. 0
DIGIN:2=channel in 2	currently not processed	e.g. 0
DIGIN:3=channel in 3	currently not processed	e.g. 0
DIGIN:4=channel in 4	currently not processed	e.g. 0
DIGOUT:1=channel out 1	currently not processed	e.g. 0
DIGOUT:2=channel out 2	currently not processed	e.g. 0
DIGOUT:3=channel out 3	currently not processed	e.g. 0
DIGOUT:4=channel out 4	currently not processed	e.g. 0
CFG=configuration	currently not processed	e.g. "" (empty)

2.4 Online requests

2.4.1 Online check of PZE authorizations

Using the command `DLG=SCMD;46`, you can check whether or not a badge is allowed to clock at a specific PZE terminal. The return string `"RET=0"` indicates that the authorization is available. The badge is not authorized if `"RET="` includes other values..

Structure of dialog data:

`"DLG=SCMD;46|DAT=...|ZEI=...|USR=...|TNR=...|KNR=..."`

Instead of the badge number `"KNR="`, it is also possible to transfer the personnel number `"PNR="` along with the company `"FIR="`.

2.4.1.1 Display of messages

When PZE authorizations are checked, it is also checked whether a message is available for the person. This message is written in the file `"spool\hyinf<tnr>.dat"` on the server, whereas `<tnr>` stands for the terminal number. The file can be loaded after the online check and, if a message is included, it can be displayed. The file has the following structure:

KNR	Badge number	e.g. 17
TYP	Information about the generation of the message.	e.g. PE
DATB, DATE	Period during which the message is to be displayed.	06/15/2004, 06/30/2004
WTG	Weekday on which the message is to be displayed: 0 = Sunday ... 6 = Saturday 7 = all days of the week	e.g. 7
OPT:KOM=J/N	Specification whether or not the message is to be displayed for a clock-in record.	e.g. J
OPT:GEH=J/N	Specification whether or not the message is to be displayed for a clock-out record.	e.g. J
OPT:PAU=J/N	Specification whether or not the message is to be displayed for clocking a	e.g. J

	break.	
OPT:FGR=J/N	Specification whether or not the message is to be displayed for an absence reason posting.	e.g. J
OPT:INFO=J/N	Specification whether or not the message is to be displayed when information on the account balance is shown.	e.g. J
ANZ	Number specifying how often the message is to be displayed. If this field is populated, the message display with the next clocking must be posted using the field PARAM02.	e.g. 1
VERWEIS	Unique data record number	e.g. 10537
INFO:1, ..., INFO:10	Up to 10 lines of the message to be displayed	e.g. Please contact the payroll office

2.4.2 Online check of ZKS authorizations

Using the command DLG=SCMD;49, you can check whether or not a badge is authorized for a specific access point in ZKS. The return string "RET=0" indicates that the authorization is available. The badge is not authorized if "RET=" includes other values..

Structure of dialog data:

"DLG=SCMD;49|DAT=...|ZEI=...|USR=...|ZNR=...|KNR=..."

2.4.3 Online request of a person's account balances

Using the command DLG=SCMD;31 a person's account balances can be requested. The return string includes the designations and values of up to 8 accounts that are to be displayed.

Structure of dialog data:

"DLG=SCMD;31|DAT=...|ZEI=...|USR=...|TNR=...|KNR=..."

Structure of the return string:

"RET=0|KT=|LT=|BEZL:1=Gleitzzeit|WERT:1=0:00|BEZL:2=Urlaubskonto|WERT:2=38.00|"

2.5 Pre-processed data from third-party systems

2.5.1 Import of day-related (clocking) data

This section describes how data is transferred from external systems providing preprocessed data for time and attendance. This data can be processed further by HYDRA-PZE (Time & Attendance) or they are directly available for modules affecting several products, e.g. ADE/PZE comparison or HYDRA incentive wages.

Preprocessed clocking records and calculated workday results may be imported in HYDRA. The workday results, e.g. include the determined net attendance time per person and day. In addition to the workday result, one or more clocking records may be available.

Three dialogs are relevant for this purpose:

Include day results:	TGERG.MODIFY
Delete all clocking records of a person of one day:	STMP.DELETE
Load clocking:	STMP.LOAD

The following dialogs are required in the interface file to include a person's data of an entire day:

- 1) Include the person's day result (header record)
- 2) Optional: Delete all clocking records of a person at one day
This avoids double clocking records if data is transferred several times over time.
- 3) Optional: Insert all individual clocking records of the person at one day (subsequent records)

Only the work day result (header record) is relevant if the "production time statistics" function is required in the first place. The clocking records may optionally be skipped, as they only provide more detailed information.

Below please find a description of the individual dialogs and a sample file.

Example of a dialog (one line of an interface file):

```
DLG=STMP.DELETE | STMP.FIR=012 | STMP.PNR=002449 | STMP.ABREDAT=03/01/2001 |
```

Explanation:

STMP.DELETE is the dialog identification. Vertical lines ("|", ASCII 124) are used to separate the individual parameters that follow (STMP.FIR, STMP.PNR, ...). Select a field width for the different parameters that is wide enough for the presentation. However a fixed file structure can also be realized by adding leading zeros (for numbers) and trailing spaces. The sequence of the parameters is irrelevant. Some parameters must be specified in a dialog and some parameters are optional. You can specify the optional parameters, if required, or you can leave these parameters out. HYDRA then populates these parameters using default values.

Conventions used to present the different data types

Data type	Format	Examples
N<x>	Digits, maximum of <x> places	PNR.PNR=2449 or PNR.PNR=002449
N<x>.<y>	Decimal number with a maximum of <x> predecimal places and <y> decimal places. A dot is the decimal separator.	PNR.PSTD SATZ=30.5 or PNR.PSTD SATZ=00030.5
C<x> Texts (character)	Character string with a maximum length of <x>	PNR.NAME=Huber or PNR.NAME=Huber
Date	MM/DD/YYYY (American format: month, day, year. Slashes are used as separator.)	STMP.DAT=12/31/2001
Times or durations	Seconds since midnight or HH:MM or HH:MM:SS or HH,DDD or HH.DDD H hours (as many places as required) M Minutes (in groups of 60) S Seconds D Industrial or decimal minutes (in groups of 100)	STMP.ZEI=52200 or STMP.ZEI=14:30 or STMP.ZEI=14:30:00 or STMP.ZEI=014,5 or STMP.ZEI=14.500

2.5.1.1 Importing work day result

The dialog for importing the work day results includes the daily times per person and day (header record). Provided that the work day result is not yet available, it will be inserted. In case this dialog already includes a work-day result, it will be updated to avoid multiple entries. HYDRA automatically deletes old work-day results from the data management after a configurable period of time.

Dialog: TGERG.MODIFY				
Parameter	Type	Mandatory	Contents	Description
TGERG.FIR	C4		Company	Company of the person
TGERG.PNR	N8	X	Personnel number	The person's personnel number
TGERG.ABREDAT	Date	X	Settlement date	
TGERG.IZ	Duration	X	Actual working time	The person's (net) actual working time on the settlement day (breaks are already deducted)
TGERG.SZ	Duration		Target time	Optional: The person's target time on the settlement day
TGERG.FZ	Duration		Absence	Optional: The person's absence time on the settlement day
TGERG.SCHZART	C1		Shift time type	Optional: The person's shift type on the settlement day (F/S/N/...)
TGERG.DATB	Date	*1)	Start of work date	Date of the person's evaluated start of working time
TGERG.ZEIB	Time	*1)	Start of work time	Time of the person's evaluated start of working time
TGERG.DATE	Date	*1)	End of work date	Date of the person's evaluated end of working time
TGERG.ZEIE	Time	*1)	End of work time	Time of the person's evaluated end of working time

*1) If the PZE/ADE comparison function is used, these fields must be filled. Only then, the application *Labor time calculation* can be used to its full extent.

Example:

```
DLG=TGERG.MODIFY|TGERG.PNR=999998|TGERG.ABREDAT=12/27/2010|
TGERG.DATB=12/27/2010|TGERG.ZEIB=21600|TGERG.DATE=12/27/2010|TGERG.ZEIE=52200|
TGERG.SZ=28800|TGERG.IZ=30600|TGERG.FZ=0|TGERG.SCHZART=F|
```

2.5.1.2 Deleting all clocking records of a day

This dialog deletes all clocking records of the person on the settlement day. This dialog has been designed to clean the data set before new clocking records are inserted. Old clocking records are deleted automatically in HYDRA after a configurable period of time (at the moment 200 days by default).

Dialog: STMP.DELETE				
Parameter	Type	Mandatory	Contents	Description
STMP.FIR	C4	X	Company	Company of the person
STMP.PNR	N8	X	Personnel number	The person's personnel number
STMP.ABREDAT	Date	X	Settlement date	

2.5.1.3 Loading a clocking record

This dialog loads a clocking record in HYDRA. Old clocking records are deleted automatically in HYDRA after a configurable period of time (at the moment 200 days by default).

Dialog: STMP.LOAD				
Parameter	Type	Mandatory	Contents	Description
STMP.FIR	C4	X	Company	Company of the person
STMP.PNR	N8	X	Personnel number	The person's personnel number
STMP.ABREDAT	Date	*1)	Settlement date	
STMP.ABREDATB	Date	*1)	Start date	Rounded start date May differ from the settlement date with night shifts.
STMP.ABREZEIB	Time	*1)	Start time	Rounded start time
STMP.ABREDATE	Date	*1)	End date	Rounded end date May differ from the settlement date with night shifts.
STMP.ABREZEIE	Time	*1)	End time	Rounded end time
STMP.DATB	Date	*2)	Start date (not rounded)	optional: start date that is not rounded May deviate from the settlement date with night shifts.
STMP.ZEIB	Time	*2)	Start time (not rounded)	optional: start time that is not rounded
STMP.DATE	Date	*2)	End date (not rounded)	optional: end date that is not rounded May deviate from the settlement date with night shifts.
STMP.ZEIE	Time	*2)	End time (not rounded)	optional: end time that is not rounded
STMP.IZ	Duration		Actual time	optional: The person's actual working time in the time interval (clocking duration)
STMP.SCHZART	C1	*1)	Shift type	Optional: The person's shift type on the settlement day (e.g. E, L or N)

*1) Rounded time stamps are only required if the transferred clocking data are not to be evaluated by the HYDRA work-day evaluation or the work-day evaluation function is not supposed to round independently. If you want to import clockings as raw data, only the time stamps that are not rounded and marked via *2) may be filled. The fields marked via *1) must be skipped or left empty.

*2) If the clocking records are imported as raw data to be further processed by the work-day evaluation, use time stamps not rounded to fill the fields. The fields marked via *1) must be skipped or left empty.

2.5.1.4 Examples

In the example below, the data of two persons is transferred for a day:

```
DLG=TGERG.MODIFY|TGERG.FIR=012|TGERG.PNR=002449|TGERG.ABREDAT=01/29/2001|TGERG.IZ=7:4
5|TGERG.SZ=7:30|TGERG.FZ=0:00|TGERG.SCHZART=F|

DLG=STMP.DELETE|STMP.FIR=012|STMP.PNR=002449|STMP.ABREDAT=03/01/2001|

DLG=STMP.LOAD|STMP.FIR=012|STMP.PNR=002449|STMP.ABREDAT=01/29/2001|STMP.ABREDATB=01/2
9/2001|STMP.ABREZEIB=5:53|STMP.ABREDATE=01/29/2001|STMP.ABREZEIE=9:57|STMP.SCHZART=F|

DLG=STMP.LOAD|STMP.FIR=012|STMP.PNR=002449|STMP.ABREDAT=01/29/2001|STMP.ABREDATB=01/2
9/2001|STMP.ABREZEIB=10:13|STMP.ABREDATE=01/29/2001|STMP.ABREZEIE=14:11|STMP.SCHZART=
F|

DLG=TGERG.MODIFY|TGERG.FIR=012|TGERG.PNR=002450|TGERG.ABREDAT=01/29/2001|TGERG.IZ=7:3
0|TGERG.SZ=7:30|TGERG.FZ=0:00|TGERG.SCHZART=F|

DLG=STMP.DELETE|STMP.FIR=012|STMP.PNR=002450|STMP.ABREDAT=03/01/2001|

DLG=STMP.LOAD|STMP.FIR=012|STMP.PNR=002450|STMP.ABREDAT=01/29/2001|STMP.ABREDATB=01/2
9/2001|STMP.ABREZEIB=5:58|STMP.ABREDATE=01/29/2001|STMP.ABREZEIE=10:01|STMP.SCHZART=F
|

DLG=STMP.LOAD|STMP.FIR=012|STMP.PNR=002450|STMP.ABREDAT=01/29/2001|STMP.ABREDATB=01/2
9/2001|STMP.ABREZEIB=10:16|STMP.ABREDATE=01/29/2001|STMP.ABREZEIE=14:01|STMP.SCHZART=
F|
```

2.6 Transferring configurations from third-party systems

2.6.1 Transfer of the planned working time

2.6.1.1 Personal working time

As of HYDRA PZE 7.2 it is possible to transfer the planned working time per person and day without having to define day types and models. These working time plans are saved as "personal working time" in HYDRA.

The following key fields need to be assigned to values for the transfer:

Dialogs: GLZTMOD.INSERT, GLZTMOD.UPDATE, GLZTMOD.MODIFY				
Parameter	Type	Mand atory	Contents	Description
GLZTMOD.PNR	N8	X	Personnel number	
GLZTMOD.DATB	Date	X	Beginning of validity	Start date for the "personal

				working time".
GLZTMOD.DATE	Date	X	Validity end	The end date for the "personal working time" mostly matches the start date.
GLZTMOD.ART	C1	X	Constantly 'P'	P=Personal working time

The following data fields can be transferred for each person and day:

Parameter	Type	Mand atory	Contents	Description
GLZTMOD.BEZK	C6		Short name	
GLZTMOD.BEZL	C20		Detailed designation	
GLZTMOD.VAB	C 15		Responsibility area	
GLZTMOD.SCHZART	C1		Shift type	Only transferred for shift workers.
GLZTMOD.SZ	Time		Target time	Target working time
GLZTMOD.AZMAX	Time		Max. working time per day	A message is triggered after the maximum working time has been exceeded.
GLZTMOD.RAHMB	Time		Skeleton time from	Start of the skeleton time
GLZTMOD.RAHME	Time		Skeleton time until	End of the skeleton time
GLZTMOD.NORMB	Time		Normal time from	Beginning of the normal working time
GLZTMOD.NORME	Time		Normal time until	End of the normal working time
GLZTMOD.KERNB	Time		Core time from	Start of the core working time
GLZTMOD.KERNE	Time		Core time until	End of the core working time. The core time is interrupted by the break frame.
GLZTMOD. PAURAHMB:<1..3>	Time		Frame "from" for the breaks 1 to 3	Beginning of the break frame for the breaks 1 to 3
GLZTMOD. PAURAHME:<1..3>	Time		Frame "until" for the breaks 1 to 3	End of the break frame for the breaks 1 to 3
GLZTMOD. PAUMIN:<1..3>	Time		Minimum duration for the breaks 1 to 3	
GLZTMOD. PAUNORMB:<1..3>	Time		"Normal break from" for the breaks 1 to 3	Beginning of the normal breaks 1 to 3. The normal break is allocated if no break is clocked.

GLZTMOD. PAUNORME:<1..3>	Time		"Normal break until" for break 1 to 3	End of normal break 1 to 3.
GLZTMOD. ENTLTMOD:SZHART	N4		Payment day type	Payment day type for the shift specified in the parameter SZHART
GLZTMOD.PAUFREI	Time		Free break	Free break that is deducted irrespective of the spent working time.
GLZTMOD.OPT:SZB	C1		Compensation of target time starting	A=Beginning of working time R=Beginning of skeleton time K=Beginning of core time N=Beginning of normal time
BEARB	C10		Modified by	

The data type "time" can be assigned to seconds since the beginning of the day or in the format HH:MM (with normal minutes) (example 10:30 a.m. = 37800 = 10:30).

Example for transferring an early shift on 17 December 2007 from 6:00 a.m. until 2:00 p.m.:

```
DLG=GLZTMOD.MODIFY|GLZTMOD.PNR=4711|
GLZTMOD.DATB=12/17/2007|GLZTMOD.DATE=12/17/2007|
GLZTMOD.SZHART=F|GLZTMOD.SZ=28800|
GLZTMOD.RAHMB=21600|GLZTMOD.RAHME=50400|
GLZTMOD.NORMB=21600|GLZTMOD.NORME=50400|
GLZTMOD.KERNB=21600|GLZTMOD.KERNE=50400|
```

2.6.1.2 Day types and year models

In HYDRA the working time is defined in the form of day types and year models:

- There is a separate working time day type for each different daily routine.
- The year models define which working time day type and which shift type is to be assigned at which day of the year.
- The defined year models are saved with the person in the HR master (also see the document entitled HYD-LUG).

2.6.1.3 Transfer of working time day types

The following key fields need to be assigned when working time day types are transferred:

Dialogs: GLZTMOD.INSERT, GLZTMOD.UPDATE, GLZTMOD.MODIFY

Parameter	Type	Mandatory	Contents	Description
GLZTMOD.GLZTMOD	N4	X	Number of the flexitime day type	
GLZTMOD.DATB	Date	X	Beginning of validity	A working time day type is valid until the next validity period starts for the next day type with the same number.
GLZTMOD.ART	C1	X	Type of the model	G=Flexitime day type S=Fixed shift model F=Flexible shift model

The data fields for transferring a working time day type are the same as for the personal working times as described in section "2.6.1.1 Personal working time".

With shift day types, one data record is transferred per shift.

Example:

DLG=GLZTMOD.MODIFY|GLZTMOD.GLZTMOD=7000|GLZTMOD.BEZK=KBez|GLZTMOD.BEZL=Langbez|GLZTMOD.VAB=|GLZTMOD.DATB=01/01/1900|GLZTMOD.ART=G|GLZTMOD.SCHZART=|GLZTMOD.ENTLTMOD: SCHZART=|GLZTMOD.PAUFREI=0|GLZTMOD.OPT:SZB=A|GLZTMOD.SZ=28800|GLZTMOD.AZMAX=36000|GLZTMOD.RAHMB=25200|GLZTMOD.RAHME=68400|GLZTMOD.PAURAHMB:1=28800|GLZTMOD.PAURAHME:1=36000|GLZTMOD.PAURAHMB:2=39600|GLZTMOD.PAURAHME:2=50400|GLZTMOD.PAURAHMB:3=68400|GLZTMOD.PAURAHME:3=70200|GLZTMOD.KERNB=32400|GLZTMOD.KERNE=57600|GLZTMOD.PAUMIN:1=900|GLZTMOD.PAUMIN:2=1800|GLZTMOD.PAUMIN:3=1800|GLZTMOD.NORMB=28800|GLZTMOD.NORME=59400|GLZTMOD.PAUNORMB:1=32400|GLZTMOD.PAUNORME:1=33300|GLZTMOD.PAUNORMB:2=43200|GLZTMOD.PAUNORME:2=45000|GLZTMOD.PAUNORMB:3=68400|GLZTMOD.PAUNORME:3=70200|BEARB=12345

2.6.1.4 Transfer of working time year models

This dialog has been designed to edit working time year models:

Dialog: GLZJMOD.MODIFY				
Parameter	Type	Mandatory	Contents	Description
GLZJMOD.GLZJMOD	N4	X	Number of the flexitime year model	
GLZJMOD.BEZK	C6		Short name	
GLZJMOD.BEZL	C20		Detailed designation	
GLZJMOD.JAHR	N4	*1)	Year	
GLZJMOD.DATB	Date	*1)	Start date of the assignment	

GLZJMOD.DATE	Date	*1)	End date of the assignment	
GLZJMOD.VAB	C 15		Responsibility area	
GLZJMOD.MODELL	Cx		Day types to be assigned	The day types to be entered are included in this parameter and separated by comma. The day type 0 means that no day type is to be defined on this day. The models are entered in the period specified by the parameters JAHR; DATB and DATE. The parameter MODELL specifies how many day types are assigned. If the parameter MODELL includes more day types than can be entered in the date range, they will be ignored.
BEARB	C10		Modified by	

***1) The following combinations are allowed:**

- 1) Year only
- 2) Start and end date
- 3) Year, start and end date

In any case, the dates of these three parameters must all be in the same year!

Example: DLG=GLZJMOD.MODIFY|GLZJMOD.GLZJMOD=7001|GLZJMOD.BEZL=Langbez|

GLZJMOD.BEZK=KBez|GLZJMOD.DATB=01/14/2002|GLZJMOD.DATE=01/18/2002|

GLZJMOD.MODELL=100,100,100,100,100| GLZJMOD.VAB=|BEARB=12345|

2.6.1.5 Transfer of shift rhythm year models

This dialog has been designed to edit shift rhythm year models:

Dialog: SCHZARTJMOD.MODIFY				
Parameter	Type	Mandatory	Contents	Description
SCHZARTJMOD. SCHZARTJMOD	N4	X	Number of the shift rhythm year model	
SCHZARTJMOD. BEZK	C6		Short name	

SCHZARTJMOD.BEZZ	C20		Detailed designation	
SCHZARTJMOD. JAHR	N4	*1)	Year	
SCHZARTJMOD. DATB	Date	*1)	Start date of the assignment	
SCHZARTJMOD. DATE	Date	*1)	End date of the assignment	
SCHZARTJMOD.VAB	C 15		Responsibility area	
SCHZARTJMOD. MODELL	Cx		Day types to be assigned	The shift types to be entered are included in this parameter and separated by comma. The shift type "" (blank) means that no shift type is to be defined for this day. The shift types are entered in the period specified by the parameters JAHR; DATB and DATE. The parameter MODELL specifies how many shift types are assigned. If the parameter MODELL includes more shift types than can be entered in the date range, they will be ignored.
BEARB	C10		Modified by	

***1) The following combinations are allowed:**

- 1) Year only
- 2) Start and end date
- 3) Year, start and end date

In any case, the dates of these three parameters must all be in the same year!

Example: DLG=SCHZARTJMOD.MODIFY|SCHZARTJMOD.SCHZARTJMOD=7001|
SCHZARTJMOD.BEZL=Langbez|SCHZARTJMOD.VAB=|SCHZARTJMOD.BEZK=KBez|
SCHZARTJMOD.DATB=01/14/2002|SCHZARTJMOD.DATE=01/18/2002|
SCHZARTJMOD.MODELL=F,F,F,S,S|BEARB=12345|

2.6.2 Absence planning

2.6.2.1 Overview

When absence plannings are transferred from third-party systems, all absences are generally updated for each person. The following processing applies:

- 1) All absences of a person are deleted (FZ.DELETE using MOD=G or FZ.DELETE_ALL)
- 2) All absences of a person are transferred a new time (FZ.INSERT for each absence)

If you have stored the user who created the absences, you can configure that only this user can delete the absence. It is then possible to manually manage the absences in the system in addition to the absences managed via interface.

2.6.2.2 Creating absence planning

You can use this dialog to insert absences of persons for the Time Management or the Personnel planning:

Dialog: FZ.INSERT				
Parameter	Type	Mandatory	Contents	Description
FZ.PNR	N8	*1)	Personnel number	The person's personnel number (as an alternative to cost center and area)
FZ.KST	C 8	*1)	Cost center	Cost center (as an alternative to person and area)
FZ.BER	C 8	*1)	Area	Area (as an alternative to person and cost center).
FZ.FIR	C4		Company	Company of the person, cost center or area. If no company is indicated, the absence applies for all companies.
FZ.DATB	Date	X	Start date	Start date of the absence
FZ.DATE	Date	X	End date	End date of the absence

FZ.WTG	N1		Weekday	Weekday for which absence planning applies: 0 ... 6 = Sunday ... Saturday 7 = every day (by default)
FZ.ENTLTMOD	N4		Absence payment	Number of the payment day type with which the absence is to be set off. This key determines, for example, the color indicating absences in the graphic absence planning. This key determines, for example, the color indicating absences in the graphic absence planning.
FZ.BEZK	C 3		Comment	The comment is entered in the absence overview. If this field remains empty, the first three letters of the short name of the absence payment will be used.
FZ.BEZL	C20		Comment	Comment defined for the absence
FZ.VERB	C1		Processing	'F': Set off absence from absence planning. 'D': Set off average working time from the HR master. 'S': Set off planned target working time. 'N': Set off planned normal time.
FZ.DAUER	Duration or N6.x		Duration of the absence	If processing "F" is set, this field has to include the duration of the absence.
FZ.TLWABW	N3		Partially absent	For part-day absences, this field specifies the percentage used to fill the time.
FZ.CERTIFY	C1 (J/N)		Subject to approval	Defines whether or not the generated absence is subject to approval.
FZ.LFZ:DATB	Date		Start date of the first pre-existing condition	If continued pay is to be monitored, this field includes the

				start date of the first pre-existing condition.
FZ.LFZ:DAUER	N4		Duration of pre-existing conditions	If continued pay is to be monitored, this field states the duration of the pre-existing condition in days.
FZ.LFZ:VERWEIS	N8		Reference to the last pre-existing condition	If continued pay is to be monitored, this field includes the reference to the last pre-existing condition.
BEARB	C10		Optional: Modified by	If you transfer the user who modified the entry, you can later on delete the absences of this user.

*1) Only one of the fields FZ.PNR, FZ.KST and FZ.BER must and may be filled.

Examples:

DLG=FZ.INSERT|FZ.PNR=1234|FZ.DATB=12/27/2019|FZ.DATE=12/30/2019|FZ.ENTLMOD=400|

DLG=FZ.INSERT|FZ.PNR=1456|FZ.DATB=08/22/2019|FZ.DATE=09/02/2019|FZ.ENTLTMOD=400|BEARB=MASTERSYS|

2.6.2.3 Deleting an absence planning

Different dialogs are available to delete absences. The dialog used depends on the system used. Does the system use the personnel time management including labor time calculation or does the system only use the absences for display and planning purposes?

- If you use the personnel time management including labor time calculation, use the dialog FZ.DELETE with MOD=G
- If the absences are only displayed or used for the personnel planning, then use the dialog FZ.DELETALL.

The differences between the two dialogs are described below.

2.6.2.4 Deleting absences if you use the labor time calculation

You can use the dialog FZ.DELETE with MOD=G to delete absences of a person. All absence times of the person are deleted. Optionally, you can filter by the user (modified by) or the date range to delete the absences.

If you delete specific absences via the GUI, the data records are internally marked as deleted, but on database level you can track this action in a history in the system. But if you delete all absences of a person, the data records are actually deleted physically because the deletion and the new transfer of all absences require greater data volumes and a useful history is not possible.

If you use the dialog FZ.DELETE with MOD=G, the following actions are performed in addition to the actual delete absence action.

- If labor time calculations have already been performed for the specified person, the results for the absences included in the period of time specified must be recalculated.
- If the deleted absences include requested absences, the absence requests are rejected.

If you do not require these additional actions, use the dialog FZ.DELETE_ALL. This way, the server is not loaded unnecessarily.

Dialog: FZ.DELETE				
Parameter	Type	Mandatory	Contents	Description
MOD	C1	X	Mode "G" obligatory for "global": MOD=G	The mode G specifies that all absence times of a person are deleted. Other modes are not planned.
FZ.PNR	N8	X	Personnel number	The person's personnel number
FZ.BEARB:DEL	C10		The absences of the user (modified by) are deleted.	Optional filter. If the filter is set, then only the absences are deleted that were created or changed by this user.
FZ.DATB	Date		Start date	Optional filter for a date range. To use the filter, enter start and end date. If you use this filter, only the absences are deleted that are fully included in the specified period of time.
FZ.DATE	Date		End date	See FZ.DATB.

Examples:

DLG=FZ.DELETE|MOD=G|FZ.PNR=1456|

DLG=FZ.DELETE|MOD=G|FZ.PNR=1456|FZ.DATB=12/04/2019|FZ.DATE=12/20/2019|

DLG=FZ.DELETE|MOD=G|FZ.PNR=1456|FZ.BEARB:DEL=MASTERSYS|

2.6.2.5 *Deleting absences if you do not use the labor time calculation*

You can use the dialog FZ.DELETE_ALL to delete absences of a person. All absence times of the person are deleted. Optionally, you can filter by the user (modified by) or the date range to delete the absences.

If you delete specific absences via the GUI, the data records are internally marked as deleted, but on database level you can track this action in a history in the system. But if you delete all absences of a person, the data records are actually deleted physically because the deletion and the new transfer of all absences require greater data volumes and a useful history is not possible.

Contrary to the dialog FZ.DELETE with MOD=G, the dialog FZ.DELETE_ALL does not perform further actions that are integrated in the personnel time management. For this reason, FZ.DELETE_ALL is quicker and unnecessary data changes are avoided.

Dialog: FZ.DELETE_ALL				
Parameter	Type	Mandatory	Contents	Description
FZ.PNR	N8	X	Personnel number	The person's personnel number
FZ.BEARB:DEL	C10		The absences of the user (modified by) are deleted.	Optional filter. If the filter is set, then only the absences are deleted that were created or changed by this user.
FZ.DATB	Date		Start date	Optional filter for a date range. To use the filter, enter start and end date. If you use this filter, only the absences are deleted that are fully included in the specified period of time.
FZ.DATE	Date		End date	See FZ.DATB.

Examples:

DLG=FZ.DELETE_ALL|FZ.PNR=1456|

DLG=FZ.DELETE_ALL|FZ.PNR=1456|FZ.BEARB:DEL=MASTERSYS|

DLG=FZ.DELETE_ALL|FZ.PNR=1456|FZ.DATB=12/04/2019|FZ.DATE=12/20/2019|

2.6.3 Creating account limits in HYDRA

You can use this dialog to create account limits in HYDRA PZE:

Dialog: PZEKTOG.INSERT				
Parameter	Type	Mandatory	Contents	Description
PZEKTOG.FIR	C4		Company	Company of the person, cost center or area. If no company is indicated, the account limit applies for all companies.
PZEKTOG.PNR	N8	*1)	Personnel number	Personnel number of the person (as an alternative to reference and value)
PZEKTOG.BZG	C20	*1)	Reference	The account limit applies to the specified organization unit (as an alternative to person): - BER: area - KST: cost center - ABT: department - PKREIS: employee subgroup - TAETIGKEIT: activity - BESCHVERH: employment relationship - NSTMP: person does not clock
PZEKTOG.WERT	C20	*1)	Value	The value refers to the organization unit specified in the previous field (as an alternative to person).
PZEKTOG.KTO	N1	X	Number of the account	Account number of the configuration of accounts
PZEKTOG.JAHR	N4		Year	Year of validity of the account limit
PZEKTOG.PER	N2		Period/month	Validity period for the account limit. It refers to the evaluation periods configured for the month evaluation.
PZEKTOG.KTOG: MAXAKTIV	C1 (J/N)	X	Maximum limit active	Specifies whether or not the account limit includes a

				maximum limit value.
PZEKTOG.KTOG: MAX	Duration or N6.x		Maximum limit	For time accounts the maximum limit is entered as duration and as decimal number for daily accounts. The maximum number of decimal places results from the configuration of accounts.
PZEKTOG.LART: MAX	C4		Maximum wage type	Wage type for the maximum limit
PZEKTOG.KTOG: MINAKTIV	C1 (J/N)	X	Minimum limit active	Specifies whether or not the account limit includes a minimum limit value.
PZEKTOG.KTOG: MIN	Duration or N6.x		Minimum limit	For time accounts the minimum limit is entered as duration and as decimal number for daily accounts. The maximum number of decimal places results from the configuration of accounts.
PZEKTOG.LART: MIN	C4		Minimum wage type	Wage type for the minimum limit
PZEKTOG.VERB: MOC	C1 (K/B/S)		Processing	"B" specifies that the record is processed as account limit. The entry 'S' is used to set the account balance. If "K" is set for processing, fixed amounts can be posted to (or deducted from) the account, irrespective of the account balance. The account balance that must be set and the fixed amount are stored in the field of the maximum limit value.

*1) Of the fields PZEKTOG.PNR, PZEKTOG.BZG and PZEKTOG.WERT, either the field PZEKTOG.PNR can be populated or the two other fields. All 3 fields can also be empty.

2.6.4 Assigning authorizations for PZE and ZKS terminals

You can use this dialog to assign clocking authorizations at PZE terminals and allow access at ZKS access points:

Dialog: ZBERECHT.INSERT				
Parameter	Type	Mandatory	Contents	Description
ZBERECHT.FIR	C4		Company	The person's company
ZBERECHT.PNR	N8	X	Personnel number	The person's personnel number
ZBERECHT.ART	C1	X	Type of authorization	PZE: 'T': Terminal 'G': Terminal group ZKS: 'Z': Access profile
ZBERECHT.NR	N4	X	Authorization number	Number of the terminal, terminal group or access profile
ZBERECHT.DATB	Date		Start date of the authorization	If this field remains empty, the validity start date for the authorization will not be restricted.
ZBERECHT.DATE	Date		End date for the authorization	If this field remains empty, the authorization has no end date and is unlimited.

All authorizations of a person are deleted using the dialog ZBERECHT.DELETE:

Dialog: ZBERECHT.DELETE				
Parameter	Type	Mandatory	Contents	Description
ZBERECHT.FIR	C4		Company	The person's company
ZBERECHT.PNR	N8	X	Personnel number	The person's personnel number
MOD	C1	X	Constant "MOD=G"	Delete all authorizations of the person.

The authorizations are transferred via initial download: all authorizations of a person are deleted and then completely inserted. To make sure that these modifications become active at the same time, use the line "DLG=WORK.BEGIN" to open a transaction before deleting the authorizations. After the last authorization, finish the transaction using the line "DLG=WORK.END". Create a transaction for each person so that it does not get too large.

2.7 Data collection for the incentive wage

2.7.1 List of bonus reasons (ZUSCHLGR.LIST)

You can use the dialog ZUSCHLGR.LIST to request a list of the bonus reasons configured in the system. The list includes all bonus reasons and does not have any selection criteria.

Example:

DLG=ZUSCHLGR.LIST|DATEI=../spool/zuschlgr.dat|DAT=10/23/2017|ZEI=40000|USR=2209|

Dialog: ZUSCHLGR.LIST				
Parameter	Type	Mandatory	Contents	Description
ZUSCHLGR	N4	X	Reason	
BEZ	C40		Designation	
ASTUFE	C1		BDE authorization	
CERTIFY	C1		Authorization required	J/empty: bonus requires approval N: bonus does not require approval
VERBCERTIF	C1		Allocate if still requires approval	N: bonus is not allocated if still requires approval Other: bonus is used in the incentive wage calculation until it is rejected.
VAB	C15		Responsibility area	
BEARB	C10		Last modified by	
BEARBDAT	Date		Last modified on	
BEARBZEI	N5		Last modified on	
VERB	C1		Effect on target time/actual time	I: bonus has an effect on the actual time S/Other: bonus has an effect on the target time.
VERBKRI	C10		Posting indicator	Reserved for customer-specific functions

Example of a file that has been created:

```

ZUSCHLGR|VAB|BEZ|BEARB|BEARBDAT|BEARBZEI|VERB|ASTUFE|CERTIFY|VERBCERTIF|VERBKRIIT|
1||Maschinenstrung|@|10/23/2017|44650|S|3|J|N||
2||Materialmangel|@|10/23/2017|44650|S|3|J|N||
3||Transporteur fehlt|@|10/23/2017|44650|S|3|J|N||
10||Nacharbeit/allg.|@|10/23/2017|44650|I|3|J|N||
11||Nacharbeit/Entgraten|@|10/23/2017|44650|I|3|J|J||
12||Nacharbeit/Montage|@|10/23/2017|44650|I|3|J|N||
20||Langsamere Maschine|@|10/23/2017|44650|S|3|J|N||
30||Einrichter fehlt|@|10/23/2017|44650|S|3|J|N||
50||Einarbeitung|@|10/23/2017|44650|S|7|N|N||
55||Einarbeitung Mitarb.|@|10/23/2017|44650|S|7|N|N||
200||Werkzeugschaden|@|10/23/2017|44650|I|7|J|N||
500||Schnellere Maschine|@|10/23/2017|44650|S|3|J|N||
510||Einrichter Mitarbeit|@|10/23/2017|44650|S|3|J|N||

```

2.7.2 Recording of bonuses on the terminal (P_ZUSCHL)

You can use the dialog P_ZUSCHL to record bonuses.

Parameter

DLG=ZUSCHLGR.LIST|DATEI=./spool/zuschlgr.dat|DAT=10/23/2017|ZEI=40000|USR=2209|

Dialog: ZUSCHLGR.LIST				
Parameter	Type	Mandatory	Contents	Description
DAT	Date	X	Date	
ZEI	N5	X	Time	
ZUSCHLGR	N4	X	Bonus reason	
DAUER:STD or DAUER:MIN or DAUER:SEK	Decimal	*1)	Absolute duration of the bonus	Decimal with 2 decimal places. Optionally in hours with industrial minutes, minutes (60 per hour) or seconds.
DAUER.ANZ:STD or DAUER.ANZ:MIN or DAUER.ANZ:SEK	Decimal	*1)	Relative duration of the bonus	Relative duration of the bonus in combination with a quantity in DAUER.ANZ:ANZ in decimal format with 2 decimal places. Optionally in hours with industrial minutes, minutes (60 per hour) or seconds.
DAUER.ANZ:ANZ	Decimal	*1)	Quantity for the relative duration of the bonus.	Decimal with 2 decimal places in minutes (only in combination with DAUER.ANZ:*).)
ANR	C40	X *2)	HYDRA order number (fully defined key)	

KNR	C10	X *2)	Badge number	
LPGRP	C 8	*2)	Premium group •	
KNR:SIGN	C10		Badge number of person that approves	
VORMONAT	C1		Bonus must be booked to the previous month.	J: The bonus date is set to the last day of the previous month in parameter DAT.
BEM:1	C 50		Comment 1	Requirements: *3)
BEM:2 ... BEM:5	C 50		Comments 2 to 5	Requirements: *4)
FU:01 ... FU:02	Date		User fields date	Requirements: *3)
FU:03 ... FU:06	N		User fields integer	Requirements: *3)
FU:07 ... FU:08	Decimal		User fields decimal	Requirements: *3)
FU:09	C20		User field text	Requirements: *3)
FU:10	C40		User field text	Requirements: *3)

If the badge number is only entered via bar code, the field must be configured in the field configuration with "field attribute 1" = MANUELL and "field attribute 2" = READONLY.

*1) Recording of the bonus value

The bonus value is saved in HYDRA in date format "hours" with industrial minutes. In some cases, values of other units are recorded for bonuses, e.g. "piece". Internally, the date format "hours" is always used.

Two options are available:

1. Collection of an absolute value with a parameter DAUER:*

The value can be collected directly. With parameter DAUER:MIN, the value is divided by 60 to get hours before being saved. With parameter DAUER:SEK, the value is divided by 3600 to get hours before being saved.

2. You use the parameters DAUER.ANZ:ANZ and DAUER.ANZ:STD/MIN/SEK to collect a relative value as time per piece.

Using the combination of the above parameters, you can record the bonus as "x seconds per piece", for example. You then use the number of pieces and the relative bonus to automatically calculate and save an absolute bonus.

You can record the value either as absolute or as relative bonus.

***2) Assigning the bonus**

You can record a bonus for a premium group (group incentives) or a single person (individual piecework or individual bonus). The following rules apply:

1. You must enter the person (KNR) and the order (ANR). Only then, the system can perform the validation check and assign the bonus of a concrete order processing to a person.
2. If a premium group was collected via LPGRP, the bonus is collected as group incentives. If the bonus is collected as group incentives, the staff badge number and the order are entered to document the context. By default, person and order are not relevant in the processing of the group incentives.

***3) Requirements of comment 1 and user fields**

The parameter BEM:1 and the user fields are only available as of program version hymwll71.dll 8.1.1.19 (November/2017, SP12). A customer-specific extension must be installed.

***3) Requirements of comment 2 to 5**

For the parameters BEM:2 to BEM:5, you require the program version hymwll71.dll 8.1.1.19 (November/2017, SP12). A customer-specific extension with database patch must be installed and authorized.

Example

DLG=P_ZUSCHL|DAT=10/24/2017|ZEI=44280|KNR=4125|ANR=4000LL100090|ZUSCHLGR=55|DAUER:STD=3.75|USR=2209|

Validation checks

- The order must exist.
- The person must exist. The person must have at least the BDE authorization level that is stored for the bonus. If no authorization level is stored for the bonus, the person must have at least level 3. This guarantees that only persons with special authorizations can enter bonuses. If the parameter KNR:SIGN is used to record the staff badge number of the person authorizing the bonus, their BDE authorization level is checked.

- If the premium group is specified in the dialog, the group must exist.
- You can record the value either as absolute or as relative bonus. If the three parameters for absolute bonus, quantity and relative bonus include a value that is not 0, the terminal issues an error message with the posting.
- The bonus reason must exist.

Processing

The editing date of the bonus always includes the time of recording. If the bonus is recorded on a terminal, "T<terminal number>" is entered for *Modified by* with the bonus.

The bonus requires approval if configured accordingly in the bonus configuration.

If a person approving the bonus is recorded with parameter KNR:SIGN, their personnel number is saved in field "Authorization" of the bonus.