

Manual

Integrated HR Master SIS-IPS 4.0pe

Version 1.1.23347

Last changed on: 22 September 2020

Copyright

©Copyright 2020 All rights reserved.

SAP® and R/3® are registered trademarks of SAP AG.

WINDOWS® is a registered trademark of Microsoft Corporation.

MPDV® and HYDRA® are registered trademarks of MPDV Mikrolab GmbH.

ORACLE® is a registered trademark of ORACLE Corporation, California, USA.

Copying and distribution of this documentation or any part thereof, for any purpose or in any form, is prohibited without prior written permission from MPDV Mikrolab GmbH.

The information contained in this documentation is subject to change without prior notice.

Contents

1	Integrated HR Master - Overview.....	4
2	HR Master Data	5
3	HR Master Changes.....	23

1 Integrated HR Master - Overview

Purpose

Integrated HR master for recording staff with settings for different applications (labor time management, shop floor data collection, quality management, ...)

Implementation considerations

You use the function package if:

- You intend to use HYDRA products for whom employees have to be recorded.

Integration

Persons entered in the HR master are also required in many other function packages.

Features

- HR Master
 - Maintenance of persons with validity period (HR master with revision index option)
 - Allocation of a photograph to the employee
 - Print of labor lists with free selection of fields to be printed
 - Allocation of persons to responsibilities to control which users have access to and may maintain employees and their data.
 - Comfortable maintenance function for several persons and groups of persons
- HR master changes
 - Recording and listing of HR master changes

2 HR Master Data

Overview

	→	
HYDRA menu	Master data → Staff → HR master data	
FEDRA menu	Detailed scheduling → Master data → HR master data	
Transaction code	pers	
Function authorization	pers	

Available user fields		
Where?	Object type/user field key	Source (type)
Table and detail view	PNR/SYSTEM	HR master data (HR)
How to configure user fields? Which user field types are available?		

The application *HR master data* manages the persons' master data. These persons are employees of the company or involved in the company's processes (e.g. temporary workers). The displayed data and available editing options may vary and depend on the used products and the user's authorizations.

Purpose

You must create the relevant employees in the system, e.g. for time & attendance functions, for staff postings in BDE (applies only when using HYDRA) and other activities where a person needs to be assigned (e.g. entry of the malfunction reason at a machine).

You can store a person several times with different validity periods. Use this option to make changes to persons and to keep the previous version up to a specific date. For example, you can use this function if a person changes the department or cost center. The product groups PZE and LLE (applies only when using HYDRA) consistently work with the HR master managed in versions. These product groups use the HR master version valid for the day in question for retrospective calculations, evaluations and planning. Other product groups always access the person's currently valid version (i.e. today's valid version).

Other applications also access the *HR master data* to select the appropriate person if you enter a personnel number in the application's search field *personnel number*. If a user does not have the function authorizations **pers** and/or **pers.view**, all HR master data fields are hidden. Except for the following fields: *person*, *valid from*, *valid until*, *staff badge*, *title*, *first name*, *middle name*, *last name*, *company*, *area*, *cost center*, *department*, *supervisor*, *name (supervisor)* and the additional information fields. The application does not automatically hide the fields in the additional information tab, as you can use the [configuration of HR master data fields](#) to specify which fields should be visible or not.

In the HR master, you can also use function authorizations to specify the **tabs** the user may view or edit. Example: production supervisors can view and/or change the settings of the shop floor data tab. However, they cannot change the other tabs. Click [here](#) to find further information on this processing and the required configuration.

To prevent the *HR master data* from being printed or exported to Excel, you can disable these functions in the application [Function authorization](#). The [Function authorization](#) *pers_disexp* disables the export and copy function (CTRL+C) and *pers_disprt* disables the print function.

Integration

Synchronization of ZKS badges with HR master data

If you change data of ZKS badges, the system synchronizes specific data with the HR master:

- Company
- Last name and first name
- PIN code
- Image
- Additional information (configured HR master fields and badge fields)

The additional information must have the same:
 - designation/name
 - data type and
 - field length
 in the [configuration of HR master data and badge fields](#) in order to be synchronized.

The system only synchronizes changes to active employee identification badges with the HR master data. These changes apply from the current date or in the future. Synchronization affects all HR master data versions that are currently valid and will be valid in the future if the validity periods of badge and master data version coincide. The synchronization process does not create new HR master data versions.

If you change HR master data, the system also synchronizes specific data fields with ZKS badge fields. For further details on this, refer to the documentation dealing with badges.

Requirements

When editing and displaying HR master data, the system checks whether a client user is authorized for a person. If the person the user wants to change is assigned to a responsibility area, the system checks if the user is authorized for this responsibility area.

Selection criteria

The documentation [Advanced personnel selection](#) describes the selection criteria.

Field descriptions of the *Person* tab

This tab shows general data relating to the person/employee. The personnel number and/or badge number identify every person. The latter is used for the bookings on the BDE or PZE terminal (applies only when using HYDRA).

Person

Personnel number that uniquely identifies the person.

Valid from, until

Validity period of the person. You can only enter values in the field *Valid from* if you create or copy a person. If other, future versions of the person are available, the validity end date is automatically populated, otherwise the field remains empty.



If you add a new person, you should not change the entry "1 January 1900" in the *valid from* field. The field *date of joining* includes the person's entry date. If the *valid from* date is in the future, the person's clocking authorizations are only shown once the validity start date has been reached.

Badge

Number of the company ID card. This number has to be unique for all persons. Numerical and hexadecimal badge numbers (characters 0-9 and A-F) are supported. The staff badge no. field may be empty.

You can reassign badges of employees who have left the company. If you assign such a badge number to a new person, the *staff badge no.* field of the person who left the company is emptied automatically. A person has left the company if the date of leaving ("employed till" field) lies in the past in all HR master versions.

If you want to read in the badge numbers as a barcode via a shop floor client (e.g. AIP), you can find the respective configurations in this [document](#).

Production employee

Use the option *Production employee* to identify production staff.

Salutation

Salutation of the person (e.g. Mr., Ms.)

Title, First name, Last name

Contains the person's academic title, first name, middle name and last name.

Acronyms

Initials of the person. You can assign internal initials to a person.

Company

Use this field to assign the person to a company. Entries in this field are required (mandatory field).

Area

Use this field to assign the person to an area. You can use the area field to group persons. These groups can span multiple cost centers and are used as a selection criterion in evaluations and lists in the HYDRA Time & Attendance (PZE) module. Entries in this field are required (mandatory field).

Cost center

The person's standard cost center is also a mandatory field.

Department, employee subgroup

These dropdown boxes provide further options for classifying the employee hierarchically. You can show both of these fields in a variety of lists and evaluations/reports of the product group Time and Attendance (PZE).

Activity

Brief description of the employee's function in the company.

Responsibility area

Enter a responsibility area to restrict the MOC users who can access the employee's data.



You can also leave the responsibility area field empty. If the responsibility area field is empty, no authorization check takes place and all users can view the employee's data.

Date of joining, date of leaving

Contains the date the employee joined or left the company. Both fields are included in data selection. If the date of joining refers to a date in the future or the date of leaving refers to a date in the past, the employee is *inactive*.

Supervisor

Enter the supervisor's company and personnel number to assign the employee to a supervisor. If the supervisor is defined as a recipient in the escalation management, they can be notified according to the configuration.

Replacement 1

Assign the first person replacing the supervisor. Use this field to specify the person that replaces the supervisor in cases of absence. If a [replacement](#) is required, this field will be used for the absence workflow. Specify the replacement of the supervisor in the replacement's personnel data and not in the supervisor's data. Therefore, you can specify different replacements for different employees.

Replacement 2

Assign the second person replacing the supervisor. Use this field to specify the person that replaces the supervisor and the first replacement in cases of absence. If a [replacement](#) is required, this field will be used for the absence workflow. Specify the replacement of the supervisor in the replacement's personnel data and not in the supervisor's data. Therefore, you can specify different replacements for different employees.

Field descriptions of the *Personal data* tab

Use the fields of the *personal data* tab to store personal data. These entries (with few exceptions) are for information purposes only.

Nationality

Shows the employee's country code, e.g. US, GB, F, HU, D, CH, A, NL, etc. You can assign any values in the field *nationality*. The system does not validate these entries.

Date of birth

Shows the employee's date of birth.

Gender

Use the radio button to assign the employee's gender. As of service pack 16, you can select the options *Gender-neutral* and *Not defined*. The default value will be *Not defined* instead of *Male* as of service pack 16. If you do not want to use the field, you can leave it at *Not defined*.

Place of birth

Shows the employee's place of birth.

School-leaving qualification

Use this field to assign the employee's school-leaving qualification.

Secondary school-leaving qualification

Use this field to assign the employee's secondary school-leaving qualification.

Family status

Use the radio buttons to assign the employee's marital status. The "Not defined" option is available as of Service Pack 16. The default value will be *Not defined* instead of *Single* as of service pack 16. If you do not want to use the field, you can leave it at *Not defined*.

Standard console

Currently not processed

PIN code, confirmation

Shows the PIN code, which the employee uses as a password to log in to the HR self-service in the Internet or Intranet, for example to enter clocking in or out times or to submit applications for leave of absence. Since the PIN code is not displayed legibly, you have to enter the code a second time for confirmation. If you use the ZKS product group (access control) and you change the PIN code in the HR master data, the system automatically changes the employee's badge, provided that the PIN code in the badge matches the previous PIN code in the HR master data.



If you use the PIN code and dormakaba devices for access control, the PIN code must consist of four digits.

Street, ZIP code, residence

Shows the employee's address.

Company phone, Private phone

Shows the employee's business and private phone numbers.

Company mobile

Shows the employee's business mobile number. If the employee is registered as a recipient in the escalation management and if messages are sent by SMS, these text messages will be sent to the number entered in this field.

Private mobile

The employee's private mobile number.

Company e-mail

Shows the employee's business e-mail address. If the employee is registered as a recipient in the escalation management and if messages are sent by e-mail, the e-mails will be sent to this address.

Private e-mail

The employee's private e-mail address.

Field descriptions of the *Shop floor data* tab**Employee group**

Enter group numbers to assign employees to specific groups. This is a comment field.

Year model

This entry is relevant if the option "Synchronize labor utilization with the person's BDE shift model" is enabled in the [Basic settings](#) or waiting period processing is activated. This data field includes the year model that is used to calculate times.

Example for waiting period posting: If the person clocks in at 6:00 a.m. but doesn't log on to the machine and the OP until 7:00 a.m., then the time between 6:00 a.m. and 7:00 a.m. will be compared to the shift model and posted to the relevant waiting period OP. In this case, a comparison means that the time difference is posted to the corresponding waiting period OP.

Workplace

Shows the employee's regular workplace. This is a machine-related workplace as defined in the configuration of machines/workplaces. If waiting period processing is active, this entry is also entered in the waiting period posting generated by the system in the BDE product group (shop floor data collection).

Please note:

Do not configure the workplace as a group workplace because otherwise, the machine list (with all logged on persons) shows this workplace for all terminals where staff was logged off and logged on to the waiting period OP.

Waiting period OP

The waiting period is posted to the operation specified. If you do not enter a waiting period OP, the system uses the default waiting period OP, as entered in the HYDRA basic settings.

Please note:

Define waiting period OPs as personal overheads (order type GKP) because waiting period operations are not posted explicitly and do not always need to be uploaded to the ERP system. You cannot assign other types of operations.

Log on to several workplaces

When a person logs on to a machine/workplace, the system checks whether this person is already logged on to another machine/workplace.

If this checkbox is enabled, then the person is allowed to log on to multiple machines/workplaces simultaneously. Otherwise, the second login attempt is denied and the terminal shows an error message.

Automatic OP change

If this checkbox is selected, the person is automatically logged off from the current OP if they log on to another machine or workplace.

If persons are logged on to a group workplace, an overhead cost order, or a merged OP relating to the person, the system also interrupts the operation, since the person is directly connected to the operation.

Restriction

→ If individual workplaces are assigned to terminals which are configured to send combined OP/user postings (Terminals > Dialog control > Log person on with order) and you log on an additional operation to the same machine, the person will not be logged off automatically from the current operation.

Note

- Select the *Log on to several workplaces* checkbox to enable the above-described procedure.
- Operations are not changed automatically, if staff is logged on automatically, e.g. due to a changed machine status, the change of shifts, etc.

Check whether person is logged on

If you select this option, the system checks whether the person who interrupts, logs off the order or reports part quantities for the order is actually logged on to the operation.

Target quantity check

Use this option to specify if you want to check the target quantity when you post quantities manually onto an operation.

1 No check.

2° Log off order: If you log off an order, the system checks whether the current yield coincides with the specified minimum and maximum target quantity (see below).

3 Order interruption/logoff/partial confirmation (reporting part quantities): the system checks all posted quantities for overdelivery and, on logging off an operation, an underdelivery check is also carried out.

Please

note:

In general only yield is checked.

The limit values for overdelivery and underdelivery defined in the operation data do not affect this and are checked separately, if they are set. If this is true, the system first checks

- the above-mentioned personnel-related target quantities and then
- the operation-related target quantities including the overdelivery and underdelivery quantities defined for the operation.



For further information on overdelivery/underdelivery checking, see the document entitled [MBL_PC_UnderOverDeliveryOverview.pdf](#).

Minimum target quantity in %

If the system checks the target quantity, you have to define here the minimum quantity, as a percentage of the target quantity ($\leq 100\%$) that must be reached before you can log off an operation.

Maximum target quantity in %

Enter the maximum quantity to be produced, as percentage of the target quantity ($\geq 100\%$).

Max. OPs per person

Enter the maximum number of operations that a person can log on to.

Please note:

This setting is also relevant when it comes to the creation of merged operations on the terminal.

Automatic logoff of personnel when shift ends

This option only takes effect for the automatic shift change if the following conditions are met:

- the person is logged on to an operation where the option "automatically log off person when shift ends" is set to "X - use workplace settings" and
- the person including OP is logged on to a workstation where the option "automatically log off person when shift ends" is set to "X - use the person's settings".

Use this option to configure personnel-related data collection at machine data collection (MDE) workstations. When using the MDE (only applies when using HYDRA), fully automatic shift closings are generated via the terminals. Therefore, it can be set here whether the person logged on at the workstation is automatically logged off at the end of the shift or should remain logged on.

Lock person (BDE)

If you enable this option, the person is no longer allowed to post data (e.g. order postings, personnel postings). Requirement: The person who performs the posting needs to enter their personal badge number in the posting dialog.

BDE postings

Authorization level required to log on orders.

The employee's authorization level must be higher than or equal to the operation's authorization level in order to log on, log off or interrupt an operation. The plausibility check is performed on the system server.



HYDRA waiting period processing only integrates users whose authorization level for *OP postings* is greater than 0. This is particularly important if shop floor data collection HYDRA BDE and time & attendance PZE are used simultaneously as both modules refer to the same HR master data. Therefore, enter the value "0" in this field for employees who do not perform BDE postings (e.g. administrative staff).

Log OP on

Uncheck this option and the person will no longer be allowed to log on operations. This setting does not depend on the authorization level.

Log OP off

Uncheck this option and the person will no longer be allowed to log off operations. This setting does not depend on the authorization level.

If you disable both options *log on OP* and *log off OP*, the person is only able to report part quantities for operations and to interrupt operations.

Log off all staff

Use this option to specify whether the user is allowed to use the terminal function "Log off everyone" of the Windows AIP terminal.

Change target quantity

If this option is selected, the user is allowed to change an operation's target quantity via the terminal. The plausibility check is performed on the system server.

MDE authorization

Use this setting to specify the authorization level required for changing statuses via the terminal.

The value entered here must be higher than or equal to the value entered in the "Authorization level" field of the status you want to assign. The plausibility check is performed on the system server.

Change only if person is logged on

Use this option to specify that the employee is only allowed to change a status if the employee is logged on to the relevant workplace/machine.

Change cycle/partitioning

If this option is selected, the employee is authorized to modify the *Cycle* and *Partitioning* (parts per cycle) for an order via the terminal. The plausibility check is performed on the system server.

Change production lock

This option is only important if the dynamic dialog "production lock" (M_PSPERRE) is activated in the Windows AIP terminal and this dialog includes the staff badge no. field. In this case, the employee is only allowed to activate or deactivate the production lock manually if they are authorized respectively, i.e. if this option is set.



This option is not effective if the production lock is set automatically along with setting a status.

Enable the dynamic dialog "production lock" (M_PSPERRE) in the dynamic dialog configuration.

Status change of resources

Use this setting to specify the authorization level required for changing resource statuses.

This authorization can only be used in conjunction with the "Tool and Resource Management" (WRM) module.

Reset maintenance

If this option is set, the person at the Windows terminal AIP can reset a maintenance using the WRM function "Maintenance" (applies only when using HYDRA).

As of service pack 16/2020:

You can use the authorization level to specify the maintenances a person is allowed to reset.

A person can reset a maintenance if the following conditions are fulfilled:

- The option (checkbox) Reset maintenances is enabled;
- An authorization level is entered;
- The authorization level is greater than or equal to the authorization level (entered in the field [Authorization](#)) of the maintenance.

The plausibility check is performed online on the system server. The system only checks the authorizations if a staff badge number is entered in the AIP input dialog.

If no authorization level is entered, the employee can reset every maintenance, irrespective of the authorization level that is assigned to the maintenance (downward compatibility).

Enter measures

If this option is set, the employee can use the function "resource comments" to enter a comment/measure via the Windows CTWIN/AIP terminal.

Installing/removing resources (WRM maintenance messages)

Reserved

DNC download authorization

This option allows the employee to download a DNC program via the HYDRA terminal.

This option can only be used in conjunction with the DNC module.

DNC upload authorization

This option allows the employee to upload a DNC program via the HYDRA terminal.

This option can only be used in conjunction with the DNC module.

DNC release authorization

Authorization to release a blocked DNC program via the HYDRA terminal.

This option can only be used in conjunction with the DNC module.

Field descriptions of the *Incentive wage* tab

This tab includes fields for the calculation of incentive wages (LLE). If you do not use the incentive wage module, you can leave all fields at their respective default values.

Premium indicator

Leave this field empty, if you do not use the incentive wage module.

This field defines the type of calculation used for incentive wages. You can specify the meaning of this option according to your requirements while implementing the incentive wage module and customizing the system.

Refer to your customer documentation for further information on the options applicable to your system.

To customize the LLE module, use the "incentive wage indicator" as a selection criterion for the *wage type determination* to calculate incentive wages. In this case, you can specify if an employee works for a piece rate or group incentives.

Premium group •

The premium group used for group calculation in the HYDRA incentive wage module. This option is not used by default. Reserved for future use.

Premium factor

Reserved for future use.

Operator position/function

If this field includes a value, the employee is logged on with the operator function defined in this field, provided that no operator function is transferred in the login dialog. Once the employee has been logged off, the operator function is stored in the log record, record type "B".

Wage/premium indicator

If this field includes a value, the employee is logged in with the wage/premium indicator that is defined in this field, provided that no wage/premium indicator is transferred in the login dialog. The wage/premium indicator is stored in the BDE log record (record type B), once the employee has been logged off.

Wage type

You can assign this wage type to the time tickets using the wage type determination.

Wage group

Reserved for future use.

BDE/PZE comparison

Reserved for future use.

Field descriptions of the *Time and labor data* tab

Models

Assign a working time model and a payment model to each employee. Shift workers also require a shift rhythm model. This model specifies which of the possible shifts of the shift day type apply to that employee. The payment model defines the pay which applies to that employee.

Working time model

The working time model which applies to the employee. The working time model can include flextime and shift day types.

Shift rhythm model

The shift rhythm model that specifies the sequence of shift types for a shift worker (or employee with flexible shift time).

Payment model

The payment model defines which payment day type applies on which day. The payment day type defined in this model takes precedence over the payment day type defined in the working time day type .

Overtime type

Number of the payment day type that specifies how to set overtime off against undertime.

Employment relationship

This field specifies whether the employee in question is a salaried employee or not. This setting does not affect data processing. However, you can use the field to select employees.

Average working time

The average working time per day entered here, rather than the planned working time, is set off in the event of absence (holiday, sickness, etc.), provided that

- the *Allocate average working time* checkbox (see below) is selected, or
- the corresponding setting is selected for the absence planning.

Part-time rate

Use the percentage entered here as the multiplication factor for the target time of the working time model. The calculated target time is rounded to the nearest full minute. You can use this percentage to manage part-time employees without having to create a separate model for each target time.

First allocation

Shows the date that this employee was (or will be) first evaluated. If nothing is entered here, the employee will be evaluated from the date they join the company.

Date of latest evaluation

This field shows the date when the employee was last evaluated.

Time sheet

Number of the time sheet for HYDRA@Web.

Leave entitlement

Use the HR master fields or configure the [leave entitlement](#) to define the leave entitlement. If you define the leave entitlement in the separate configuration dialog, the system automatically assigns the leave entitlement applicable for the relevant year to the HR master fields when posting the leave entitlement on January 1st.

The sum of the fields *Annual leave*, *Special leave* and *Additional leave* will be assigned to the leave account (4th account in the [Configuration of Accounts](#)) on 1st January. If an employee joins the company during the course of the year, enter the leave entitlement valid from the next year on in these fields. You can store the leave entitlement for the remainder of the current year when you edit accounts.

Any changes made to the annual leave entitlement that is entered in *Annual leave*, *Special leave* and *Additional leave* only take effect if the work day evaluation is performed on January 1st.



Enter the leave entitlement with a maximum of one decimal place, regardless of whether the leave account is kept as day account or time account.

Business trip authorization

For terminals of type CT-38x (and for combined BDE and PZE terminals with the program AIP or CT-WIN) the *Business trip authorization* controls whether the employee is allowed to use the *1st. Absence reason key* on the terminal (only applies if HYDRA is used).

Lock person

If this checkbox is selected, then this employee will no longer be processed by [labor time calculation](#) and has no longer an [clocking authorization](#) at time & attendance terminals. In addition, locked employees are neither evaluated in the personnel time management module (PZW) nor in personnel scheduling (PEP) - only applies if using HYDRA.

Person does not clock

If this option is set, the message "unplanned absence" is neither generated nor displayed in the messages listing. During the frame working time, the attendance overview shows such employees with the status "Person does not clock" if they are absent and no absence is planned for them.

Allocate average working time

If this checkbox is selected, all periods of absence are set off against the time entered in *average working time*.

Field descriptions of the *Additional information* tab

The Additional info tab can include up to 30 customer-specific fields. You can configure the label and data type for each of the fields individually. For further information please refer to the document dealing with the [configuration of HR master data and badge fields](#).

Editing functions



Copy all selected staff

Use this function to create a new version for several employees at once and to change up to 10 HR master fields in this new version:



You need the function authorization **pemm** to copy multiple employees at once.

The system always copies the person's version that is valid at the *valid from date* you entered. In this case, it does not play a role which version of the person you've selected in the HR

master. The system only uses the personnel number of this selected data record.



This function is only available if you enable the extension [PersonsMassCopy](#).



Edit all selected staff

Use this function to change HR master data for several employees at the same time. You can select up to 10 fields and assign a value:



You need the function authorization **pemm** to edit multiple employees at once.



Modify image

You can assign an image to the employee in the HR master data.

Toolbar



Clocking authorizations

Calls the [Clocking authorizations](#).



Access authorizations

Calls the [Access authorizations](#).



Current account balances

Calls the application [Current account balances](#).

Print staff badges



You need the function authorization **pepb** to print (pepb.print) and design (pepb.layout) staff badges.



Print staff badges

A window opens to [print staff badges](#) for the employees selected in the HR master data.



Report designer

A separate document describes how to [design staff badges](#).

Checking Business Parameter Containers (BSCs)

See [here](#) for further details on how to check the system against business parameters.

3 HR Master Changes

Overview

Menu	Master data → Individuals → HR master changes
Transaction code	pecl
Function authorization	pecl

This list is used to document all changes regarding individuals. This allows the staff in charge to trace employee data processing for an extended period.

Comp...	Person	Name	Valid from	Valid until	Status	Modified by	Modified on
BSP	50014	Albert, Claudia	1/1/1900		Created	12345	2/24/2011 10:45:58 AM
BSP	96665	Haus, Harald	1/1/1900		Created	12345	2/24/2011 10:51:50 AM
0001	10002541	Berry, Claire	1/1/1900		Created	12345	2/24/2011 10:56:37 AM
0001	10003645	Hoffman, Paul	1/1/1900		Created	12345	2/24/2011 11:03:03 AM
BSP	85741	Meyers, Joseph	1/1/1900		Modified	12345	2/24/2011 11:46:54 AM
BSP	85741	Meyers, Joseph	1/1/1900		Modified	12345	3/1/2011 9:29:32 AM

Field	Old value	New value
Working time model	0	140
Payment model	0	100
Overtime type	0	900

Comp...	Person	Name	Valid from	Valid until	Status	Modified by	Modified on
BSP	85741	Meyers, Joseph	1/1/1900		Modified	12345	3/1/2011 9:33:43 AM
BSP	885	Burger, Simone	1/1/1900		Created	12345	3/1/2011 10:32:23 AM
BSP	667	Schulz, Christine	1/1/1900		Modified	12345	3/2/2011 10:04:29 AM
BSP	96665	Haus, Harald	1/1/1900		Modified	12345	3/3/2011 9:13:30 AM
BSP	50014	Albert, Claudia	1/1/1900		Modified	12345	3/3/2011 9:22:03 AM
0001	10003645	Hoffman, Paul	1/1/1900		Modified	12345	3/3/2011 9:23:39 AM
0001	10002541	Berry, Claire	1/1/1900		Modified	12345	3/3/2011 9:24:58 AM
BSP	85741	Meyers, Joseph	1/1/1900		Modified	12345	3/3/2011 9:27:01 AM
0001	10003645	Hoffman, Paul	1/1/1900		Modified	12345	3/4/2011 11:05:08 AM

The list indicates a line with changes in personal data and the date of processing for each change.



Display of changed data

By clicking on the '+' and/ '-' button at the beginning of each line, a table showing the changed HR master fields will be opened and/or closed.