

Manual

SMA-AMF: SMA Posting Functions in Production SMA-AMF 8.1

Version 1.0.23049

Last changed on: 02.09.2020

Copyright

©Copyright 2020 All rights reserved.

SAP® and R/3® are registered trademarks of SAP AG.

WINDOWS® is a registered trademark of Microsoft Corporation.

MPDV® and HYDRA® are registered trademarks of MPDV Mikrolab GmbH.

ORACLE® is a registered trademark of ORACLE Corporation, California, USA.

Copying and distribution of this documentation or any part thereof, for any purpose or in any form, is prohibited without prior written permission from MPDV Mikrolab GmbH.

The information contained in this documentation is subject to change without prior notice.

Contents

1	SMA Posting Functions in Production.....	4
1.1	General	4

1 SMA Posting Functions in Production

1.1 General

By default, the package "SMA posting functions in production" includes the following posting functions:

- Change status
- Log on operation
- Log off operation
- Interrupt operation
- Partial confirmation/report partial quantities
- Change partitioning



If you use a mobile data collection with MDE, we recommend to use a centralized MDE to ensure a quick communication for the relevant machine.

-

Change status

Function authorization	sma.setstatus
------------------------	---------------

The function enables you to change the status of the selected machine via a dialog. A list of the possible machine statuses is provided for selection.

Please note: This function is part of the package SMA-AMF.

The following fields are available in the function "Change status":

Machine status

The user is shown a list of the available machine statuses and can select a new status from this list.

Log on operation

Function authorization	sma.logon
------------------------	-----------

The posting dialog "Log on operation" can be used to log on an operation to the currently selected workplace. The operation (MES order number) and the status of the machine can be selected from a list via a search dialog.

Please note: All standard validation checks of HYDRA are run through.

Please note: This function is part of the package SMA-AMF.

The following fields are available in the function "Log on operation":

Workplace

The selected workplace is accepted. But you can still modify it manually.

MES order number

You can enter the number manually or you can select the operation by using the magnifier.

Status

The user is shown a list of the available machine statuses and can select a new status from this list.

The following functions are available via the buttons:



Closes the dialog without saving



Returns to the previous input field



Moves to the next input field



Logs on the operation

Log off operation

Function authorization	sma.logoff
------------------------	------------

The posting dialog "Log off operation" can be used to interrupt an operation at the currently selected workplace.

With regard to the logoff, you can enter the operation number (MES order number), yield and scrap quantities, the associated scrap reason and a new status for the machine in the posting dialog. The MES order number, the scrap reason and the status of the machine can be selected from a list via a search dialog.

Please note: All standard validation checks of HYDRA are run through.

Please note: This function is part of the package SMA-AMF.

The following fields are available in the function "Log off operation":

Workplace

The selected workplace is accepted.

MES order number

The indicated operation is accepted in the posting function. You can enter the number manually or you can select an operation by using the magnifier if several operations are logged on to the machine.

Yield

Input field for produced yield quantities in the relevant unit

Scrap

Input field for produced scrap quantities in the relevant unit

Scrap reason

Entry of a scrap reason. The magnifier can be used to select a scrap reason.

Machine status

The user is shown a list of the available machine statuses and can select a new status from this list.

The following functions are available via the buttons:



Closes the dialog without saving



Returns to the previous input field



Moves to the next input field



Logs off the operation.

Interrupt operation

Function authorization	sma.interrupt
------------------------	---------------

The posting dialog "Interrupt operation" can be used to interrupt an operation at the currently selected workplace.

With regard to the interruption, you can enter the operation number (MES order number), yield and scrap quantities, the associated scrap reason and a new status for the machine in the posting dialog. The MES order number, the scrap reason and the status of the machine can be selected from a list via a search dialog.

Please note: All standard validation checks of HYDRA are run through.

Please note: This function is part of the package SMA-AMF.

The following fields are available in the function "Interrupt operation":

Workplace

The selected workplace is accepted.

MES order number

The indicated operation is accepted in the posting function. You can enter the number manually or you can select an operation by using the magnifier if several operations are logged on to the machine.

Yield

Input field for produced yield quantities in the relevant unit

Scrap

Input field for produced scrap quantities in the relevant unit

Scrap reason

Entry of a scrap reason. The magnifier can be used to select a scrap reason.

Machine status

The user is shown a list of the available machine statuses and can select a new status from this list.

The following functions are available via the buttons:



Closes the dialog without saving



Returns to the previous input field



Moves to the next input field

 Unterbrechen

Interrupts the operation

Partial confirmation (report partial quantities)

Function authorization	sma.partialconf
------------------------	-----------------

The posting dialog "Partial confirmation" can be used to post quantities to an operation logged on at the currently selected workplace.

With regard to the partial confirmation, you can enter the operation number (MES order number), yield and scrap quantities and the associated scrap reason in the posting dialog. The MES order number and the scrap reason of the posting can be selected from a list via a search dialog.

Please note: All standard validation checks of HYDRA are run through.

Please note: This function is part of the package SMA-AMF.

The following fields are available in the function "Partial confirmation":

Workplace

The selected workplace is accepted.

MES order number

The indicated operation is accepted in the posting function. You can enter the number manually or you can select an operation by using the magnifier if several operations are logged on to the machine.

Yield

Input field for produced yield quantities in the relevant unit


Scrap

Input field for produced scrap quantities in the relevant unit

Scrap reason

Entry of a scrap reason. The magnifier can be used to select a scrap reason.

The following functions are available via the buttons:

 Abbrechen


Closes the dialog without saving



Returns to the previous input field



Moves to the next input field



Operation is partially confirmed (report partial quantities).

Change partitioning

Function authorization	sma.partition
------------------------	---------------

The posting dialog "Change partitioning" can be used to change the current partitioning for data collection at the currently selected workplace.

The operation number (MES order number) and the new partitioning can be entered in the posting dialog.

The MES order number can be selected from the list of logged on operations via a search dialog.

Please note: All standard validation checks of HYDRA are run through.

Please note: This function is part of the package SMA-AMF.

The following fields are available in the function "Change partitioning":

Workplace

The selected workplace is accepted.

MES order number

The indicated operation is accepted in the posting function. You can enter the number manually or you can select an operation by using the magnifier if several operations are logged on to the machine.

Partitioning

Input field for the new partitioning used for data collection.

The following functions are available via the buttons:



Closes the dialog without saving



Returns to the previous input field



Moves to the next input field



Changes the partitioning of the operation.