

Manual

Time & Attendance with ST-300 TSW-ST 8.1

Version 1.0.23049

Last changed on: 02.09.2020

Copyright

©Copyright 2020 All rights reserved.

SAP® and R/3® are registered trademarks of SAP AG.

WINDOWS® is a registered trademark of Microsoft Corporation.

MPDV® and HYDRA® are registered trademarks of MPDV Mikrolab GmbH.

ORACLE® is a registered trademark of ORACLE Corporation, California, USA.

Copying and distribution of this documentation or any part thereof, for any purpose or in any form, is prohibited without prior written permission from MPDV Mikrolab GmbH.

The information contained in this documentation is subject to change without prior notice.

Contents

1	Time & Attendance with ST-300	4
2	Time and Attendance with ST-300	5
2.1	Operation of the PZE terminal	5
2.2	Auto-Status	6
2.3	Absence reason clocking.....	6
2.4	Display of account balance information	7
2.5	Error messages.....	8
2.6	Terminal status display.....	8
3	Commissioning of ST-300.....	9
3.1	Terminal configuration.....	9
3.2	Versions	9

1 Time & Attendance with ST-300

Purpose

The terminal software included in this function package allows for recording In, Out and Break clockings as well as the recording of absence reasons for late In, early Out or working time interruptions with the time recording terminal type ST-300. In addition to these recording functions, you can also view the account balances.

Implementation notes

You use the function package if you:

- wish to record the clocking times of your employees
- wish to record the absences of your employees
- wish to provide your employees with information on their account balances

Integration

Data recorded by means of this terminal software can be displayed and/or evaluated in the MOC in various applications.

Features

- Personnel time recording/Time & Attendance

2 Time and Attendance with ST-300

ST-300 (Subterminal 300) is used to record the personnel working time. In addition to recording the in, out and break times, information regarding current account balances may be displayed to the employees.



2.1 Operation of the PZE terminal

The clocking type is set by pressing the different keys (in, out, break or absence reason keys) on the PZE terminal. The currently active clocking type and/or function is indicated on the display by an appropriate text. An employee clocks by reviewing the terminal status first, confirming the relevant key (in, out, ...) and then holding his/her company badge in front of the reader. In addition, employees may view their account balances (e.g. flextime, flexible time, remaining leave, ...) by pressing the information key.

Before each clocking and/or activity, the user has to check whether the function to be performed is active. If this is not the case, the relevant function has to be activated by pressing the appropriate key.

Key	Function	Description
1	In	Start of working time
2	Break	Start or end of break
3	Out	End of working time

4-6, 8	Absence reasons	These keys provide for the option of recording a reason for late arrival or early leaving or working time interruptions (e.g. for business trips or visits to the doctor) by means of entering an absence reason.
0	Information	Display of account balances

The selected function is now performed by reading the badge.

After successful clocking, the activity performed and the badge number are indicated on the display.



Break clocking is not mandatory. If break times have been defined in the system, they are offset automatically.

2.2 Auto-Status

If the terminal was configured for the "Auto-Status" (AST) operating mode, the system automatically decides whether an In or an Out clocking is performed. If Auto-Status is active, the display indicates the text "Auto-Status".

Automatic status identification can be overridden by the employee explicitly pressing the In or Out key, if required.

2.3 Absence reason clocking

Postings for absence reasons, so-called advance clockings or subsequent clockings, may be made on the PZE terminal. The term "advance clocking" means that the absence reason is entered in advance of the actual time of absence. In the case of "subsequent clockings", the absence reason is only notified to the terminal after the actual time of absence.

For entering an absence reason, the keys with the numbers 4-6 and 8 are used.

Procedure for entering an absence reason

- Press one of the absence reason keys.
- Perform clocking using the company badge.

If the terminal was in "Auto-Status" before, HYDRA automatically decides whether the absence reason clocking is an advance or subsequent clocking. If the terminal was in the "In" status, a subsequent clocking is made; if the "Out" status was active, an advance clocking is made.

2.4 Display of account balance information

After pressing the information key and posting by using the company badge, the display indicates the account balances of the relevant person. If more than 2 accounts are active, the keys 7 and 9 may be used to scroll the list up and down.

Which time and/or day accounts are displayed on the terminal can be specified in the configuration of accounts in HYDRA.

2.5 Error messages

The following error messages may be displayed:

Message	Description
"Double clocking"	➔ The person attempted to clock the same function within 2 minutes. This check is only performed if no other employee has clocked in the meantime.
"No access authorization"	➔ The person has no access authorization on this terminal.
"No business trip authorization"	The person is not authorized to clock a business trip.

All other messages are displayed in the "general message line" on the bottom of the screen.

Other error messages are:

Message	Description
"Incorrect company number"	➔ No correct company badge.
"No memory space. No connection to the server"	➔ The local memory space for clocking is used up (in OFFLINE mode). If the connection to the server is interrupted, the terminal saves approx. 10000 clockings locally before this message is displayed.

2.6 Terminal status display

If the subterminal does not have any connection to the master terminal, the time in the display is indicated with an asterisk between the hours and the minutes.

3 Commissioning of ST-300

3.1 Terminal configuration

Subterminals of type ST-300 are connected to a master terminal of type CT-385 in the same way as access readers. This master terminal requires an entry with the *Access terminals* ("ZZG") operation mode in the [terminal configuration](#).

One entry per subterminal must also exist in the terminal configuration. Type 300 (ST-300) enables the fields *Master terminal* and *Reader* in the *Configuration* group of the *General* tab. The *Master terminal* field includes the terminal number of the master terminal, and the *Reader* field includes the reader number of the subterminal.

3.2 Versions

The new terminal type ST-300 is available in MOC from SP7. The master terminal requires the following versions:

- ctwin: ctwin.exe 7.2.7.81 (08.07.2015)
- AIP 8.1: ctaip.exe 2.0.3.53 (08.07.2015, pzezks72.dll 2.0.1.28)
- AIP 8.2: The connection of ST-300 does not depend on the version.

In all three cases, the driver plg_crypt.dll is required as from version 2.1.0.0.