

Manual

Cavity Management WRM-NST 8.1

Version 1.0.23049

Last changed on: 02.09.2020

Copyright

©Copyright 2020 All rights reserved.

SAP® and R/3® are registered trademarks of SAP AG.

WINDOWS® is a registered trademark of Microsoft Corporation.

MPDV® and HYDRA® are registered trademarks of MPDV Mikrolab GmbH.

ORACLE® is a registered trademark of ORACLE Corporation, California, USA.

Copying and distribution of this documentation or any part thereof, for any purpose or in any form, is prohibited without prior written permission from MPDV Mikrolab GmbH.

The information contained in this documentation is subject to change without prior notice.

Contents

1 Overview of Cavity Management	4
Cavity Assignment	5

1 Overview of Cavity Management

Overview

Purpose

This function package includes the graphic user interface (GUI) as well as services to define master data for cavity management. This package allows managing the partitioning of resources by managing single cavities. The partitioning of the resource is automatically calculated from the sum of currently released cavities.

Integration

Cavity Management allows managing cavities. A tool's cavities can be edited via the GUI. Individual cavities can also be released or blocked.

Functions

- The current partitioning of the resource is edited based on the management of individual cavities.
- Table including all cavities of a tool in order to show and edit cavity-related data including the option of releasing or blocking single cavities.
- Automatic calculation of resource partitioning from the sum of currently released cavities.

Cavity Assignment

Overview

Menu	Master data → Resources → Cavity assignment
Transaction code	rescav
Function authorization	mdrcav

Purpose

The function allows to manage single cavities of a resource. All cavities together specify the partitioning of a resource, i.e. the parts produced per machine cycle.

Integration

For example: you can reference the cavities of a resource in the CAQ module.

Selection criteria

The application provides the following selection criteria:

Resource type

Use this selection criteria to specify the resource type.

Resource

Use this selection criteria to specify the resource.

Cavity number

Unique identification of the cavity

Field descriptions

Resource type

Resource type

Resource

Unique name of the resource

Cavity number

Unique identification of the cavity

Position

Cavity position within the resource

Lock

This checkbox specifies if the assignment is locked. During the automatic identification of the current partitioning, the system does not count locked assignments.

Blocking text

You can optionally enter a reason for the locked cavity.

Processing notes

If the option *Partitioning due to cavities* is enabled in the [Resource configuration](#) in tab *Resource configuration* and if you then change the cavity assignment, then the following fields are updated:

- The field *Original partitioning* shows the number of all cavities assigned.
- The field *Current partitioning* shows the number of cavities that are not locked.

These fields are included in the *Resource configuration*, in tab *Resource configuration*.