

HYDRA Documentation

Reorganization Database for HYDRA MW4.0pe

Version 1.0.23049

Last changed on: 02.09.2020

Copyright

©Copyright 2020 All rights reserved.

SAP® and R/3® are registered trademarks of SAP AG.

WINDOWS® is a registered trademark of Microsoft Corporation.

MPDV® and HYDRA® are registered trademarks of MPDV Mikrolab GmbH.

ORACLE® is a registered trademark of Oracle Corporation, California, USA.

Copying and distribution of this documentation or any part thereof, for any purpose or in any form, is prohibited without prior written permission from MPDV Mikrolab GmbH.

The information contained in this documentation is subject to change without prior notice.

Contents

1	Important Notes.....	4
2	Export Data	5
3	Delete Data	8
4	Changing exported Data	10
5	Import Data	14
6	Activating Licenses	18

1 Important Notes

Attention:

To perform the following procedures detailed knowledge of HYDRA and the used database system is required.

These procedures are performed on your own responsibility.

MPDV Mikrolab GmbH is not liable for any loss of data or for any destruction of data.

In case of doubt you might want to place an order with MPDV Mikrolab GmbH to perform these tasks for you.

This manual describes how to export, delete and import a complete HYDRA database.

It is not possible to export and import only parts of a HYDRA database.

If the following procedures are used to duplicate a HYDRA system, e.g. move the database contents from a productive to a test system, then you must be specially aware of any data interface configurations to ERP and PPS systems like SAP, etc..

If a duplicated system will be activated parallel to the source system with the same interface configurations this might lead to the loss of data or to the destruction of data.

Exchanging database contents between HYDRA systems is only allowed if the same versions of software, service packs and extensions are installed on both systems!

Otherwise you could lose configurations, data and installed extensions when replacing existing database contents.

In case of a duplication you might need to perform additional steps as described in the MPDV manual "**Change_Hostname_MW40_Server.pdf**".

When importing your database contents into a different HYDRA server you might need to replace the Installation-ID and the license keys and then request a new activation file from MPDV's Customer Service Center (CustomerServiceCenter@mpdv.com) before you can use that HYDRA server permanently.

Without activation you can use a HYDRA system for 30 days.

All licenses not activated within that period will become invalid.

2 Export Data

To get a completely reliable and consistent dataset it is necessary to shut down the HYDRA application before starting the data export!

If the data should be used in a test system where a 100% consistent dataset is not essential the export can be performed while HYDRA is still running.

If you are using HYDRAs MES Link Enabling (MLE) communication interface for the communication with ERP or PPS systems (e.g. like SAP R/3 or ECC) and the exported data from a productive HYDRA system is meant to be imported into a HYDRA test system it is strongly recommended to shut off the MLE communication interface within the HYDRA MOC client before starting the export.
For more detailed information please see the HYDRA user manuals.

Logon as user **mipadm** to the HYDRA server.

Open the environment for the desired HYDRA system:

Windows: Command prompt, e.g. "**MS-DOS MIP 1**"
UNIX: hsys.scr -X (e.g. **hsys.scr -1**)

Make sure you are located inside the matching HYDRA directory (HYDRADIR):

Windows: e.g. **d:\mip1**
UNIX: e.g. **/u1/mip1**

Check that there is enough disk space available for the designated drive letter or the file system to hold the expected amount of data.

Check if there is already an existing subdirectory named **hydra.exp**.

If there is, either delete it or rename it.

ATTENTION: Please make always sure that you are connected to the correct database instance and to the correct database and that you are really accessing the desired database contents.

This applies especially for HYDRA multi system installations.

- Windows: **hysql.exe -r -**
- UNIX: **hysql.out -r -**

- SQL Server:

determine database instance name:

```
SQL> select @@SERVERNAME;

OK. NR OF ROWS 1.

RESULT:

|0|0|1|0|0|128|HYDRASERVER\\MIPMS1|
```

determine database name:

```
SQL> select db_name();

OK. NR OF ROWS 1.

RESULT:

|0|0|1|0|0|128|mip1|
```

- ORACLE:

determine database instance name:

```
SQL> select * from v$instance;

OK. NR OF ROWS 1.

RESULT:

|0|0|1|0|3|8|1|0|16|mip1|0|64|HYDRASERVER|0|17|11.2.0.2.0|7|4|06/14/201
1|0|12|OPEN|0|3|NO|3|8|1|0|7|STOPPED|0|15|0|10|ALLOWED|0|3|NO|0|17|ACT
IVE|0|18|PRIMARY_INSTANCE|0|9|NORMAL|0|3|NO|
```

determine database name:

```
SQL> select name from v$database;

OK. NR OF ROWS 1.

RESULT:

|0|0|1|0|0|9|MIP1|
```

As soon as you made sure you are connected to the right database, please proceed as follows:

Start the export of the HYDRA database using the following command:

```
Windows:    hyexport.exe mip1
UNIX:       hyexport.out mip1
```

The export command creates a directory **mip1.exp**.

Inside this directory every database table gets its own text file.

Additionally there are the following two files:

```
mip1.sql      (Schema of the database)
mip1.dat      (Information regarding the extent sizes of database tables)
```

Check that no errors occurred during the database export.

Possible error messages are stored in the file **hyexport.err** in:

Windows: %HYDRADIR%\X\err (e.g. d:\mip1\1\err)
UNIX: \$HYDRADIR/X/err (e.g. /u1/mip1/1/err)
(X = HYDRA system number)

If you want to perform the export in any other directory than HYDRADIR you have to create subdirectories "**X/err**" in that directory first to be able to log possible errors (X = HYDRA system number), e.g.:

Windows: d:\export\X\err
UNIX: /u1/export/X/err

By using the following command it is possible to run a semi-automatic database export:

Windows: **sh.exe ./hyexport.scr**
UNIX: **./hyexport.scr**

hyexport.scr creates an export directory "mipX.exp" in HYDRADIR\X where X = HYDRA system number, e.g.:

Windows: d:\mip1\1\mip1.exp (example for HYDRA system 1)
UNIX: /u1/mip2/2/mip2.exp (example for HYDRA system 2)

If there is already an existing directory HYDRADIR\X\mipX.exp it will be automatically deleted by hyexport.scr before the new database export is created.

3 Delete Data

Before deleting an existing database it is strongly recommended to create a database backup first!

Logon as user **mipadm** to the HYDRA server.

Open the environment for the desired HYDRA system:

Windows: Command prompt, e.g. "**MS-DOS MIP 1**"

UNIX: `hysys.scr -X` (e.g. `hysys.scr -1`)

Make sure you are located inside the matching HYDRA directory (HYDRADIR):

Windows: e.g. `d:\mip1`

UNIX: e.g. `/u1/mip1`

ATTENTION: Please make always sure that you are connected to the correct database instance and to the correct database and that you are really accessing the desired database contents.

This applies especially for HYDRA multi system installations.

- Windows: `hysql.exe -r -`

UNIX: `hysql.out -r -`

- SQL Server:

determine database instance name:

```
SQL> select @@SERVERNAME;
```

OK. NR OF ROWS 1.

RESULT:

```
|0|0|1|0|0|128|HYDRASERVER\\MIPMS1|
```

determine database name:

```
SQL> select db_name();
```

OK. NR OF ROWS 1.

RESULT:

```
|0|0|1|0|0|128|mip1|
```

- ORACLE:

determine database instance name:

```
SQL> select * from v$instance;
```

OK. NR OF ROWS 1.

RESULT:

```
|0|0|1|0|3|8|1|0|16|mip1|0|64|HYDRASERVER|0|17|11.2.0.2.0|7|4|06/14/201
1|0|12|OPEN|0|3|NO|3|8|1|0|7|STOPPED|0|15|0|10|ALLOWED|0|3|NO|0|17|ACT
IVE|0|18|PRIMARY_INSTANCE|0|9|NORMAL|0|3|NO|
```

determine database name:

```
SQL> select name from v$database;
```

OK. NR OF ROWS 1.

RESULT:

```
|0|0|1|0|0|9|MIP1|
```

As soon as you made sure you are connected to the right database, please proceed as follows:

Please make sure that all HYDRA services (Windows) or processes (UNIX) are shut down.

Delete all the HYDRA database contents by using the following command:

Windows: **hysql.exe -O**

UNIX: **hysql.out -O**

Confirm the security query with "J" to start deleting the database contents.

Attention! Delete all tables from user "mipadm" !!

Please enter "J" and confirm with RETURN: **J**

Check that no errors occurred during the delete process.

Possible error messages are stored in the file **hysql.err** in:

Windows: %HYDRADIR%\X\err (e.g. d:\mip1\1\err)

UNIX: \$HYDRADIR/X/err (e.g. /u1/mip1/1/err)

(X = HYDRA system number)

4 Changing exported Data

If the exported data is used to duplicate a HYDRA system, e.g. move the database contents from a productive to a test system, then you must be aware of the following issues:

- MLE interface configurations for SAP systems
- HYDRA path configurations
- Interface configurations in the HYDRA Scheduler, e.g. HYD-ZHK

ATTENTION: Improper manipulation of HYDRA database contents could cause damage to your HYDRA system.

Changing files containing exported HYDRA data is only allowed by using a text editor which is supporting **UTF-8** format, e.g.: **Notepad++Portable.exe**

Notepad++Portable.exe is included in every HYDRA system installation.

Windows: %HYDRADIR%\admtools\Notepad++Portable

UNIX: \$HYDRADIR/admtools/Notepad++Portable

MLE Interface Configuration:

If available MLE interface configurations for SAP systems were not deactivated before starting the database export this could be done by manipulating the exported data afterwards.

In the export directory (e.g. mip1.exp) open the file **hysap_logsys.unl** and change the attribute "active role" (ACT_ROLE) for the wanted logical system (LOGSYS) to **O (= Offline)**:

```
$COLUMNS$LOGSYS|LS_DESC|ACT_ROLE|PARAM1|PARAM2|BEARB|BEARB_DATE|BEARB_TIME|
FP|Fileport|P|F||12345|08/26/2004|33579|
SAP_PP|SAP_PP|O|R||12345|09/08/2011|35509|
SAP_HR|SAP_HR|O|R||12345|09/08/2011|35499|
```

Note: The contents of your file hysap_logsys.unl might differ from the examples above!

The following settings are possible for the attribute ACT_ROLE:

- P** Productive System
- T** Test System
- I** Integration System
- O** Offline

HYDRA Path Configuration:

In the export directory, e.g. mip1.exp open the file **hy_path.unl** and check all paths in the column **P_URL_PATH**. Change them if necessary.

Example for a Windows system:

```
$COLUMNS$PATH|P_SCHEME|P_USER|P_PASSWORD|P_HOST|P_PORT|P_URL_PATH|BEM|PARAM_STR_01|PARAM_STR_02|P
ARAM_STR_03|BEARB|BEARB_DATE|BEARB_TIME|
DNC|file|||hydra|0|1\\dncdaten|sample path for DNC|||12345|07/27/2012|0|
DOC|file|||hydra|0|1\\custom\\bde\\dokumente|sample path for dokuments|||12345|07/27/2012|0|
HYDRA|file|||hydra|0|. /1/grafik/bde|AIP path for workplace pictures|||12345|07/09/2013|0|
PDVARC|file|||0|. /1/custom/archive/pdv2/tnt/|PDV export path|||12345|05/24/2011|0|
PDVTRANS|file|||localhost|0|. /1/spool/|PDV transport path|||12345|05/24/2011|0|
SPOOLWSC|file|||localhost|0|d:\\mip1\\1\\spool|MOC path for spool access|||12345|05/24/2011|0|
MOCWPIMG|file|||localhost|0|d:\\mip1\\1\\grafik\\bde|MOC path for workplace
pictures|||12345|05/24/2011|0|
MOCLOGS|file|||localhost|0|d:\\mip1\\1\\prot|MOC path for system log files|||12345|05/24/2011|0|
MOCHRIMG|file|||localhost|0|d:\\mip1\\1\\grafik\\pze|MOC path for HR master data
pictures|||12345|05/24/2011|0|
MOCHRIF|file|||localhost|0|d:\\mip1\\1\\spool|MOC path for HR interfaces|||12345|05/24/2011|0|
MOCPROF|file|||localhost|0|d:\\mip1\\1\\profiles|MOC path for profiles|||12345|05/24/2011|0|
MOCHLS|file|||localhost|0|d:\\mip1\\1\\custom\\hls|simulation file storage
path|||12345|05/24/2011|0|
EFORMSTD|file|||localhost|0|d:\\mip1\\db_ace|path for external reports
(standard)|||12345|05/24/2011|0|
EFORMCUS|file|||localhost|0|d:\\mip1\\1\\custom\\caq\\reports|path for external reports
(customer)|||12345|05/24/2011|0|
PDVLAY|file|||localhost|0|d:\\mip1\\1\\custom|path for PDV layouts|||12345|05/24/2011|0|
MOCERRS|file|||localhost|0|d:\\mip1\\1\\err|MOC path for system error
files|||12345|05/24/2011|0|
MOCREP|file|||localhost|0|d:\\mip1\\1\\custom\\reports|MOC path for
reports|||12345|05/09/2012|0|
MOCMPARK|file|||localhost|0|d:\\mip1\\1\\custom\\mpark|Layouts for MOC
MPARK2|||12345|06/18/2013|0|
PSREPORT|file|||localhost|0|d:\\mip1\\1\\custom\\eReporting|eReport export
target|||PATCH|11/02/2017|0|
PSLXML|file|||localhost|0|d:\\mip1\\1\\custom\\eReporting|eReport application configuration
|||PATCH|11/02/2017|0|
```

Note: The contents of your file hy_path.unl might differ from the examples above!

If the data should be imported on another HYDRA server all entries for column **P_HOST** need to be checked and changed if necessary, e.g.:

```
$COLUMNS$PATH|P_SCHEME|P_USER|P_PASSWORD|P_HOST|P_PORT|P_URL_PATH|BEM|PARAM_STR_01|PARAM_STR_02|P  
ARAM_STR_03|BEARB|BEARB_DATE|BEARB_TIME|  
DNC|file|||hydra|0|1\\dnccaten|sample path for DNC||||12345|07/27/2012|0|  
DOC|file|||hydra|0|1\\custom\\bde\\dokumente|sample path for dokuments||||12345|07/27/2012|0|  
HYDRA|file|||hydra|0|. /1/grafik/bde|AIP path for workplace pictures||||12345|07/09/2013|0|  
PDVARC|file|||0|. /1/custom/archive/pdv2/tnt/|PDV export path||||12345|05/24/2011|0|
```

Interface Configurations in the HYDRA Scheduler:

If there are interface configurations in the HYDRA Scheduler, e.g. to automatically transfer interface files between HYDRA and ERP systems (HYD-ZHK), they need to be checked and changed if necessary.

In the export directory (e.g. mip1.exp) open the file **hyd_scheduler.unl** and change all appropriate settings, e.g.:

```
$COLUMNS$VERWEIS|ENTRYTYPE|ENTRYOPT|INTERVAL|EXECUTE_FROM|EXECUTE_TO|FIX_HOUR|FIX_MINUTE|FIX_DAY|
FIX_MONTH|FIX_WEEKDAY|FIX_YEAR|COMMAND|DESCRIPTION|PRODUCTKEY|LICENSEKEYS|BEARB|BEARB_DATE|BEARB_
TIME|HYDRAUSER|BEGIN_DATE|BEGIN_TIME|END_DATE|END_TIME|ENTRY_ACTIVE|ENTRY_STATE|PID|SCHEDULER_ID|
...
20|I|CCV|3600|0|0|0|0|0|0|sh.exe      ./hyd_zhk.scr      MOD=GET      LOCAL=./1/inf_int/interf/HY72PPS.DAT
REMOTE="//server//sharename//path/filename"|HYD-ZHK      (SIS-MWV)      time
control      for      host      communication      via      network      share|HYD-ZHK|HYD-
ZHK|12345|04/05/2018|49851|0|04/05/2018|47943|04/05/2018|47949|N|NR||hysched.cfg|
21|I|CCV|3600|0|0|0|0|0|0|sh.exe      ./hyd_zhk.scr      MOD=PUT
LOCAL=./1/inf_int/interf/HY72ADRCK_TIMETICKET.DAT
REMOTE="//server//sharename//path/filename"|HYD-ZHK      (SIS-MWV)      time
control      for      host      communication      via      network      share|HYD-ZHK|HYD-
ZHK|12345|04/05/2018|49845|0|04/05/2018|47943|04/05/2018|47947|N|NR||hysched.cfg|
22|I|CCV|3600|0|0|0|0|0|0|sh.exe      ./hyd_zhk.scr      MOD=GET      HOST=server      USER=ftpuser      PWD=ftppasswd
LOCAL=./1/inf_int/interf/HY72PPS.DAT REMOTE="/pfad/dateiname"|HYD-ZHK (SIS-MWV) time control for
host      communication      via      FTP|HYD-ZHK|HYD-
ZHK|12345|04/05/2018|49839|0|04/05/2018|47944|04/05/2018|47949|N|NR||hysched.cfg|
23|I|CCV|3600|0|0|0|0|0|0|sh.exe      ./hyd_zhk.scr      MOD=PUT      HOST=server      USER=ftpuser      PWD=ftppasswd
LOCAL=./1/inf_int/interf/HY72ADRCK_TIMETICKET.DAT REMOTE="/pfad/dateiname"|HYD-ZHK (SIS-MWV) time
control      for      host      communication      via      FTP|HYD-ZHK|HYD-
ZHK|12345|04/05/2018|49833|0|04/05/2018|48004|04/05/2018|48009|N|NR||hysched.cfg|
...
```

Note: The contents of your file **hyd_scheduler.unl** might differ from the examples above!

5 Import Data

Before importing data it is recommended for ORACLE to deactivate the Archive-Log-Mode and for SQL Server to change the Recovery Mode from "Full" to "Simple" if they are active.

Logon as user **mipadm** to the HYDRA server.

Open the environment for the desired HYDRA system:

Windows: Command prompt, e.g. "**MS-DOS MIP 1**"
UNIX: `hsys.scr -X` (e.g. `hsys.scr -1`)

Make sure you are located inside the matching HYDRA directory (HYDRADIR):

Windows: e.g. `d:\mip1`
UNIX: e.g. `/u1/mip1`

ATTENTION: Please make always sure that you are connected to the correct database instance and to the correct database and that you are really accessing the desired database contents.

This applies especially for HYDRA multi system installations.

- Windows: `hysql.exe -r -`
UNIX: `hysql.out -r -`

- SQL Server:

determine database instance name:

```
SQL> select @@SERVERNAME;  
  
OK. NR OF ROWS 1.  
  
RESULT:  
  
|0|0|1|0|0|128|HYDRASERVER\\MIPMS1|
```

determine database name:

```
SQL> select db_name();  
  
OK. NR OF ROWS 1.  
  
RESULT:  
  
|0|0|1|0|0|128|mip1|
```

- ORACLE:

determine database instance name:

```
SQL> select * from v$instance;
```

OK. NR OF ROWS 1.

RESULT:

```
|0|0|1|0|3|8|1|0|16|mip1|0|64|HYDRASERVER|0|17|11.2.0.2.0|7|4|06/14/201
1|0|12|OPEN|0|3|NO|3|8|1|0|7|STOPPED|0|15|0|10|ALLOWED|0|3|NO|0|17|ACT
IVE|0|18|PRIMARY_INSTANCE|0|9|NORMAL|0|3|NO|
```

determine database name:

```
SQL> select name from v$database;
```

OK. NR OF ROWS 1.

RESULT:

```
|0|0|1|0|0|9|MIP1|
```

As soon as you made sure you are connected to the right database, please proceed as follows:

Please make sure that all HYDRA services (Windows) or processes (UNIX) are shut down.

Make sure that the exported data from chapter "[2 Export Data](#)" (mip1.exp or mipX.exp) is available in your HYDRADIR and the database contents are deleted as described in chapter "[3 Delete Data](#)".

Now you can import the data using the following command:

Windows: **hyimport.exe mip(X)**

UNIX: **hyimport.out mip(X)**

Check that no errors occurred during the data import.

Possible error messages are stored in the file **hyimport.err** in:

Windows: %HYDRADIR%\X\err (e.g. d:\mip1\1\err)

UNIX: \$HYDRADIR/X/err (e.g. /u1/mip1/1/err)

(X = HYDRA system number)

If you want to perform an import from any other directory than HYDRADIR you have to create subdirectories "**X\err**" in that directory first to be able to log possible errors (X = HYDRA system number), e.g.:

Windows: d:\export\X\err

UNIX: /u1/export/X/err

After a successful data import update the database statistics for the HYDRA database.

Therefor use the following commands:

Windows: **hysql.exe -r -**

UNIX: **hysql.out -r -**

```
15.06.2011 14:25:06 PROCESSING STDIN...
```

```
SQL> update statistics;
```

It must return something like this:

```
OK. NR OF ROWS 1234.
```

```
RESULT:
```

```
|0|0|0|0|
```

```
SQL> exit
```

Make sure to reactivate the Archive-Log-Mode (ORACLE) or the Recovery Mode "Full" (SQL Server) if it was active before.

Check that the imported data is correctly distributed to the available tablespaces of the HYDRA database by using the following command:

Windows: **hydbsize.exe**

UNIX: **hydbsize.out**

If the above mentioned procedures were used to duplicate a HYDRA system then you might need to perform additional steps now as described in the MPDV manual "**Change_Hostname_MW40_Server.pdf**".

Before starting HYDRA it is absolutely necessary to check the HYDRA path configurations and make sure they apply to your HYDRA system and to your HYDRA server.

You can use menu “System administration – Path configuration” of the HYDRA Maintenance Manager for that purpose:

Name	Protocol	Host	Port	User	Path	Designation
DNC	file	192.168.20.167	0		1\dncdaten	sample path for DNC
DOC	file	192.168.20.167	0		1\custom\bde\dokumente	sample path for documents
EFORMCUS	file	localhost	0		d:\mip\1\1\custom\caq\reports	path for external reports (customer)
EFORMSTD	file	localhost	0		d:\mip\1\1\db_ace	path for external reports (standard)
HYDRA	hydra	192.168.20.167	0		1\grafik\bde	AIP path for workplace pictures
MOCERRS	file	localhost	0		d:\mip\1\1\err	MOC path for system error files
MOCHRS	file	localhost	0		d:\mip\1\1\custom\hls	simulation file storage path
MOCHRIF	file	localhost	0		d:\mip\1\1\spool	MOC path for HR interfaces
MOCHRIMG	file	localhost	0		d:\mip\1\1\grafik\pze	MOC path for HR master data pictures
MOCLOGS	file	localhost	0		d:\mip\1\1\prot	MOC path for system log files
MOCMPARK	file	localhost	0		d:\mip\1\1\custom\mpark	Layouts for MOC MPARK2
MOCPROF	file	localhost	0		d:\mip\1\1\profiles	MOC path for profiles
MOCREP	file	localhost	0		d:\mip\1\1\custom\reports	MOC path for reports
MOCWPIMG	file	localhost	0		d:\mip\1\1\grafik\bde	MOC path for workplace pictures
PDVARC	file		0		1\custom\archive\pdv2\hnt\	PDV export path
PDVLAY	file	localhost	0		d:\mip\1\1\custom	path for PDV layouts
PDVTRANS	file	localhost	0		1\spool\	PDV transport path
PSLLXML	file	localhost	0		d:\mip\1\1\custom\leReporting	eReport application configuration
PSREPORT	file	localhost	0		d:\mip\1\1\custom\leReporting	eReport export target
QMIMP	file	localhost	0		d:\mip\1\1\caq_ip\l\mea	Import path for Inspectionplancharacteristics
QMIMPBCK	file	localhost	0		d:\mip\1\1\caq_ip\l\backup	Backup import path for Inspectionplancharacteristics
QMIMPLCF	file	localhost	0		d:\mip\1\1\caq_ip\l\err	Log path for import of Inspectionplancharacteristics
QMIMPLCF	file	localhost	0		d:\mip\1\1\caq_ip\l\configuration	Control path for Inspectionplancharacteristics import
SPOOLWSC	file	localhost	0		d:\mip\1\1\spool	MOC path for spool access

Before you start HYDRA again make absolutely sure that there are no mutual interactions and no possible conflicts regarding the MLE interface to ERP and PPS systems like SAP because of using identical database contents in different HYDRA systems.

As soon as all necessary procedures are finished you can start your HYDRA application again.

Make sure that your HYDRA system runs properly.

6 Activating Licenses

Every HYDRA MW4.0pe system need to have a unique Installation-ID assigned and appropriate license keys installed.

Without activating the licenses you can use a HYDRA system for 30 days.

All licenses not activated within that period will become invalid.

If data was copied from an existing HYDRA system to a different HYDRA system you need to replace the Installation-ID and the license keys with the ones intended for the new HYDRA system.

Logon to the HYDRA server as local user "**mipadm**".

Open the environment for the HYDRA system you want to work in.

e.g. start the command prompt "**MS-DOS MIP 1**"

Make sure you are located in the HYDRA installation directory (HYDRADIR), e.g.:

```
cd d:\mip1
```

Connect to the database and delete the old license keys:

```
hysql.exe -r -
```

```
SQL> delete from hyd_license;
```

```
SQL> delete from hyd_license_status;
```

```
SQL> exit
```

Set the new Installation-ID (see first line of the new license file):

```
hyliz.exe -k <Installation-ID>
```

When copying data from an existing system the system number has already been set and this command will not change it. You have to do it manually by using the HYDRA MOC Client later.

Copy the new license file to HYDRADIR of the new HYDRA system and load them into the database, e.g.:

```
hyliz.exe -f lizenz.dat > lizenz.pro
```

Check file lizenz.pro and make sure that every license was loaded successfully ("**Inserting successful**").

After that you might need to request a new activation file from MPDVs Customer Service Center (CustomerServiceCenter@mpdv.com) before you can use that new HYDRA system permanently.

For more details see the MPDV manual "**HYDRA_LicenseSetup.pdf**".

Please contact MPDVs Customer Service Center (CustomerServiceCenter@mpdv.com) if you need support requesting a new activation file or activating your HYDRA licenses.

