3.2 Lubrication

Replace the lubricant in the bearing housing every 4,000 operating hours.

Apply grease to the motor bearings every 1,000 operating hours.

5. Maintenance Schedule

Inspect the mechanical seal for leakage every 2,000 operating hours.

If vibration exceeds 4.5 mm/s, stop the pump and check shaft alignment.

Maximum discharge pressure is 10 bar. Inspect the suction filter monthly.