

Supported Bootloader Commands

Host Sends	Command Code	Bootloader Replies	Notes
BL_GET_VER	0x51	Bootloader version number (1byte)	This command is used to read the bootloader version from the MCU
BL_GET_HELP	0x52	All supported Command codes (10 bytes)	This command is used to know what are the commands supported by the bootloader
BL_GET_CID	0x53	Chip identification number (2 bytes)	This command is used to read the MCU chip identification number
BL_GET_RDP_STATUS	0x54	Returns the FLASH Read Protection level. (1byte)	This command is used to read the FLASH Read Protection level.
BL_GO_TO_ADDR	0x55	Success or Error Code (1byte)	This command is used to jump bootloader to specified address.
BL_FLASH_ERASE	0x56	Success or Error Code (1byte)	This command is used to mass erase or sector erase of the user flash .
BL_MEM_WRITE	0x57	Success or Error Code (1byte)	This command is used to write data in to different memories of the MCU