AN2606 Contents



AN2606

AN2606 List of tables

List of tables AN2606

AN2606 List of tables

AN2606 List of figures

General information AN2606

Glossary AN2606

AN2606 Glossary



AN2606 Rev 35 31/303

7.2 Bootloader selection

The figure below shows the bootloader selection mechanism.

Figure 8. Bootloader selection for STM32F05xxx a.0ele 0m1 cm 71.520430x5.4dev52043(F)5.9(c



AN2606 Rev 35 37/303



AN2606 Rev 35 39/303



12 STM32F09xxx devices bootloader

12.1 Bootloader configuration

The STM32F09xxx bootloader is activated by applying pattern6 (described in *Table 2: Bootloader activation patterns*). The following table shows the hardware resources used by this bootloader.

Note: After the STM32F09xxx devices have booted in bootloader mode using USAR bo

- 13 STM32F10xxx devices bootloader
- 13.1 Bootloader configuration





AN2606 Rev 35 59/303



AN2606 Rev 35 61/303

16.2.3 Bootloader version

The following table lists the STM32F2xxxx devices V3.x bootloader versions:

Table 31. STM32F2xxxx bootloader V3.x versions

Bootloader		
version	Description	Known limitations
number		



AN2606 Rev 35 71/303





AN2606 Rev 35 81/303








32 STM32F413xx/423xx devices bootloader

32.1 Bootloader configuration

The STM32F413xx/423xx bootloader is activated by applying pattern1 (described in



33.1.3 Bootloader version





The system clock is derived from the embedded internal high-speed RC for USARTx, I2Cx and SPIx bootloaders. This internal clock is also used for CAN and DFU (USB FS Device) but only for the selection phase. An external clock multiple of 1 MHz (between 4 and 26 MHz) is required for CAN and DFU bootloader execution after the selection phase.





36 STM32F72xxx/73xxx devices bootloader

36.1 Bootloader configuration

The STM32F72xxx/73xxx bootloader is activa







38.3 Bootloader version

The following table lists the STM32F76xxx/77xxx devices bootloader V9.x versions.

Table 81.STM32F76xxx/77xxx bootloader V9.x versions

Bootloader		
version	Description	Known limitations
number		



42 STM32L031xx/041xx devices bootloader

42.1 Bootloader configuration

The STM32L031xx/041xx bootloader is activated by applying pattern2 (described in *Table*



43.2 Bootloader selection

The figure below shows the bootloader selection mechanism.

Figure 53. Bootloader selection for STM32L05xxx/06xxx

43.3 Bootloader version





44.2 Bootloader V11.x





50.3 Bootloader version

The Table 107













AN2606 Rev 35 261/303







AN2606

AN2606 Bootloader timing

AN2606 Bootloader timing

AN2606 Bootloader timing



Revision history AN2606

294/303 AN2606 Rev 35

Revision history AN2606

302/303 AN2606 Rev 35