

Industrial Pump Maintenance Manual (Sample)

Overview

Industrial centrifugal pumps transport liquids in factories. Preventive maintenance reduces downtime and improves reliability.

Preventive Maintenance

- Inspect bearings weekly.
- Lubricate bearings regularly.
- Check shaft alignment monthly.
- Replace worn seals immediately.
- Monitor vibration and operating temperature.

Common Problems

Pump overheating may be caused by poor lubrication, bearing failure, shaft misalignment, blocked cooling passages, or overload.

Low flow may result from suction blockage, clogged filters, air leaks, or impeller wear.

Safety

Always isolate electrical power, release system pressure, and wear PPE before maintenance.