

- Insert the prepared bearing in the Y-belt-idler.
- Bearing housing orientation doesn't matter.
- Secure the bearing with the M3x18 screw. Don't fully tighten the screw.
- Place your finger on the bearing and ensure it can rotate freely. If needed adjust the screw.

