

- There is a flat part on the motor shaft, rotate it upwards.
- One of the screws must be facing directly against the pad (flat part) on the shaft. Slightly tighten both screws.
- Don't press the pulley against the motor. Leave a gap so the pulley can rotate freely.
- Don't tighten the pulley firmly yet, we'll get to that later.

