

particular dirty device, you may need to repeat the cleaning process several times.

DRIVE FAILURE SYMPTOMS AND REMEDY

Although a lot of CD – ROM problems are caused by software or firm ware or set-up problems, it is possible for the drives themselves to fail if a fault occurs in the drive or its adaptor board. It is better to replace the defective device outright.

The symptoms include,

A computer BIOS is unable to detect a drive that formally worked normally

Possibility: This could be an outright failure of the drive itself.

Troubleshooting

- i. Power down the system then reboot the system.
- ii. If you have recently worked on the system (inside) it is possible that the power or data cable were left disconnected or they may have got damaged. Check to confirm that such did not happen.
- iii. If you install on SATA hard drive in a system that was previous all data and the optical drives “disappears” make sure that the OS is fully updated.
- iv. If the problem persists check the physical interface cable between the drive and its adaptation board

THE DISC DOES NOT TURN

Possibility: this could be a problem with the drive positioning, installation or set-up issue

Troubleshooting

- i. Check to ensure that the disk is seated properly and is not jammed or obstructed.
- ii. Review the drive installation and set-up carefully to ensure that the drive is properly configured for operation. If the drives BUSY LED comes ON when