E.g. powertrace log line "60572 ID:2 7686 P 0.18 1 21915 1944478 702 1966095 0 0 9891 972768 0 983036 0 0 (radio 100.-8735% / 100.-8738% tx 0.03% / 0.00% listen 99.-8639% / 100.-8738%)"

## Core Node Information

- `60572`: Cooja simulation time stamp (in milliseconds).
- `ID:2`: The unique identifier of the node (**Mote ID 2**).
- `7686`: Contiki internal clock time tick.
- `P`: Line identifier prefix indicating **Power trace metrics**.
- `0.18`: Node link-layer address (printed as `Rime` or `Link` address `0.18`).
- `1`: Powertrace log sequence number (`seqno`).

## Cumulative Metrics (Since Simulation Boot)

These values represent the **total hardware clock ticks** (`energest` ticks) accumulated since the node started running: [

- `21915` (`all_cpu`): Total active microcontroller CPU ticks.
- `1944478` (`all_lpm`): Total Low Power Mode (sleep) ticks.
- `702` (`all_transmit`): Total radio transmission (Tx) ticks.
- `1966095` (`all_listen`): Total radio listening/reception (Rx) ticks.
- `0` / `0`: Total idle transmit and idle listen metrics.

## Interval Metrics (For Current Reporting Window Only)

These figures capture the change in hardware ticks strictly during the **last reporting period**:`9891` (`cpu`): Active CPU ticks in this interval.

- `972768` (`lpm`): Sleep mode ticks in this interval.
- `0` (`transmit`): Radio transmission ticks in this interval (the node did not transmit data during this window).
- `983036` (`listen`): Radio listen ticks in this interval.
- `0` / `0`: Idle window transmission and listening ticks.

## Duty Cycle Summary Statistics

The section inside parentheses `(...)` calculates the duty cycles using the format: **(Cumulative Average % / Current Interval %)**

- `radio 100.-8735% / 100.-8738%`: Overall combined radio duty cycle.
- `tx 0.03% / 0.00%`: The radio was transmitting **0.03%** of the time overall, and **0.00%** during this interval.
- `listen 99.-8639% / 100.-8738%`: The radio spent nearly **100%** of its time listening for packets.

Data Source Map (Where to find the values)

| Column Name | Source in Powertrace Output Line / Cooja | How to fill it |
|---|---|---|
| **Scenario** | simulation settings | Pre-filled: **A NullRDC**, **B ContikiMAC**, or **C High Rate**. |
| **Node** | `ID:X` | Put the specific node ID you are evaluating (e.g., Node 2). It's best to check a source node and a sink/sink node. |
| **CPU %** | Calculated from Interval or Cumulative ticks | $$c = \frac{\text{CPU Ticks}}{\text{CPU Ticks+LPM Ticks}} \times 100$$ |
| **LPM %** | Calculated from Interval or Cumulative ticks | $$l = \frac{\text{LPM Ticks}}{\text{CPU Ticks+LPM Ticks}} \times 100$$ |

| | | |
|---|---|---|
| **TX %** | Inside the `(...)` block at the end | Read the percentage value directly following `tx`. |
| **Listen %** | Inside the `(...)` block at the end | Read the percentage value directly following `listen`. (Fix the negative decimal bug if present). |
| **Radio %** | Inside the `(...)` block at the end | Read the total percentage value directly following `radio` (TX % + Listen %). |
| **PDR** | Cooja script log or text parsing | $\text{PDR} = \frac{\text{Total Packets Received by Sink}}{\text{Total Packets Sent by Nodes}} \times 100$ |
| **Notes** | Your observation | Note down behavioral trends (e.g., "High power consumption because radio is always on"). |