
5.4 GUIDANCE TRANSMITTER UNIT (GTU) SETUP

INITIAL SETUP:

Tools and Special Tools

MI GTU Test tool
GtuTxCal tool
Portable ILS Receiver
Handheld Radio (2 ea.)

References

5 System Configuration WP
6.2 Calibration WP

Materials/Parts

Full system hardware with GTU installed

Equipment Condition

5.3 System & Software Startup WP Completed
Equipment Powered On
Generator or Shore power applied

Personnel Required

Technician (2)

GENERAL INFORMATION

- This procedure contains instructions for the GTU setup.
 - The following procedure will need to be repeated for the second rack if system is configured with dual racks.
 - Switch to the rack being configured on the Remote Control Unit (RCU).
-

GTU Setup Procedures

Set GTU Frequency

NOTE

Perform the following Steps for each GTU

1. Set GTU Frequency from the Maintenance Interface as follows:
 - a. Ensure system software is stopped.
 - b. Select GTU Frequency Program from System dropdown.
 - c. Select Frequency from Localizer Frequency dropdown.
 - d. Select Program.

Set Carrier Power

NOTE

- Perform the following Steps for each GTU.
- Ensure only one GTU is on at a time.

1. Set Carrier Power from the Maintenance Interface as follows:
 - a. Open GTU Test from System dropdown.
 - b. Enable Localizer and Glideslope transmitter by clicking Loc On and GS On.
 - c. Ensure carrier power is set to 2.100-2.300 volts.
2. Uncheck Enable in the localizer and Glide Slope control boxes.
3. Make DSA adjustments in Status box of Localizer and Glide Slope sections.
 - a. If over 2.2v increase DSA attenuation level.
 - b. If below 2.2v decrease DSA attenuation level.
4. Turn on Localizer and Glide Slope to verify carrier Power Settings.
5. Repeats Steps 3-5 until carrier power is within limits.
6. Uncheck Enable and repeat steps for each GTU.
7. Uncheck Enable on both Loc and GS.
8. Select Close.

END OF TASK

THIS PAGE LEFT INTENTIONALLY BLANK